




ENGINE IGNITION, STARTING AND RECHARGING

INDEX

IGNITION COILS	05 - 3	ALTERNATOR.....	05-11
- Removal/Refitting.....	05 - 3	- Removal/Refitting	05-11
- Checks and inspections	05 - 3	TECHNICAL CHARACTERISTICS	
SPARK PLUGS		AND SPECIFICATIONS	
- Checking and replacement	05 - 3	- Battery.....	05-13
	05 - 4	- Alternator	05-13
BATTERY	(*)	- Starter motor.....	05-13
		- Ignition coils	05-13
		- Tightening torques	05-13
STARTER MOTOR.....	05 - 4		
- Removal/Refitting.....	05 - 5		
- Dis-assembly	05 - 6		
- Re-assembly	05 - 9		
- Checks and inspections.....	05 - 9		

(*): See INSTRUCTIONS FOR REPAIR - ENGINES - PA4655B1000000






ILLUSTRATED INDEX


IGNITION COILS

Pag. 05 - 3




STARTER MOTOR

Pag. 05 - 4




SPARK PLUGS

Pag. 05 - 3




ALTERNATOR

Pag. 05-11



IGNITION COILS

The ignition system includes two spark plugs per cylinder in an asymmetrical position which differ in size. This static distribution system with lost spark has four coils, each of which supplies the spark plug of the cylinder below and simultaneously that of the paired cylinder (1-4) (2-3). This system is a sophisticated evolution of the T-Spark ignition system.




This new system offers further advantages, such as:

- limited high voltage cable routing thereby achieving increased reliability and lowering electrical interferences;
- the position and length of the cables makes it impossible to invert the connection of the cables to the corresponding spark plugs during servicing operations.


REMOVAL/REFITTING

- Disconnect the battery (-) terminal.
- 1. Slacken the fastening screws and remove the ignition coils cover.
- 2. Disconnect the electrical connections from the ignition coils.



1. Remove the high voltage cables.
2. Slacken the fastening screws and remove the ignition coils.

- If necessary, slacken the fastening screws and remove the ignition coil support bracket.



CHECKS AND INSPECTIONS


- Check that the ignition coil characteristics are within the specified limits. If not, change the coils.

Specifications	
Primary winding resistance	0.3 Ω ± 12%
Secondary winding resistance	7k Ω ± 12%

SPARK PLUGS

The standard spark plugs are of the type with surface discharge with one point and a centre electrode.


In order to operate correctly a precise gap must be maintained between the electrodes.





The spark plugs are positioned asymmetrically in the bursting chamber and they differ in size as shown in the following diagram.

CENTRE SPARK PLUGS LARGE - M14



SIDE SPARK PLUGS SMALL - M10

Firing order

1 - 3 - 4 - 2

When fitting, tighten the spark plugs to the following torque:

Centre spark plugs (large - M14)	25 + 35 Nm 2.6 + 3.6 kgm
Side spark plugs (small - M10)	10 + 12 Nm 1 + 1.2 kgm



- Melted electrodes: overheating due to unsuitable combustion, valve defects;
- Highly worn electrode: damaging additives in the fuel or oil, pinging or overheating;
- Etc.

CHECKING AND REPLACEMENT

- With the engine cold, remove the spark plugs blowing inside to remove any traces of dirt.
- Check for dirt or breaks on the ceramic insulation, in which case change the spark plugs.



CAUTION:

The use of spark plugs of a different type or size than those specified can cause serious damage to the engine and alter the level of harmful emissions at the exhaust.



CAUTION:

A dirty or burnt out spark plug is often symptomatic of a fault in the engine supply system. For example:

- Traces of carbon powder: incorrect mixture, air cleaner very dirty;
- Oil stains: oil seepage from the piston rings;
- Formation of ash: presence of aluminium material, especially in the oil;




Due to a freewheel coupling, the pinion disengages when the main engine turns faster than the motor. A relay energized by the motor current engages the pinion through a fork.


The starter motor installed is of the translating screw pinion type, with relay housed directly above the starter motor.

REMOVAL/REFITTING


- Set the car on a lift.
- Disconnect the battery (-) terminal.
- 1. Disconnect the electrical connections of the lambda sensor.




1. Raise the car, slacken the fastening screws and remove the reinforcement bracket.
2. Remove the front section of the exhaust pipe complete with lambda sensor after slacken the fastenings.



1. Slacken the screws fastening the power steering box to the suspension crossmember.




1. Disconnect the electrical connections from the starter motor.
2. Slacken the three fastening screws and remove the starter motor.






DIS-ASSEMBLY




WARNING:

Owing to their structure, compared with the previous versions, the starter motors are more sensitive to shocks, bumps and squashing.


1. Fasten the starter motor on the vice fitted with protective jaws as illustrated.
2. Slacken the nut fastening the terminal to the coupling relay.




1. Slacken the two fastening screws and remove the dust cover.
2. Remove the circlip, slacken the fastening studs and remove the collector side support.




1. If necessary replace the bushing on the manifold side support using a suitable tool.




1. Release the fastening clamps and from the brush holder plate withdraw the two brushes connected directly to the polar frame.



1. Remove the brush holder plate withdrawing it from the rotor.




1. Withdraw the polar frame from the rotor.







1. From the drive side support, withdraw the rotor assembly, epicyclic gear with idler and fork levers.



1. Separate the epicyclic gear with idler from the rotor and from the fork levers.




1. Using a suitable bush and rubber hammer tap the stop ring of the starting coupling.




1. Remove the circlip and withdraw the starting coupling from the inverter shaft.




WARNING:
Removing the circlip avoid damaging the inverter shaft.
Carefully eliminate any burrs in the inverter shaft groove, otherwise the inverter shaft will be damaged



1. Remove the circlip, retrieve the washers and separate the fork lever connection from the starting coupling.




- The prod of the starting relay which actuates the starting control fork trigger; if not replace the electromagnet.



RE-ASSEMBLY

- Re-assemble the starter motor reversing the sequence followed for dis-assembly and observing the following instructions.
- Lubricate the components illustrated below with the specified products.




- a. Oil
- b. Grease
- c. Silicone grease


CHECKS AND INSPECTIONS

- Clean the rotor, internal toothed gear, the gear with idler and the relay only with compressed air (max 4 bar) and a clean cloth. Do not use liquid detergents.

1. Remove the protection plate.
2. Remove the circlip, then withdraw the inverter and differential drive wheel.
3. Retrieve the washers.



1. If necessary replace the bushing on the control side support using a suitable tool.



Checking the efficiency of the coupling relay

- Position the coupling relay on the test bench top and supply the actual top negatively (alternatively connect to the (-) of the battery).
- Connect the positive pole of the test bench or battery to the positive pole of the relay short circuited with the starting pin.



The other parts, such as screws and rotor shaft may be washed using unflammable liquid detergents normally to be found on the market.



WARNING:
Thoroughly dry the washed parts, otherwise in the sealed motor explosive gases may form.

Checking the outside of the collector

- Check the collector for signs of worn points; in which case turn it proceeding as follows:
- Tighten the rotor on the collector and drive side supports taking care not to damage the rotor shaft.



WARNING:
When turning do not tighten the rotor shaft in the centering.

Turn the collector using suitable tools checking that the diameter is within the specified limits.



Minimum diameter of collector
28.3 + 28.4 mm

Also check that the eccentricity of the collector and stator pack is within the specified limits.



Collector eccentricity	≤ 0.01 mm
Plate pack eccentricity	≤ 0.05 mm

If the collector reveals annealed points or interruptions, replace the rotor.

Collector continuity test

- Set the tester prods on the collector plates and check that the tester signals the passage of current.
- In the lack of electrical continuity replace the rotor.
- Repeat the above operations for all the pairs of corresponding plates.



ALTERNATOR

When the engine is running the alternator supplies electrical energy to the electronic control units and to the various services which can be operated at all times. It also charges the accumulator (battery), so that it can deliver current when the engine is stationary.

The electric current is produced by a stator which "cuts" the magnetic field generated by a rotary coil (rotor). The rotor is integral with a pulley operated directly by the crankshaft through a belt.

The contact brushes supply the rotor with the excitation current.

The alternate current generated by the alternator is rectified by the diodes and adjusted by the voltage regulator located on the alternator body.

The electronic voltage regulator used is compact in size and it warrants constant voltage in all fields of operation of the engine, regardless of the changes in load and rpm.

A cooling fan turns together with the pulley to prevent the alternator from reaching dangerous temperatures that might adversely affect its operation.


The alternator installed is of the type with claw terminals and collector rings; it is very light and compact.

CAUTION:


The fan will correctly cool the alternator if it turns clockwise (seen from pulley side).

REMOVAL/REFITTING


- Set the car on a lift.
- Disconnect the battery (-) terminal.
- 1. Disconnect the lambda sensor electrical connections.



- Raise the car.
- Remove the right front wheel and mud flaps.
- 1. Working as shown on the guide pulley, slacken the tension of the auxiliary components drive pulley and remove it.




- 1. Slacken the fastening screws and remove the reinforcement bracket.
- 2. Remove the front section of the exhaust pipe complete with lambda probe after slackening their fastenings.







- Slacken the screws fastening the power steering box to the suspension crossmember.




- Set a hydraulic jack under the gearbox as illustrated.
- Slacken the fastening screws and remove the rear power unit support.



- Disconnect the electrical connections from the alternator.



- Slacken the two fastening bolts and remove the alternator retrieving it from under the car pulling it out of the opening obtained by removing the power unit rear support.



TECHNICAL CHARACTERISTICS AND SPECIFICATIONS

BATTERY

Nominal voltage	12 V
Capacity	45 A/h 50 A/h with air conditioner

ALTERNATOR

Nominal voltage	14 V
Nominal current	100 A
Maximum continuous speed	18000 rpm
Inductor winding resistance (measured between collector rings at 20 °C)	2.6 Ω ± 5%

STARTER MOTOR

	1770		1350		1772	
	12	1.4	12	1.4	12	1.4
Nominal voltage (V)	Not available at time of going to press					
Nominal power rating (kW)	Not available at time of going to press					
Test under load	Voltage (V)	7 ± 0.1	325	1020	> 10.7	> 10.7
	Absorption (A)	< 90	> 4500	4 ± 0.1	< 750	> 21.5
	Revolutions (rpm)	> 10.7	< 90	> 4500	4 ± 0.1	< 750
	Torque (Nm)	> 10.7	< 90	> 4500	4 ± 0.1	< 750
Loadless test	Voltage (V)	12 ± 0.1	< 90	> 4500	4 ± 0.1	< 750
	Absorption (A)	< 90	> 4500	4 ± 0.1	< 750	> 21.5
	Revolutions (rpm)	> 10.7	< 90	> 4500	4 ± 0.1	< 750
	Torque (Nm)	> 10.7	< 90	> 4500	4 ± 0.1	< 750

IGNITION COILS

Primary winding resistance	0.3 Ω ± 12%
Secondary winding resistance	7 k Ω ± 12%

TIGHTENING TORQUES

PART	Nm	kgm
Centre spark plugs (large - M14)	25 + 35	2.6 + 3.6
Side spark plugs (small - M10)	10 + 12	1 + 1.2



ENGINE COOLING SYSTEM

INDEX


ENGINE COOLING SYSTEM	07-3
- Description	07-4
- Operation of the circuit	07-4
- Checking the level and changing the engine coolant fluid	07-4
- Expansion tank	07-5
- Removal/Refitting	07-5
- Pressurized cap sealing test	07-6
- Hydraulic system proof test	07-6
- Water pump	07-6
- Removal/Refitting	07-7
- Thermostat unit	07-9
- Removal/Refitting	07-9
- Radiator	07-10
- Removal/Refitting	07-10
- Dis-assembly	07-12
- Cooling fan	07-13
- Removal/Refitting	07-13
- Dis-assembly	07-13
- Fan control thermal contact (Specific for '95 versions)	07-14
- Removing/Refitting	07-14
- Checks and inspections	07-14
- Coolant temperature gauge transmitter and maximum temperature warning light	07-14
- Removal/Refitting	07-14
- Checks and inspections	07-14
TECHNICAL CHARACTERISTICS AND SPECIFICATIONS	
- Cooling system	07-15
- Thermostat	07-15
- Cooling fan thermal contact (Specific for '95 versions)	07-15
- Coolant temperature gauge transmitter and max. temperature warning light contact	07-15
- Tightening torques	07-15



ILLUSTRATED INDEX


EXPANSION TANK

Pag. 07 - 5




WATER PUMP

Pag. 07 - 6




RADIATOR


Pag. 07-10




COOLING FAN

Pag. 07-13




FAN CONTROL THERMAL CONTACT (Specific for  '95 versions)

Pag. 07-14




COOLANT TEMPERATURE GAUGE TRANSMITTER AND MAX. TEMP. WARNING LIGHT CONTACT

Pag. 07-14





THERMOSTAT UNIT

Pag. 07 - 9



ENGINE COOLING SYSTEM



- 1. Water pump
- 2. Thermostatic cup
- 3. Cooling fans
- 4. Radiator
- 5. Fan control thermal contact (Specific for  '95 versions)
- 6. Climate control unit heater

- 7. Expansion tank
- 8. Throttle body
- 9. Coolant temperature gauge sender and maximum temperature warning light contact
- 10. Coolant temperature sensor (NTC)
- 11. Longitudinal manifold
- 12. Coolant - engine oil heat exchanger



DESCRIPTION

The cooling system is of the sealed type with forced circulation by a centrifugal pump (1) located on the cylinder head and operated by the timing gear belt. A thermostatic valve (2), fitted on the rear of the engine keeps the engine temperature at an optimum level; it opens when the coolant reaches a temperature of 83 °C. The radiator (4) cools the engine fluid by the dynamic air and also by a fan (3) which is turned on:

- for the "95 Versions" (M2.10.3 injection-ignition system) by a thermal contact (5) on the radiator;
- for the "96 Versions" (M2.10.4 injection-ignition system) directly by the MOTRONIC control unit, depending on the signal received from the engine coolant temperature sensor (NTC).

(For further details about how the fan works, see ELECTRIC- ELECTRONIC DIAGNOSIS - Sect. 26 for versions with air conditioner and Sect. 28 for versions without air conditioner).

The expansion tank (7) tops up the circuit if the level falls and absorbs the changes in the volume of the coolant due to changes in temperature: it also vents air from the circuit.

The circuit is fitted with a coolant fluid temperature sender for the max. temperature gauge and thermal contact (9) for the warning light.

OPERATION OF THE CIRCUIT

After the fluid has cooled the engine, it leaves the cylinder head and reaches the thermostatic unit (92). From here, if the temperature is below 83 °C, it is drawn into the pump (1) through a longitudinal coolant return manifold located on the left-hand side of the cylinder head.

Conversely, if the temperature exceeds this value, the fluid is directed to the radiator (4) through the opening of the thermostat.

After being cooled in the radiator, the fluid returns, still through the longitudinal manifold, to the pump which directs it to the engine.

From the thermostatic cup the fluid is also sent to:

- heat the throttle body (8) from which it flows to the expansion tank (7) also venting air from the system;


- the climate control system heater (6) from which it returns to the longitudinal manifold;
- the heat exchanger (12) for cooling the engine oil before being ducted directly into the longitudinal manifold through which it returns to the pump.

The expansion tank supplies the engine cooling system via a special pipe connected with the longitudinal manifold.

CHECKING THE LEVEL AND CHANGING THE ENGINE COOLANT FLUID

Checking

- With the engine cold, visually check that the level of the coolant reaches the notch indicated by the arrow on the header tank, otherwise fill the system with the specified fluid.



Draining and replenishing

- Set the car on a lift.
- Slacken and remove the header tank plug.



WARNING:
Absolutely never remove the header tank plug when the engine is hot!


- Raise the car.



EXPANSION TANK


The expansion tank supplies the circuit and absorbs the variations in coolant volume due to the changes in engine temperature.

The tank also allows air, collected through the pipe coming from the throttle body, to bleed from the system by way of a calibrated valve in the pressurized cap. This valve also acts as a washing function enabling outside air to enter the system to compensate for the vacuum created as the system cools.



REMOVAL/REFITTING

- Drain the engine cooling system (see relative paragraph).
- 1. Disconnect the electrical connection of the engine coolant fluid minimum level warning light sensor.
- 2. Loosen the two clamps and disconnect the coolant delivery and return hoses from the expansion tank.
- 3. Unscrew the three screws and remove the expansion tank.



- 1. Slacken the radiator outlet hose and drain the coolant into a suitable recipient.



WARNING:
The anti-freeze mixture used as coolant can harm the paintwork; therefore avoid any contact with painted components.

- Reconnect the sleeve to the radiator and any disconnected pipes, checking that all the clamps are firmly tightened.
- Fill the header tank to the MAX mark with fluid of the specified type and quantity.
- Start the engine and bring it to normal operating temperature so that the thermostat opens to release the amount of residual air in the circuit.
- With the engine cold, top up to the MAX mark on the header tank.
- Retighten the pressurised cap on the header tank.




WARNING:
It is unwise to mix anti-freeze fluids of different types or brands!
Never use antirust additives: they might not be compatible with the anti-freeze in use!

**PRESSURIZED CAP SEALING TEST**

- Perform the test using a seal test tool.
- 1. Screw the fitting to the lower end of the test tool.
- 2. Install the expansion tank pressurized cap onto the fitting of the test tool.
- 3. Manually operate the piston of the test tool and pressurize the cap. Check that the valve opens at the specified pressure read from the manometer.



Pressurized cap setting
0.98 ± 0.1 bar

**HYDRAULIC SYSTEM PROOF TEST**


- Unscrew and remove the pressurized cap from the expansion tank.
- 1. Screw the hydraulic system proof testing tool and relevant fitting onto the expansion tank filler neck.
- 2. Manually pressurize the circuit and check that the pressure is maintained at the specified value. If the pressure is incorrect, check that there are no leaks in the radiator or sleeves.




Hydraulic system test pressure
1.08 bar

**CAUTION:**

For safety reasons never let the pressure rise above 1.38 bar when testing with the testing tool.

**WATER PUMP**


The water pump is of the centrifugal type with blades. It is fastened to the cylinder head and operated by the crankshaft via the timing gear belt. An O-Ring ensures tightness between the cylinder head and the pump. The water pump is kept running constantly to ensure that the coolant fluid circulates continuously.




1. Pulley
2. Impeller
3. Pump casing
4. O-Ring
5. Bearing

**REMOVAL/REFITTING (For engines with counter-rotating shafts)**


- Set the car on a lift.
 - Disconnect the battery (-) terminal.
 - Drain the engine cooling system (see relative paragraph).
1. Slacken the screws and move the header tank to one side without disconnecting the piping.




3. Slacken the fastening screws and remove the lower cover of the timing gear and counter-rotating shaft drive belts.



- Slacken the lower screws of the upper cover of the timing gear and counter-rotating shaft drive belts.
1. Lower the car, slacken the fastening screws and remove the upper cover.



1. Raise the car and working as illustrated on the belt tensioner, loosen the tension of the auxiliary components drive belt and remove it.
2. Slacken the four fastening screws and remove the auxiliary components drive pulley.




24 - 29 Nm
2.4 - 3.0 kgm


1. Slacken the fastening screw and remove the belt tensioner.
2. Slacken the fastening screw and remove the auxiliary components drive belt guide pulley.




1. Slacken the fastening screw and remove the socket for the oil vapour recovery pipe.




1. Slacken the fastening screws and remove the ignition coils cover.
2. Disconnect the electrical connections from the ignition coils.




1. Slacken the fastening screws and remove the ignition coils.
2. Slacken the fastening screws and remove the ignition coils support bracket.



1. Slacken the fastening screws and remove the cylinder head cover complete with gasket.




1. Working on the timing gear belt tensioner, loosen the tension on the belt, then take it off the timing gear drive pulleys.



21 + 26 Nm
2.1 + 2.7 kgm

1. Using tools no. 1.822.146.000 and no. 1.822.156.000 slacken the screw fastening the timing gear exhaust side drive pulley and remove it.

2. Slacken the four screws fastening the timing gear intake side drive pulley and remove it.




1.822.146.000
1.822.156.000

100 + 124 Nm
10.2 + 12.6 kgm



1. Slacken the fastening screws and remove the side protection on the exhaust side.
2. Remove the two fastening screws and remove the water pump complete with O-Ring.




- Refit reversing the sequence followed for removal.

For refitting the timing gear drive belt and timing and for assembly of the auxiliary components drive belt see GROUP 00.

REMOVAL/REFITTING (For engines without counter-rotating shafts)


- Set the car on a lift.
- Disconnect the battery (-) terminal.
- Drain the engine cooling system (see relative paragraph).
- Slacken the screws and move the header tank to one side without disconnecting the piping.
- 1. Raise the car and working as illustrated on the belt tensioner loosen the tension of the auxiliary components drive belt and remove it.
- 2. Slacken the four fastening screws and remove the auxiliary components drive pulley.



3. Slacken the fastening screw and remove the auxiliary components drive belt guide pulley.


- Slacken the lower screws of the cover of the timing gear drive belt.

1. Lower the car, slacken the fastening screws and remove the cover of the timing gear drive belt.







1. Slacken the fastening screw and remove the socket for the oil vapour recovery pipe.




1. Slacken the fastening screws and remove the ignition coils cover.
2. Disconnect the electrical connections from the ignition coils.



1. Slacken the fastening screws and remove the ignition coils.
2. Slacken the fastening screws and remove the ignition coils support bracket.



1. Slacken the fastening screws and remove the side protection on the exhaust side.
2. Remove the two fastening screws and remove the water pump complete with O-Ring.




- Refit reversing the sequence followed for removal.


For refitting the timing gear drive belt and timing and for assembly of the auxiliary components drive belt see GROUP 00.

REMOVING/REFITTING

- Remove the battery.
- 1. Drain the engine coolant fluid disconnecting the radiator delivery sleeve from the thermostatic cup.
- 2. Disconnect the electrical connection from the engine coolant temperature sensor (NTC).



1. Disconnect all the pipes connected to the thermostat unit.
2. Slacken the fastening screws and remove the thermostat unit.



THERMOSTAT UNIT

The thermostat unit is fitted on the rear end of the cylinder head.

Its purpose is to prevent the engine from exceeding the optimum temperature: until the coolant temperature reaches 83 °C, the thermostatic valve diverts the coolant fluid towards the pump; at higher temperatures, the opening of the thermostatic valve enables the passage of the fluid towards the radiator.


On the thermostat unit there is a sensor (NTC) for detecting the coolant temperature to be sent to the control unit.




RADIATOR


The radiator is sized to meet the heat dispersal requirements when the engine is running. It comprises a radiant mass and two side reservoirs fitted with inlet and outlet unions for the coolant fluid; the pipes and radiant mass fins are in aluminium, the reservoirs are in plastic.

REMOVING/REFITTING


- Set the car on a lift.
- Disconnect the battery (-) terminal.
- Drain the coolant fluid from the air conditioning system (see specific paragraph).
- 1. Raise the car and drain the engine coolant fluid disconnecting the radiator outlet sleeve.
- 2. Disconnect the electrical connection from the solenoid valve control thermal contact ( '95 versions).




- 1. Slacken the fastening screws and remove the air inlet pipe from the crossmember.




- 1. Remove the grille (see specific paragraph).




- 1. Remove the front bumper (see specific paragraph).




- 1. Raise the car and disconnect the two coolant inlet and outlet pipes from the conditioner condenser.
- 2. Slacken the two upper radiator fastening screws.



- Release the power steering pipes from the fastenings on the lower radiator crossmember.
- 1. Remove the two screws fastening the lower radiator crossmember to the body.




- 1. Remove the radiator, condenser, fan and lower radiator crossmember assembly withdrawing from below.






DIS-ASSEMBLY


1. Remove the lower crossmember from the radiator.



1. Slacken the three fastening screws, then remove the complete fan.



1. Slacken the four fastening screws, then remove the conditioner condenser.



COOLING FAN


The cooling fan makes it possible to increase the heat dispersion capacity of the radiator.

The fan is turned on by:


- for the "95 Versions" (M2.10.3 injection-ignition system) by a thermal contact on the radiator,
 - for the "96 Versions" (M2.10.4 injection-ignition system) directly by the MOTRONIC control unit, depending on the signal received from the engine coolant temperature sensor (NTC).
- (For further details about how the fan works, see ELECTRIC - ELECTRONIC DIAGNOSIS - Sect. 26 for versions with air conditioner and Sect. 28 for versions without air conditioner).

REMOVING/REFITTING


- Disconnect the battery (-) terminal.
- 1. Slacken the fastening screws and remove the air intake pipe from the crossmember.



1. Disconnect the electrical connections from the cooling fan.




1. Slacken the fastening screws and remove the cooling fan.





DIS-ASSEMBLY


1. Slacken the three fastening nuts and remove the heat shield.



1. Slacken the three fastening nuts, then separate the fan from the duct.
2. Remove the additional resistance slackening the two fastening screws.




1. Slacken the six fastening screws and separate the air duct from the radiator.



1. Remove the fan control thermal contact from the radiator (95 versions).




FAN CONTROL THERMAL CONTACT

(Specific for  '95 versions)

REMOVING/REFITTING

- Set the car on a lift.
- Disconnect the battery (-) terminal.
- 1. Raise the car and disconnect the electrical connection of the fan control thermal contact.
- 2. Slacken and remove the fan control thermal contact and recover the coolant fluid that comes out.



CHECKS AND INSPECTIONS

Check the setting of the thermal contact referring to the wiring diagram (see "Electric System Diagnosis").

Cut-in/cut-out temperatures of cooling fan	
1st speed	Cut-in (contacts closed) 92 ± 2°C Cut-out (contacts open) 87 ± 2°C
2nd speed	Cut-in (contacts closed) 97 ± 2°C Cut-out (contacts open) 92 ± 2°C


Change the thermal contact if the values are not correct



COOLANT TEMPERATURE GAUGE TRANSMITTER AND MAXIMUM TEMPERATURE WARNING LIGHT CONTACT



REMOVING/REFITTING



- Disconnect the battery (-) terminal.
- Disconnect the electrical connection from the engine coolant temperature sensor (NTC).
- 1. Disconnect the electrical connection from the engine coolant gauge transmitter and maximum temperature warning light contact, then remove it retrieving the coolant fluid that comes out.



CHECKS AND INSPECTIONS

Check the setting of the transmitter referring to the wiring diagram (see "Electric System Diagnosis").

Temperature (°C)	Resistance (Ω)	
		
60 (test fluid water)	525 + 605	470 + 600
90 (test fluid water)	195 + 245	160 + 230
120 (test fluid glycerine)	82 + 94	73 + 93

	Resistance (Ω)	
		
Contact closing temperature	122 ± 2°C	120 ± 2°C
Contact opening temperature	112 ± 3°C	108 ± 2°C



TECHNICAL CHARACTERISTICS AND SPECIFICATIONS


COOLING SYSTEM

Pressurised plug setting pressure	0.98 ± 0.1 bar
Hydraulic circuit control pressure	1.08 bar

THERMOSTAT

Start of opening temperature	83° ± 2°C
Valve stroke at 100° ± 2°C	7.5 mm

COOLING FAN THERMAL CONTACT



(Specific for  '95 versions)



Fan cut-in/cut-out temperature

1st speed	Cut-in (contacts closed) 92 ± 2°C Cut-out (contacts open) 87 ± 2°C
2nd speed	Cut-in (contacts closed) 97 ± 2°C Cut-out (contacts open) 92 ± 2°C

COOLANT TEMPERATURE GAUGE TRANSMITTER AND MAX. TEMPERATURE WARNING LIGHT CONTACT

Resistance (Ω)

Temperature (°C)	Resistance (Ω)	
		
60 (test fluid water)	525 + 605	470 + 600
90 (test fluid water)	195 + 245	160 + 230
120 (test fluid glycerine)	82 + 94	73 + 93

	Resistance (Ω)	
		
Contact closing temperature	122° ± 2°C	120° ± 2°C
Contact opening temperature	112° ± 3°C	108° ± 2°C

TIGHTENING TORQUES

Part	Nm	kgm
Auxiliary components drive belt pulley fastening screws	24 + 29	2.4 + 3.0
Timing gear belt fastening nut	21 + 26	2.1 - 2.7
Exhaust side timing gear belt drive pulley fastening screws	100 + 124	10.2 + 12.6



155 T.SPARK 16V

GROUP 12


CLUTCH


INDEX

CLUTCH.....	12-2
- DESCRIPTION.....	12-2
- CLUTCH UNIT.....	12-3
- Removing / Refitting	12-3
- CLUTCH CONTROL CYLINDER... ..	12-4
- Removing / Refitting	12-4
- TECHNICAL CHARACTERISTICS AND SPECIFICATIONS.....	12-5

- GENERAL SPECIFICATIONS	12-5
- Fluids and lubricants	12-5
- CONTROLS AND ADJUSTMENTS ..	12-5
- Clutch plate	12-5
- TIGHTENING TORQUES.....	12-6
- SPECIAL EQUIPMENT	12-6


● MECHANICAL UNITS


 GROUP 12 - CLUTCH


 GROUP 13 - GEARBOX - DIFFERENTIAL

 GROUP 17 - AXLE SHAFTS

 GROUP 21 - FRONT SUSPENSION

 GROUP 22 - FRONT AND REAR BRAKES

 GROUP 23 - STEERING

 GROUP 25 - REAR SUSPENSION

 GROUP 28 - WHEELS AND TYRES

For all the parts not mentioned herein, see the corresponding Group of the manual "155 - INSTRUCTIONS FOR REPAIR" - PA465500000000 - (pages with publication no. PA4655C1000000)



CLUTCH

DESCRIPTION

The clutch adopted is single-plate, dry with diaphragm pressure plate springs.

The clutch is disengaged by a hydraulic device comprising a reservoir (1) shared with the braking system, a pump (2) fastened to the pedal unit, a control cylinder (3) fastened to the gearbox cover and a thrust bearing (4).


The pump, operated by the pedal, transmits the fluid pressure increase to the control cylinder piston through the special pipe.

Through a rod, the piston acts on the lever and transmits the control to the fork which moves the thrust bearing overcoming the action of the diaphragm pressure plate springs.

In addition to reducing the effort required on the pedal, the adoption of the hydraulic clutch release device makes it possible to obtain:

- increased reliability in relation to the conventional, mechanical solution.
- improved smoothness due to the damping of the hydraulic system during disengagement which avoids jerking, particularly when the transmitted torque is high.
- greater operating precision as this device permits constant adjustment of the height of the clutch pedal.
- increased driving comfort as a result of the reduction of the level of vibration transmitted from the engine, due to the damping effect of the oil.

In order to meet the current laws concerning environmental pollution problems, ecological material (asbestos free) material has been used for the friction linings.




1. Brake-clutch system reservoir
2. Clutch pump
3. Clutch control cylinder
4. Thrust bearing
5. Clutch plate
6. Pressure plate
7. Clutch pedal



UTCH UNIT


REMOVING/REFITTING

- Remove the gearbox-differential unit (see GROUP 13).
- When changing only the clutch plate, mark its position between the pressure plate and flywheel to simplify re-assembly operations.
- 1. Install the flywheel stopper tool no. 1.820.228.000.
- 2. Install tool no. 1.820.126.000 in the clutch plate hub.
- 3. Slacken the screws fastening the pressure plate to the flywheel.




20 + 25 Nm
2.1 + 2.6 Kgm

1. Remove the pressure plate.
2. Remove the clutch plate.




1. Withdraw the thrust bearing from its sleeve in the gearbox cover.



When refitting the bearing it must not stick or turn noisily, otherwise it must be replaced.



- Only if necessary:
- 1. Remove the seeger locking and withdraw the clutch engagement control lever.
- 2. Prise and remove the anti-slip bush from the gearbox cover.
- 3. Working from inside the gearbox cover withdraw the clutch engagement sleeve control fork and pin.
- 4. Slacken the screws fastening the thrust bearing sleeve and remove it.




When refitting install a new anti-slip bush if the pin has too much play.
When refitting, grease the bushes and sleeve with the specified product. The sleeve complete with splash guard must be replaced each time oil leaks are found.


CLUTCH CONTROL CYLINDER

REMOVING / REFITTING

- Remove the battery after disconnecting the terminals.
- 1. Remove the corrugated air intake pipe between the cleaner and the throttle, after disconnecting it from the air-flow meter.
- 2. Remove the battery tray after separating the two injection relay support brackets.



- Empty the brake-clutch fluid reservoir using a suitable syringe.
- 1. Slacken the two screws fastening the clutch control cylinder
- 2. Disconnect the pump hose fitting from the clutch control cylinder.
- 3. Remove the clutch control cylinder.



TECHNICAL CHARACTERISTICS AND SPECIFICATIONS


GENERAL SPECIFICATIONS

FLUIDS AND LUBRICANTS

APPLICATION	TYPE	NAME
Thrust bearing housing and clutch control lever shaft Clutch control cylinder prod	GREASE	TUTELA MR3
Lubrication of pump inner components and hydraulic system filling	FLUID Class: DOT 4 SAE J 1703 F	ALFA ROMEO BRAKE FLUID SUPER DOT 4

CHECKS AND ADJUSTMENTS

CLUTCH PLATE



Clutch plate thickness	New	7.1 + 7.7 mm
	At wear limit	6.3 mm
Clutch plate diameter		228.5 mm

PA4978C 116V001

1-1995





TIGHTENING TORQUES

Part	Nm	kgm
Screws fastening pressure plate to flywheel	20 + 25	2.1 + 2.6
Screws fastening clutch control cylinder to gearbox cover	13 + 16	1.3 + 1.6
Nuts fastening clutch pump to pedal unit	13 + 21	1.3 + 2.1
Clutch circuit pipe fitting on pump	17 + 19	1.7 + 1.9
Clutch circuit pipe fitting on control cylinder	17 + 19	1.7 + 1.9
Thrust plate bearing sleeve fastening screws	7 + 9	0.7 + 0.9

SPECIAL TOOLING

TOOL NUMBER	DESCRIPTION
1.820.126.000	Tool for centering clutch plate
1.820.228.000	Flywheel stopper tool

GROUP 13

GEARBOX - DIFFERENTIAL

INDEX

GEARBOX

- DESCRIPTION..... (*)
- REMOVING AND REFITTING..... 13-2
- DIS-ASSEMBLY..... (*)
- CHECKS & INSPECTIONS..... (*)
- RE-ASSEMBLY..... (*)

DIFFERENZIALE


- DESCRIZIONE..... (*)
- SMONTAGGIO..... (*)
- VERIFICHE E CONTROLLI..... (*)

TECHNICAL CHARACTERISTICS AND SPECIFICATIONS..... 13-7


- TECHNICAL CHARACTERISTICS . 13-7
- Gearbox ratios 13-7
- GENERAL SPECIFICATIONS 13-7
- Fluids and lubricants 13-7
- Sealants and adhesives..... 13-7
- CONTROLS AND ADJUSTMENTS . 13-7
- Differential 13-7
- TIGHTENING TORQUES 13-8
- SPECIAL TOOLING 13-9

For all the parts not mentioned herein, see the corresponding Group of the manual "155 - INSTRUCTIONS FOR REPAIR" - PA465500000000 - (pages with publication no. PA4655C1000000)


(*) See publication PA494200000000. "Instructions for Repair - OVERHAULING OF MECHANICAL UNITS" referring to overhauling of Gearbox C.510.5.XX.YY.



- Remove the front grille (Group 75).
- 1. Disconnect the horn fastening bracket.
- 2. Position engine support no. 1.820.226.000, with supports 1. 820.239.000 and crossmember 1.820.581.000.
- 3. Place a support square on the front of the crankcase.
- 4. Place a support square on the rear of the crankcase, between two injectors.
- Place a chain between the two squares and the support, hooking the engine to the support.




- 1. Remove the heater pipe fastening clamps from the throttle body.
- 2. After removing the cover, disconnect the lambda probe connection disconnecting it from its stay clamp.



- 1. Slacken the two upper screws fastening the gearbox to the engine.


- 1. Disconnect the reversing switch and speedometer sensor connections from the gearbox.
- 2. Slacken the two screws and remove the clutch cylinder from the gearbox, moving it upwards: the cylinder remains restrained by the pipe leading from the clutch pump.




GEARBOX UNIT

REMOVAL AND REFITTING


- Set the car on a lift.
- Remove the front wheels with gravel guards.
- Remove the battery after disconnecting the terminals.
- 1. Remove the corrugated intake pipe between the cleaner and throttle, after disconnecting the air-flow meter.
- 2. Remove the battery tray after separating the two injection relay support brackets.




1. Remove the engine rear support.
2. Position a suitable hydraulic jack under the cross-member
3. Slacken the six rear screws fastening the cross-member to the body.




1. Slacken the six fastening bolts and disconnect the left C.V. joint of the differential axle shaft.
2. Disconnect the three gearshift control rods.




1. On both sides, slacken the two screws fastening the front crossmember to the wheel hub.




1. Slacken the two screws fastening the power steering to the front crossmember.
2. Slacken the four front nuts and loosen the other screws fastening the gearshift controls support, which needs to be lowered slightly to enable release from the front crossmember.



1. Raise the car.
1. Slacken the plug and drain the gearbox-differential oil into a suitable recipient.
2. Disconnect the gearbox earth cable.



1. Remove the reinforcement under the exhaust pipe.
2. Disconnect the exhaust pipe fastening bracket.
3. Remove the exhaust pipe, front section.



NOTE: carefully retrieve the lambda probe wiring to avoid tearing or damaging it.



TECHNICAL CHARACTERISTICS AND SPECIFICATIONS

TECHNICAL CHARACTERISTICS

Version	Axle ratio	Gear engaged	Gearbox ratio	Total ratio
167A2G	17/57 1 : 3.353	1 ^A	1 : 3.545	1 : 11.886
		2 ^A	1 : 2.238	1 : 7.504
		3 ^A	1 : 1.520	1 : 5.096
		4 ^A	1 : 1.156	1 : 3.876
		5 ^A	1 : 0.946 1 : 0.970 (*) 1 : 3.172 1 : 3.254 (*)	1 : 3.909
167A4N 167A6A	17/57 1 : 3.353	1 ^A	1 : 3.909	1 : 13.107
		2 ^A	1 : 2.238	1 : 7.504
		3 ^A	1 : 1.520	1 : 5.096
		4 ^A	1 : 1.156	1 : 3.876
		5 ^A	1 : 0.971	1 : 3.256
167A4P	20/63 1 : 3.150	1 ^A	1 : 3.909	1 : 12.313
		2 ^A	1 : 2.238	1 : 7.050
		3 ^A	1 : 1.520	1 : 4.789
		4 ^A	1 : 1.156	1 : 3.641
		5 ^A	1 : 0.971	1 : 3.059
167A6	16/57 1 : 3.562	1 ^A	1 : 3.909	1 : 13.924
		2 ^A	1 : 2.238	1 : 7.972
		3 ^A	1 : 1.520	1 : 5.414
		4 ^A	1 : 1.156	1 : 4.118
		5 ^A	1 : 0.970	1 : 3.455
		RM	1 : 3.909	1 : 13.924

(*) : '96 Versions.

GENERAL SPECIFICATIONS


APPLICATION	TYPE	NAME
Gearbox-differential unit oil	OIL	TUTELA ZC 80/S
Gear engagement control rod bushes and gearshift lever ball joint	GREASE	TUTELA ZETA 2 ISECO MOLIKOTE LONGTERM No. 2

CHECKS AND ADJUSTMENTS


DIFFERENZIAL	
Bearing preload (relieved)	0.12 mm *
Sun - planetary gears backlash	≤ 0.10 mm

* NOTE: The bearing preload adjustment is carried out using spare rings with a thickness of from 1.70 mm to 2.60 mm in steps of 0.05 mm.


- Slacken the two lower gearbox cover fastening screws and in their place insert bracket no. 1.820.623.001 with support no. 1.820.208.000.
- Add a suitably-sized bolt in the hole on the right.
- Slacken the two screws fastening the lower cover.
- Slacken the bolt fastening the gearbox to the engine.




- Slacken the nut fastening the gearbox to the engine.
- Lower the gearbox disconnecting it from the engine.



- Slacken the three screws fastening the starter motor to the gearbox.



- Slacken the four screws fastening the rear gearbox support to the gearbox.
- Slacken the bolt fastening the support to the body and remove it.






TIGHTENING TORQUES

Part	Nm	kgm
Screws and nuts fastening gearbox-engine	75 + 92	7.6 + 9.4
Screw fastening front engine support to body	75 + 92	7.6 + 9.4
Screws fastening lower gearbox cover	42 + 51	4.3 + 5.3
Screws fastening gearbox to front engine support	42 + 51	4.3 + 5.3
Screw fastening reversing shaft	29 + 36	2.9 + 3.6
Ring nut for main and transmission shaft for fastening 5th gear	100 + 124	10 + 13
Screw fastening gearshift control forks	15 + 19	1.6 + 1.9
Screw fastening lever on gearshift control shaft	20 + 25	2.0 + 2.5
Screw fastening support reverse control lever	9 + 11	0.9 + 1.1
Screw fastening bush for gearshift control shaft	9 + 11	0.9 + 1.1
Screw fastening differential crown wheel	75 + 92	7.6 + 9.4
Screw fastening differential retainer flange to gearbox	21 + 26	2.2 + 2.7
Screw fastening tachometer support	8 + 13	0.8 + 1.3
Magnetic threaded taper plug for filling gearbox oil	30 + 48	3.1 + 4.9
Threaded taper plug for filling gearbox oil	30 + 48	3.1 + 4.9
Screw fastening differential right-hand shaft support	7 + 11	0.7 + 1.1
Threaded taper plug for 1st and 2nd gear rod housing on gearbox	13 + 21	1.3 + 2.1
Front screws fastening gearbox controls support	16 + 25	1.6 + 2.5
Screw fastening differential side joint to flange	40 + 52	4.1 + 5.3
Screw for reversing light switch	20 + 32	2.0 + 3.2
Screw fastening starter motor to gearbox	20 + 25	2.0 + 2.5
Screw fastening earth cable to gearbox	10 + 13	1.0 + 1.3
Screws fastening rear engine support to b.dy	75 + 92	7.6 + 9.4
Screws fastening rear engine support to crossmember	32 + 40	3.3 + 4.1
Screws fastening supportto gearshift control lever to body	10 + 16	1.0 + 1.6
Nut per pin fastening intermediate gear	10 + 16	1.0 + 1.6
Nut fastening engagement tie-rod to intermediate lever	10 + 16	1.0 + 1.6
Nut for screw fastening selection transmission on gearbox	10 + 16	1.0 + 1.6

SPECIAL TOOLING

TOOL NUMBER	DESCRIPTION
1.820.017.000	Half rings for: - removing main shaft 4th speed driven gear - main shaft dis-assembly
1.820.019.000	Plate for removing transmission shaft 2nd and 3rd speed driven gears
1.820.022.000	Half plates for fitting main shaft front bearing inner race
1.820.024.000	Half ring support plate and for removing transmission shaft 1st speed driven gear
1.820.085.000	Tool for measuring thickness of differential shim rings
1.820.146.000	Plate for supporting gearbox on rotary stand
1.820.208.000	Support for gearbox removing/refitting
1.820.226.000	Engine support
1.820.229.000	Flange for removing differential flange
1.820.239.000	Support for engine and gearbox
1.820.581.000	Engine support crossrail
1.820.623.001	Bracket for removing/refitting gearbox
1.821.003.000	Drift for removing differential support outer bearing race
1.821.028.000	Installing tool for differential support outer bearing race
1.821.034.000	Puller tool for differential bearings
1.821.047.000	Installing tool for safety pawls for 1st - 3rd - 5th speed control rods
1.821.049.000	Half plates for installing main shaft rear bearing
1.821.050.000	Installing tool for 4th speed driven gear
1.821.062.000	Installing tool for differential bearings
1.821.092.000	Installing tool for 1st speed driven gear

TOOL NUMBER-	DESCRIPTION
1.821.117.000	Puller tool for removing transmission and main shaft front bearing inner race
1.821.161.000	Mallet for extracting differential flange
1.821.170.000	Installing tool for differential carrier gearbox side oil seal
1.821.171.000	Grip for installing tools
1.821.225.000	Installing tool for differential carrier engine side oil seal
	Installing tool for: main shaft front bearing inner race
	Installing tool for: main and transmission shaft rear bearing
	Installing tool for: synchronizer hub and transmission shaft 2nd and 3rd speed gears

GROUP 17

AXLE SHAFTS



CONTENTS

AXLE SHAFTS.....	17-2	TECHNICAL CHARACTERISTICS AND SPECIFICATIONS	17-3
- DESCRIPTION.....	17-2	- GENERAL SPECIFICATIONS	17-3
- INTERMEDIATE SHAFT	17-2/1	- Fluids and lubricants.....	17-3
- Removal/Refitting	17-2/1	- TIGHTENING TORQUES.....	17-3
- Disassembly	17-2/2	- SPECIAL TOOLS	17-3

For all parts not mentioned herein, refer to the corresponding Group of manual "155 - INSTRUCTIONS FOR REPAIR" - PA465500000000 - (Pages with publication no. PA4655C1000000)


INTERMEDIATE SHAFT REMOVING/REFITTING

- Set the car on a lift.
- Disconnect the battery (-) terminal.
- 1. Disconnect the electrical connection of the lambda sensor.



1. Slacken the two bolts fastening the wheel upright to the shock absorber stem, then remove only the upper one to free the axle shaft from the intermediate shaft.

1. Slacken the fastening screws and remove the reinforcement bracket.
2. Remove the front section of the exhaust pipe complete with lambda sensor after slackening the associated fastenings.



The axle shafts (6), made from high-strength steel, have grooved ends to enable coupling with the constant velocity joints (1) and (5). On the ends there are the seats for the circlips (2) which retain the actual joints. Constant velocity joints are formed of an inner core (1d) known as "drive", keyed onto the input shaft, and an outer shell (1a), known as "driven", which is the output piece of the joint.

On the outer surface of the inner core, there are six round grooves which contain six balls (1b), held in place by a cage (1c).

These balls are the actual motion transmission element and they are contemporaneously housed in six grooves machined on the inner surface of the shell.


AXLE SHAFTS

DESCRIPTION

The axle shafts, together with the constant velocity joints and the intermediate shaft, form the set of devices which transmit motion from the gearbox to the driving wheels.

The assembly of these devices, commonly known, along with the gearbox, as "transmission", comprises the following:


- right and left axle shafts;
- gearbox and wheel side constant velocity joints; intermediate shaft



1. Wheel side constant velocity joint
2. Circlip
3. Retainer clamp
4. Bolt
5. Retainer clamp
6. Axle shaft
7. Constant velocity joint connection flange




- Slacken the fastenings and remove the exhaust pipe support bracket.
 - Slacken the fastening screws of the intermediate flange to the support, then withdraw the intermediate flange from the differential.
- Retrieve the dust cover ring.



DIS-ASSEMBLY

- Position the intermediate shaft in a vice fitted with protective jaws.
- Using tool no. 1.822.157.000, slacken the lock nut.



- Withdraw the flange from the intermediate shaft.
- Retrieve the bearing retainer plate.

PA4978C116V002

12 - 1995



TECHNICAL CHARACTERISTICS AND SPECIFICATIONS

GENERAL SPECIFICATIONS

FLUIDS AND LUBRICANTS

APPLICATION	TYPE	NAME
Axle shaft constant velocity joints	GREASE	OPTIMOL PU 035 BERUTOX GKN HTB

TIGHTENING TORQUES

Part	Nm	kgm
Screws fastening differential side axle shaft joint to flange	40 + 52	4.1 + 5.3
Screws fastening intermediate axle shaft flange	8 + 10	0.8 + 1.0
Nut fastening axle shafts to wheel hub	67 + 74 + 62° ± 2°	6.8 + 7.5 + 62° ± 2°
Bolt fastening wheel upright - shock absorber	66 + 74	6.7 + 7.5

SPECIAL TOOLS

TOOL NUMBER	DESCRIPTION
1.820.082.000	Pliers for installing fastening clamps for joint protection boot
1.820.084.000	Pliers for installing fastening clamps for joint protection boot
1.821.161.000	Mallet (use with No. 1.821.165.000)
1.821.165.000	Removing tool for constant velocity joint
1.822.157.000	Wrench for intermediate shaft flange lock nut

PA4978C116V002

12 - 1995

- Complete re-assembly of the intermediate shaft reversing the sequence described for dis-assembly.

GROUP 21

FRONT SUSPENSION

INDEX

FRONT SUSPENSION CHARACTERISTICS AND SPECIFICATIONS	
- Technical characteristics	21-2
- Coil springs	21-2
- Shock absorbers	21-2
- Antiroll bar	21-2
- GENERAL SPECIFICATIONS	21-2
- Fluids and lubricants	21-2
<hr/>	
- CHECKS AND ADJUSTMENTS	21-3
- Front wheel toe-in	21-3
- Wheel camber angles	21-3
- Front wheel caster	21-4
- Front geometries	21-5
- geometries	21-5
- TIGHTENING TORQUES	21-6
- SPECIAL TOOLING	21-7

For all the parts not mentioned herein, see the corresponding Group of the manual "155 - INSTRUCTIONS FOR REPAIR" - PA465500000000 - (pages with publication no. PA4655C1000000)



TECHNICAL CHARACTERISTICS AND SPECIFICATIONS

TECHNICAL CHARACTERISTICS

COIL SPRINGS

SPECIFICATIONS	Version with heater	Version with air conditioner
Inside diameter (mm)	150	150
Outside diameter (mm)	177.4	177.6
Wire diameter (mm)	13.7	13.8
Number of Coils	5.58	5.58
Direction	Right-handed	
Free length (mm)	384	386.5

SHOCK ABSORBERS

Type: telescopic hydraulic pressurized lamellar	BOGE
Stroke (mm)	167
Stem diameter (mm)	22

ANTIROLL BAR

Bar diameter (mm)	22
-------------------	----

GENERAL SPECIFICATIONS

FLUIDS AND LUBRICANTS

APPLICATION	TYPE	NAME
Wishbone flexible supports	GREASE	GREASE MOLYKOTE 7544 PG 54 TUTELA MP3
Steering track rods	GREASE	MOLYGUARD SYL113



CHECKS AND ADJUSTMENTS

FRONT WHEEL TOE-IN

A - B	1598	1747	1970
			-1 ± 1 mm

N.B. Values measured with car unladen in running order (with specified fluids).

WHEEL CAMBER ANGLES

	1598	1747	1970
			$\gamma = -20' \pm 20'$
			(unadjustable characteristic)

N.B. Values measured with car unladen in running order (with specified fluids).



FRONT WHEEL CASTER ANGLES

	$\beta = 3^{\circ} 10' \pm 30'$ (unadjustable characteristic)		

N.B. Values measured with car unladen in running order (with specified fluids)

FRONT GEOMETRY

	- 20 ± 5 mm	- 20 ± 5 mm - 35 ± 5 mm (1)	- 20 ± 5 mm - 35 ± 5 mm (1)

(1): Sports version

N.B. Values measured with car unladen in running order (with specified fluids).



REAR GEOMETRY

	- 10 ± 5 mm	- 10 ± 5 mm - 25 ± 5 mm (1)	- 10 ± 5 mm - 25 ± 5 mm (1)

(1): Sports version

N.B. Values measured with car unladen in running order (with specified fluids).

TIGHTENING TORQUES

Part	Nm	kgm
Bolts fastening shock absorber to wheel upright	66 + 74	6.7 + 7.5
Centre nut retaining helical spring to shock absorber	95 + 105	9.7 + 10.7
Screws fastening shock absorber to body	34 + 42	3.5 + 4.3
Nut fastening track rod to wheel upright	29 + 37	3.0 + 3.8
Bolt fastening wishbone to wheel upright	67 + 74	6.8 + 7.5
Nut fastening connecting rod to stabiliser bar	43 + 53	4.4 + 5.4
Nut fastening stabiliser bar connecting rod to wishbone	26 + 33	2.7 + 3.3
Screws fastening wishbone U-bolts to crossmember	59 + 72	6.0 + 7.3
Front screws fastening crossmember to body	92 + 113	9.4 + 11.5
Screws fastening upper crossmember connections	92 + 113	9.4 + 11.5
Screws fastening steering box to crossmember	43 + 47	4.4 + 4.8
Nuts fastening U-bolts connecting stabiliser bar to crossmember	29 + 35	3.0 + 3.6
Nut fastening axle shaft to wheel hub	67 + 74 + 62° ± 2°	6.8 + 7.5 + 6.2° ± 2°

SPECIAL TOOLS

TOOL NUMBER	DESCRIPTION
1.820.047.002	Plate per removing front wheel hub bearing inner ring (To be used with 1.820.223.000 and 1.821.051.000)
1.820.089.000	Tool for compressing front suspension spring
1.820.223.000	Half rings for removing front wheel hub bearing inner ring (To be used with 1.820.047.002 and 1.821.051.000)
1.820.238.000	Plate for compressing front suspension springs (To be used with 1.820.089.000)
1.820.247.000	Tool for retaining front shock absorber stem
1.821.045.000	Tool for removing installing bearing outer ring from front wheel upright (To be used with 1.821.149.000)
1.821.051.000	Tool for: - removing wheel hub from wheel upright - removing front wheel hub bearing inner ring (To be used with 1.820.047.002 and 1.820.223.000)
1.821.099.000	Tool for removing bearing outer ring from wheel upright
1.821.149.000	Supporto per removing bearing outer ring from front wheel upright (To be used with 1.821.045.000)
1.821.209.000	Tool for installing bearing and wheel hub in front wheel upright
1.822.117.000	Wrenche for slackening and tightening front shock absorber fastening nut



GROUP 22

FRONT AND REAR BRAKES

INDEX

FRONT AND REAR BRAKES

TECHNICAL CHARACTERISTICS AND SPECIFICATIONS 22-2

- TECHNICAL CHARACTERISTICS 22-2
- Brake pump 22-2
- Servobrake 22-2
- Front brake caliper 22-2
- Rear brake caliper 22-2
- GENERAL SPECIFICATIONS 22-3
- Fluids and lubricants 22-3
- Controls and adjustments 22-3

- Dimensions for brake disk grinding 22-3
- Brake pads 22-3
- Adjusting gap between inductive sensors - phonic wheels 22-4
- TIGHTENING TORQUES 22-5
- SPECIAL TOOLING 22-5
- BOSCH 5.3 ABS 22-7
- Description 22-7
- Components 22-9
- Description of how the wheel anti-lock system works 22-11
- Repair operations on the unit 22-16



TECHNICAL CHARACTERISTICS AND SPECIFICATIONS

TECHNICAL CHARACTERISTICS

BRAKE PUMP

Model	Type	Diameter	Stroke
2.0 T.S. 16V	ISOVAC	15/16" (23.8 mm)	9/16" (14+14 mm)
2.0 T.S. 16V right hand drive		7/8" (22.23 mm)	5/8" (16+16 mm)

SERVOBRAKE

Model	Type	Diameter of operating cylinder
2.0 T.S.	ISOVAC	7" +8" (17.78 + 20.32 cm)
2.0 T.S. 16V right-hand drive		9" (22.86 cm)

FRONT BRAKE CALIPERS

Model	Type	Diameter of piston (mm)	Area of brake pads (cm ²)	Brake pad nominal thickness (mm)
2.0 T.S. 16V	LUCAS	54	50	18.3 ±0.2

REAR BRAKE CALIPERS

Model	Type	Diameter of piston (mm)	Area of brake pads (cm ²)	Brake pad nominal thickness (mm)
2.0 T.S. 16V	LUCAS	34	21	14 ⁰ ±0.4



GENERAL SPECIFICATIONS


FLUIDS AND LUBRICANTS

APPLICATION	TYPE	NAME
Joints and pedal bushes	GREASE	TUTELA ZETA 2
Filling brake/clutch hydraulic system	FLUID Class: DOT 4 SAE J 1703 F	ALFA ROMEO BRAKE FLUID SUPER DOT 4
Front/rear wheel inductive sensor seat for wheel antilock device	GREASE	TUTELA ZETA 2

CHECKS AND ADJUSTMENTS

BRAKE DISK	FRONT	REAR
Diameter (mm)	284	240
Use limit thickness (mm)	20.2	9.2
Min. thickness after grinding (mm)	21.2	10.2
Nominal thickness (mm)	22.2	11.2

DIMENSIONS FOR GRINDING BRAKE DISKS



- 1. Radial
- 2. Circumference




BRAKE PADS

BRAKE PADS	FRONT	REAR
Use limit thickness	1.5 mm(1)	1.5 mm


(1) Signalled by brake pad wear sensor

ADJUSTMENT OF GAP BETWEEN INDUCTIVE SENSORS AND PHONIC WHEELS

Front wheels



Rear wheels



TIGHTENING TORQUES

Description	N.m	kg.m
Fitting for stiff pipe on brake pump	15 + 19	1.5 + 1.9
Nut fastening brake pump	13 + 21	1.3 + 2.1
Nut fastening servobrake to pedal unit	10 + 15	1.0 + 1.5
Nut fastening accelerator pedal to pedal unit	3 + 5	0.3 + 0.5
Front and rear wheel fastening studs	83 + 103	8.5 + 10.5
Screw fastening front brake calipers	22 + 32	2.2 + 3.3
Screw fastening front brake caliper support bracket	85 + 105	8.6 + 10.7
Screw with centering pin fastening front and rear brake disks	5 + 13	0.5 + 1.3
Screw fastening front and rear brake disks	5 + 13	0.5 + 1.3
Bleed screw on brake calipers	4 + 6	0.4 + 0.6
Fitting connecting hoses on brake calipers	15 + 19	1.5 + 1.9
Screw fastening rear brake calipers	45 + 55	4.6 + 5.6
Screw fastening rear brake caliper support bracket	20 + 25	2.0 + 2.5
Connections between stiff pipes and hoses	15 + 19	1.5 + 1.9
Screw fastening braking load proportioning valve to rear crossmember	4 + 5	0.4 + 0.5
Screw for square lever for proportioning valve adjustment	20 + 25	2.0 + 2.5
Fitting for connecting stiff pipes on braking load proportioning valve and 4-way distributor	9 + 11	0.9 + 1.1
Screw fastening parking brake to body	18 + 29	1.8 + 3.0
Screw fastening brake-clutch fluid reservoir to body	3 + 4	0.3 + 0.4
Nut fastening hydraulic control unit to bracket	3 + 4	0.3 + 0.4
Screw fastening control unit support bracket to body	20 + 25	2.0 + 2.5
Screw fastening front and rear wheel inductive sensor	5 + 6	0.5 + 0.6

SPECIAL TOOLING

TOOL NUMBER	DESCRIPTION
1.820.248.000	Tool for moving back front brake piston
1.822.108.000	Tool for moving back rear brake piston



BOSCH 5.3 ABS

(from chassis no. replaces the previous version "2E")

DESCRIPTION


The Bosch 5.3 A.B.S. further optimises compactness (ease of assembly), lightness and reliability. The use of new microhybrid electronic components, optimisation of the flows as a result of the study of the new, more compact shapes of the valve bodies and the reduction of the number of hydraulic components since they are pressed directly onto the valve seat of the nozzles which are previously assembled separately have made it possible to improve the characteristics of solenoid valves.

1...2 main components of the system are:
 - new electronic control unit, more powerful and versatile than the previous ones;

- electrohydraulic control unit (4) which modulates the braking pressure at the brake calipers through eight solenoid valves, two for each wheel;
- four sensors (5) and (9), one for each wheel, which detect the angular rotation speed of the wheels.

The system is completed by:

- the hydraulic system piping;
 - a specific wiring loom;
 - a switch on the brake pedal (8) for detecting the the braking condition;
 - a warning light (7), on the check panel.
- In addition, under particular diagnosis conditions, the warning light (7), supplies information about the faults memorised by the control unit through a series of coded flashes (see Electric System Diagnosis*).




Layout of Bosch 5.3 A.B.S. System

- | | |
|--|--|
| <ol style="list-style-type: none"> 1. Brake fluid reservoir 2. Brake pump 3. Vacuum servobrake 4. Electrohydraulic control unit with electronic control unit incorporated 5. Front wheel rpm sensor | <ol style="list-style-type: none"> 6. Front brakes 7. Warning light 8. Stop lights control switch 9. Rear wheel rpm sensor 10. Rear brakes 11. Proportioning valve |
|--|--|



HYDRAULIC LAYOUT OF BOSCH 5.3 A.B.S. SYSTEM



Braking system with double crossed circuit

- | | |
|---|--|
| <ol style="list-style-type: none"> 1. Brake control pump 2. Servobrake 3. High pressure accumulator (damping chamber) 4. High pressure accumulator (damping chamber) 5. Recovery pump drive motor 6. Recovery pump 7. Recovery pump 8. Low pressure accumulator (reservoir) 9. Low pressure accumulator (reservoir) 10. Fast pressure reduction valve 11. Right rear charge solenoid valve 12. Right rear discharge solenoid valve 13. Left front charge solenoid valve 14. Left front discharge solenoid valve 15. Right front charge solenoid valve 16. Right front discharge solenoid valve 17. Left rear charge solenoid valve | <ol style="list-style-type: none"> 18. Left rear discharge solenoid valve 19. Right rear drum brake 20. Left front disk brake 21. Right front disk brake 22. Left rear drum brake |
|---|--|

- | | |
|------|---------------------------------------|
| MC1. | Supply union for brake pump 1st stage |
| MC2. | Supply union for brake pump 2nd stage |
| RR. | Delivery union to right rear cylinder |
| FL. | Delivery union to left front caliper |
| FR. | Delivery union to right front caliper |
| RL. | Delivery union to left rear cylinder |

COMPONENTS

Electrohydraulic control unit

The electrohydraulic control unit comprises two sections assigned to one another: an electronic control unit and an electrohydraulic control unit.

On the basis of the signals received from the sensors and with the help of characteristic programmes mapped in its memories, the electronic control unit commands the electrohydraulic control unit.


The electrohydraulic control unit is connected to the brake pump and to the A.B.S. system components through the pipes of the braking system.

The main change with respect to the previous versions is the replacement of the three-way valves with two two-way solenoid valves for each wheel.

Electronic control unit

The electronic control unit is formed of hybrid circuits with resistances, diodes, transistors and integrated logic circuits. The heart of the system are two CMOS microprocessors with 12K ROM which autonomously carry out the same programme and monitor one another mutually. Both receive the same input signals which are processed individually and only when the results obtained are identical, the control unit sends the operating command to the electrohydraulic control unit.

Conversely, if for example there is a fault in the wheel anti-lock system, the device cuts itself out and braking takes place conventionally: simultaneously, the fault warning light on the check panel comes on.



Operating logic

The signals (alternate or analogue) sent by the rpm sensors to the electronic control unit are transformed by the input amplifier into square wave signals.

The frequency of these signals gives the control unit the corresponding values of speed, acceleration or deceleration of the single wheels.

From the combination of the single wheel peripheral speeds, a reference speed is processed which is continuously updated and indicates the speed of the car at all times.

When the driver presses the brake pedal the wheels can each decelerate to a different extent: comparison of the peripheral speed of each wheel with the reference speed keeps the skidding of each wheel constantly under control.

If the braking force causes a wheel to skid with respect to the others, the electronic control unit sends the command to the solenoid valves of the electrohydraulic control unit to reduce the braking force on the wheel that has lost grip. This way the wheel concerned regains speed.

The memory of the electronic control unit also contains threshold acceleration and deceleration values that none of the wheels may ever exceed.

Therefore, through systematic, very rapid comparison of the wheel skidding, deceleration and acceleration values, rolling of the tyre during braking is kept under control.

As soon as the foreseen combined acceleration/deceleration and skid values are exceeded, the electronic control unit intervenes with commands to the solenoid valves of the electrohydraulic control unit, in the three adjustment phases to lower, maintain or return the pressure generated by the driver on the brake pedal to the brake callipers, bringing the braking condition to the optimum values set by the system.


These phases determine an intermittent but extremely fast adjustment cycle which is repeated until the car stops. The electronic control unit commands the different phases supplying the solenoid valves pulses with different current intensities. It also makes sure that both rear wheels are given the same braking force applicable to the one with lower grip (to ensure stability). If a fault is detected, the wheel anti-lock device cuts out and alerts the driver by turning on the warning light on the check panel, while however ensuring operation of the conventional braking system.

The electronic control unit is informed that the driver is braking by the signal from the switch on the brake pedal. Besides controlling braking, this information is also helpful under certain particular conditions, such as for example if a sharp acceleration that makes the wheels skid is followed by heavy braking, or in the case of irregular road surfaces (humps, steps) that can involve changes in speed of the wheel due to causes not linked with the braking in progress.

In these conditions the microprocessors process a strategy connected with the changes of speed of the wheels of these particular moments, bringing braking back to the correct parameters. Since these are particular conditions of braking control, the lack of connection of the switch on the brake pedal to the control unit does not compromise the efficiency of the system. For this reason it is not signalled by the warning light, nor is the A.B.S. system disabled.

Further details about the operating principle of the ABS are given below.

Electrohydraulic control unit



1. Electrohydraulic control unit
2. Electric recovery pump
3. Electronic control unit
4. Control unit connector

The electrohydraulic control unit is connected to the brake pump and to the brake calliper cylinders through the brake system lines and together with the electronic control unit it forms the electrohydraulic control unit. Its task is to change the pressure of the brake fluid in the brake calliper cylinders according to the command signals leading from the electronic control unit.

It comprises eight two-way solenoid valves (two for each hydraulic circuit) and an electric recovery pump (2) with double circuit. The eight solenoid valves and the electric recovery pump are driven by the electronic control unit depending on the signals of the four rpm sensors. The pump makes it possible to recover the brake fluid during the pressure reduction phase making it available again upstream of the solenoid valves for the next pressure increase phase.

The accumulators absorb the brake fluid during pressure reduction.

The unit is connected to the braking system through unions identified by the codes stamped on them as illustrated.


Pipe outlets

MC1	Supply union from brake pump - circuit 1
MC2	Supply union from brake pump - circuit 2
LF	Delivery union to left front brake calliper
LR	Delivery union to left rear brake calliper
RF	Delivery union to right front brake calliper
RR	Delivery union to right rear brake calliper

Inductive sensors

These are quite the same as those used for the previous versions.

Pressure maintenance phase




1. Electronic control unit
2. Low pressure accumulator (reservoir)
3. Recovery pump drive motor
4. Recovery pump
5. High pressure accumulator (damping chamber)
6. Brake control pump
7. Servobrake
8. Fast pressure reduction valve
9. Charge solenoid valve
10. Discharge solenoid valve
11. Brake caliper
12. Rpm sensor
13. Phonic wheel
14. Restrictor

During this phase, the electronic control unit (1) connects the charge solenoid valve (9) to earth, so it closes, while the discharge solenoid valve (10) that is not connected to earth, is already closed. The hydraulic connection between the brake pump (6) and the brake caliper (11) is cut off (standby position). The pressure in the brake caliper (11) is kept constant at the rating reached previously, regardless of the pressure on the brake pedal. Although the braking effort maintains a continuous slowing action, the wheel effort maintains its speed, in relation to the ramp on the ground, until the signal of the rpm sensor (12) is a value similar to the reference speed calculated by the electronic control unit (1).

At this point, the control unit passes from the maintenance phase to the pressure increase phase (if the wheel accelerates) or reduction (if the wheel tends to lock).

Pressure reduction phase



1. Electronic control unit
2. Low pressure accumulator (reservoir)
3. Recovery pump drive motor
4. Recovery pump
5. High pressure accumulator (damping chamber)
6. Brake control pump
7. Servobrake
8. Fast pressure reduction valve
9. Charge solenoid valve
10. Discharge solenoid valve
11. Brake caliper
12. Rpm sensor
13. Phonic wheel
14. Restrictor

The electronic control unit (1) detects the tendency of the wheel to lock and activates the electrohydraulic unit to keep deceleration of the wheel within the thresholds allowed.

The electronic control unit (1) connects to earth the charge (9) and discharge (10) solenoid valves.

The charge solenoid valve (9) remains closed keeping the connection between the brake pump (6) and brake caliper (11) shut; The discharge solenoid valve (10) opens putting the brake caliper (11) into hydraulic connection with the low pressure accumulator (2) and the recovery pump (4), in order to withdraw part of the fluid at the brake caliper (11) and reduce the pressure on the caliper itself.

Simultaneously, the electronic control unit (1) supplies the drive motor (3) of the recovery pump (4) which makes it possible to re-admit the fluid taken from the brake caliper (11) to the main circuit.

The accumulator (2) or low pressure reservoir in the circuit has the task of storing part of the brake fluid taken from the calipers. Through the circuit of the recovery pump (4), the fluid is withdrawn and sent, via the damp-

ing chamber (5) and the restrictor (14), into the main circuit of the brake pump (6).

In this phase a series of pressure waves (or hydraulic thrusts) are generated which are dampened by the presence of the damping chamber (5) and the restrictor (14).

During braking, light pushes on the brake pedal are to be considered normal when the ABS system is operational. During this phase, due to the effect of the lowering of the braking force, the wheel tends to resume the reference speed calculated by the electronic control unit (1).

The type of braking is intermittent or by steps with a succession of the phases depending on the wheel rolling conditions and according to a repetitive cycle that is not perceived by the driver, in the form of jerks, owing to the quickness and frequency with which it occurs and because it is evaded out by the inertia of the wheel which is prevented from reaching extreme skidding conditions because of the rapidity of the device.




With the car without A.B.S. the driver is able to act intermittently on the brake pedal with a frequency of 2 cycles per second (2 presses and 2 releases).
 With the A.B.S. system, the cycles increase to 4-10 per second (depending on grip).
 Normally operation of the A.B.S. ceases at speeds below 2,75 km/h to allow the wheels lock completely when the car reaches a halt.

Brake pedal release

— pressure reduction

NOTA The recovery pump is of the free piston type with double circuit, driven by an electric motor that turns constantly during the recovery phase.
 The pistons are not coupled with the electric motor but they are moved by the cam, only upon arrival of the brake fluid. Therefore, the pump can perform only one impelling stroke while suction is not possible owing to the lack of mechanical connection between motor and pump.



- 1. Electronic control unit
- 2. Low pressure accumulator (reservoir)
- 3. Recovery pump drive motor
- 4. Recovery pump
- 5. High pressure accumulator (damping chamber)
- 6. Brake control pump
- 7. Servobrake
- 8. Fast pressure reduction valve
- 9. Charge solenoid valve
- 10. Discharge solenoid valve
- 11. Brake caliper
- 12. Rpm sensor
- 13. Phonic wheel
- 14. Restrictor

To enable rapid reduction of the pressure on the brake pedal (11) when the brake pedal is released, the system

is fitted with a non return valve (6) in parallel with the inlet solenoid valve (9).



REPAIR OPERATIONS ON THE UNIT



Instructions for correct repairing

- To replace the electronic control unit it is necessary to disassemble the whole hydraulic unit, owing to reasons of space and to avoid damaging the internal connector.
- The electrohydraulic control unit cannot be overhauled and it is fault-proof until it is tampered with. It must be replaced if found to be faulty.
- After each replacement of a hydraulic unit, rpm sensor, electronic control unit or wiring (especially if after an accident) the entire A.B.S. system must be checked with the Tester.
- After all operations on the hydraulic system of the A.B.S. or brake system, it is necessary to fill with DOT 4 brake fluid, relieve the air, and check the tightness of all the connection points.

- The electrohydraulic control unit is supplied filled with DOT 4 brake fluid and with the solenoid valves not supplied. The operation for filling with fluid and relieving the air is the same as for a conventional system, but requires more time.
- During removal of the electrohydraulic unit avoid overturning it to prevent spilling the oil contained in the hydraulic part.
- When refitting pay attention to the unions: to prevent mistakes in connecting the various parts of the braking circuit during repair operations, the connections of the hydraulic modulator unit are of different sizes (M10x1 and M12x1), the unions are also identified by the codes stamped on them.



GROUP 23

STEERING SYSTEM

INDEX

STEERING SYSTEM

- DESCRIPTION..... 23-2
- POWER STEERING PUMP..... 23-2
- TECHNICAL CHARACTERISTICS
AND SPECIFICATIONS..... 23-4

- GENERAL SPECIFICATIONS 23-4
- Fluids and lubricants 23-4
- TIGHTENING TORQUES..... 23-4
- SPECIAL TOOLING 23-5

For all the parts not mentioned herein, see the corresponding Group of the manual "155 - INSTRUCTIONS FOR REPAIR" - PA465500000000 - (pages with publication no. PA4655C1000000)



STEERING SYSTEM

DESCRIPTION


The power assisted steering system reduces effort at the steering wheel when manoeuvring from a standstill while reaping steering accurate at high speeds.

The system comprises a pump (1) operated directly by the engine through a belt. The pump withdraws oil through the suction pipe from the tank (2) located in the engine compartment and sends it under pressure

through the delivery pipe to the distributor valve on the power steering box (3).

The distributor valve, controlled by the turning of the steering wheel (4) and steering column (5), sends the oil under pressure from one side or the other of the hydraulic cylinder, which is integral with the rack and pinion, inside the steering box.

A pipe returns to the tank, thereby closing the circuit.




NOTE: the location of the components in the engine compartment is illustrated above.

For the removing and refitting service procedures, refer to the corresponding group of the manual "155 - INSTRUCTIONS FOR REPAIR" PA46550000000 with the exception of the following concerning the power steering pump.


POWER STEERING PUMP

REMOVAL AND REFITTING


- Set the car on a lift.
 - Remove the right front wheel with gravel guard (see GROUP 7D).
 - Remove the right engine compartment shield.
 - Using a syringe, withdraw the oil from the power steering tank
1. Slacken the belt tensioner and remove the pulley guide
 2. Remove the services drive belt.



1. Holding the pump shaft, slacken the three screws fastening the power steering pump pulley and remove it.
2. Working from above, disconnect the two pump inlet and delivery pipes.



1. Slacken the three fastening screws and remove the power steering pump



Refit the pump reversing the procedure followed for removal. Tension the belt as described in group 00.

Fill the hydraulic circuit and relieve the air (see specific paragraph).

TECHNICAL CHARACTERISTICS AND SPECIFICATIONS

GENERAL SPECIFICATIONS

FLUIDS AND LUBRICANTS

APPLICATION	TYPE	NAME
Filling power steering system	OIL	TUTELA G1/A
Roller bush seat on steering column support	GREASE	SPCA Spagroph ISECO Ergon Rubber Grease REINACH Sferal B2 AR

TIGHTENING TORQUES

Description	N·m	kg·m
Self-braking nut for fastening steering wheel to steering column	42 + 52	4.3 + 5.4
Self-braking nut for fastening track rod ball pin to wheel upright	29 + 36	3.0 + 3.7
Oil inlet pipe fitting on power steering	38 + 42	3.9 + 4.3
Oil outlet pipe fitting on power steering	29 + 32	3.0 + 3.3
Bolt fastening steering column to power steering pinion	17 + 21	1.7 + 2.1
Screws fastening steering box to front crossmember	47 + 57	4.8 + 5.8
Nut for locking steering track rod	10 + 15	1.0 + 1.5
Self-locking nuts for fastening steering column cardan joint forks	17 + 21	1.7 + 2.1
Self-locking nut fastening steering wheel on steering column	42 + 52	4.3 + 5.3
Screws fastening steering column to body	21 + 26	2.1 + 2.7
Screw fastening steering wheel adjustment lever	15 + 19	1.5 + 1.9
Nut fastening lower reaction strut (air-bag)	14 + 23	1.4 + 2.3
Rear steering wheel fastening screws (air-bag)	7 + 8	0.7 + 0.8

SPECIAL TOOLING

TOOL NUMBER	DESCRIPTION
1.821.105.000	Steering wheel puller tool
1.821.169.000	Track rod pin puller tool



REAR SUSPENSION

INDEX

REAR SUSPENSION

TECHNICAL CHARACTERISTICS AND SPECIFICATIONS 25-2

- TECHNICAL CHARACTERISTICS 25-2

- Coil springs 25-2

- Shock absorbers 25-2

- Stabilizer bar 25-2

- CHECKS AND ADJUSTMENTS..... 25-3

- Rear wheel toe-in..... 25-3

- Rear wheel camber 25-3

- TIGHTENING TORQUES..... 25-4

- SPECIAL TOOLING..... 25-4

For all the parts not mentioned herein, see the corresponding Group of the manual "155 - INSTRUCTIONS FOR REPAIR" - PA465500000000 - (pages with publication no. PA4655C1000000)



25-2

REAR SUSPENSION

TECHNICAL CHARACTERISTICS AND SPECIFICATIONS

TECHNICAL CHARACTERISTICS

COIL SPRINGS

CHARACTERISTICS	
Inside diameter (mm)	100
Outside diameter (mm)	124.8
Diameter of wire (mm)	12.4
Number of coils	6.32
Direction	Right-handed
Free length (mm)	305

SHOCK ABSORBERS

Type	telescopic hydraulic pressurized lamellar
Stroke (mm)	160
Diameter of stem (mm)	11.5

STABILIZER BAR

Diameter of bar (mm)	17
----------------------	----

ANGOLI / ASSETTI ALFA 155 - Edizione 95

VETURE		RUOTE ANTERIORI					RUOTE POSTERIORI		
ALFA 155		CAMPANATURA	CONVERGENZA	INCIDENZA	ASSETTO	CAMPANATURA	CONVERGENZA	ASSETTO	
		mm	mm	B	mm	mm	mm	mm	
1.7	-20 ± 20'	-1 ± 1	3°10' ± 30'	-20 ± 5	//	-1° ± 15'	0,5 ± 2	-10 ± 5	
1.8	-20 ± 20'	-1 ± 1	3°10' ± 30'	-20 ± 5	*Lusso	-1° ± 15'	0,5 ± 2	-10 ± 5	
2.0 16V	-20 ± 20'	-1 ± 1	3°10' ± 30'	-20 ± 5	*Super	-1° ± 15'	0,5 ± 2	-10 ± 5	
2.5 V6	-20 ± 20'	-1 ± 1	3°10' ± 30'	//	//	-1° ± 15'	0,5 ± 2	-25 ± 5	
2.0 TB 4x4	-20 ± 20'	-1 ± 1	3°10' ± 30'	//	//	-1° ± 15'	1,3 ± 2	-15 ± 5	
TD	-20 ± 20'	-1 ± 1	3°10' ± 30'	-20 ± 5	//	-1° ± 15'	0,5 ± 2	-10 ± 5	
2.5 TD	-20 ± 20'	-1 ± 1	3°10' ± 30'	-35 ± 5	-35 ± 5	-1° ± 15'	0,5 ± 2	-25 ± 5	

N.B. - Valori misurati a vuoto in ordine di marcia (con rifornimenti prescritti)

Allestimenti

TIGHTENING TORQUES

Description	N.m	kg.m
Hex. head screw for fastening front rebound pad to the body	92 + 113	9.4 + 11.6
Hex. head screw for fastening rear rebound pad to the body	92 + 113	9.4 + 11.6
Bolt fastening rear suspension wishbone to frame	142 + 157	14.5 + 16.0
Nut for screw fastening lower shock absorber to suspension	75 + 92	7.6 + 9.4
Hex. head screw for fastening upper shock absorber to the chassis	48 + 59	4.9 + 6.0
Nut for pin fastening rear hub	226 + 294	27 + 30
Hex. head screw for fastening stabilizer bar to rear suspension arm	48 + 59	4.9 + 6.0
Hex. head screw for fastening stabilizer bar support U-bolts to rear suspension arm	24 + 29	2.4 + 3.0
Wheel stud	83 + 103	8.5 + 10.5

SPECIAL TOOLS

TOOL NUMBER	DESCRIPTION
1.820.003.000	Tool for removing and refitting rear axle
1.822.005.000	Extension wrench for tightening rear wheel hub fastening nut

CHECKS AND ADJUSTMENTS

REAR WHEEL TOE-IN

A-B	2.0 T.SPARK 16V	
	Version with heater	Version with air conditioner
	2.9 ± 1 mm	2.7 ± 1 mm
	(not adjustable)	

N.B. Values measure with unladen vehicle in running order (with fuel and specified fluids).

REAR WHEEL CAMBER

2.0 T.SPARK 16V	
	(not adjustable)
	α = °

N.B. Values measure with unladen vehicle in running order (with fuel and specified fluids).

* NOT AVAILABLE AT TIME OF GOING TO PRESS

REAR ALIGNMENT

(see GR 21 - Front suspension - Technical Characteristics and Specifications).



TIGHTENING TORQUES

Description	Nm	kgm
Hexagon head screw for fastening front rubber rebound to body	92 ± 113	9.4 ± 11.6
Hexagon head screw for fastening rear rubber rebound to body	92 ± 113	9.4 ± 11.6
Bolt fastening rear suspension wishbone to frame	142 ± 157	14.5 ± 16.0
Nut for screw fastening front shock absorber to suspension	75 ± 92	7.6 ± 9.4
Hexagon head screw for fastening upper shock absorber to chassis	48 ± 59	4.9 ± 6.0
Nut for rear hub fastening pin	226 ± 294	27 ± 30
Hexagon head screw for fastening stabilizer bar to rear suspension arm	48 ± 59	4.9 ± 6.0
Hexagon head screw for fastening U-bolts supporting stabilizer bar to rear suspension arm	24 ± 29	2.4 ± 3.0
Wheel stud	83 ± 103	8.5 ± 10.5


SPECIAL TOOLS

TOOL NUMBER	DESCRIPTION
1.820.003.000	Tool for removing and refitting rear axle
1.822.005.000	Extension wrench for tightening rear wheel hub fastening nut




CHECKS AND ADJUSTMENTS

REAR WHEEL TOE-IN



N. B. Values measured with unladen car in running order (with specified fluids).

REAR WHEEL CAMBER



N.B. Values measured with unladen car in running order (with specified fluids)

REAR GEOMETRY

(see GR. 21 - Front suspension - Technical characteristics and specifications).



GROUP 28

WHEELS AND TYRES

INDEX

WHEELS AND TYRES 28-1

TECHNICAL CHARACTERISTICS AND SPECIFICATIONS 28-2

TIGHTENING TORQUES 28-2

CHARACTERISTIC DATA 28-2

For all the parts not mentioned herein, see the corresponding Group of the manual "155 - INSTRUCTIONS FOR REPAIR" - PA465500000000 - (pages with publication no. PA4655C1000000)



TECHNICAL CHARACTERISTICS AND SPECIFICATIONS

TIGHTENING TORQUES

PART	N · m	kg · m
Wheel fastening screws (with rims in sheet metal)	83 + 103	8.5 + 10.5
Wheel fastening screws (with rims in alloy)	83 + 103	8.5 + 10.5

CHARACTERISTIC DATA

Dimensions

MODEL	RIM SIZES	TYRE SIZES	PRESSURES (bar)			
			REDUCED LOAD (2 PERSONS)		FULLY LADEN	
			FRONT	REAR	FRONT	REAR
2.0 T. Spark 16V	6.5Jx15"	195/65 VR15	2.2	2.0	2.5	2.5
	6.5Jx15"	205/60 VR15	2.5	2.3	2.8	2.5
	OPTIONAL 7J X 16"	205/45 ZR16				
	SPARE WHEEL (compact type) 4B X 15" for alloy rims 4J X 15" for steel rims	115/70 R15 90M			4.2	

CAUTION: In the event of continued driving at top speed, the pressures should be increased by 0.3 bar.

NOTE: For improved mating between the wheels and the car body the rims have a specific camber value for each rim size. Therefore, in addition to the correct rim and tyre match it is also necessary to check and maintain the rim camber.

RIM SIZE	RIM CAMBER
6.5 J X 15"	37 mm
7 J X 16"	41 mm




155


T.SPARK 16V


REPAIR MANUAL


● BODY

 GROUP 40 - ELECTRICAL SYSTEM


 GROUP 43 - INSTRUMENT PANEL AND ELECTRONIC INSTRUMENTS

155 ◀  GROUP 49 - BODYWORK


155 ◀  GROUP 55 - DOORS

155 ◀  GROUP 56 - BOOT AND BONNET

155 ◀  GROUP 66 - INTERIOR TRIM

155 ◀  GROUP 75 - EXTERNAL TRIM

 GROUP 80 - HEATING AND VENTILATION

 Refer to the corresponding Group in the "155 - REPAIR MANUAL" - PA4655D1000000

155

T.SPARK 16V

REPAIR MANUAL

ELECTRICAL & ELECTRONIC DIAGNOSIS



GROUP 40

ELECTRIC SYSTEM

INDEX

ELECTRIC SYSTEM	40-2
- RULES AND PRECAUTIONS	40-2
- FUSES	40-3
- Location in fusebox	40-3
- Location on auxiliary bracket	40-4
- Location in engine compartment ..	40-4
- ELECTROMECHANICAL DEVICES, TIMERS AND INTERMITTENT DEVICES	40-5
- Location in fusebox	40-5
- Location on auxiliary bracket	40-5
- Location in engine compartment ..	40-6

For all the parts not mentioned herein, see the corresponding Group of the manual "155 - INSTRUCTIONS FOR REPAIR" - PA46550000000 - (pages with publication no. PA4655D1000000)



ELECTRIC SYSTEM

RULES AND PRECAUTIONS

WARNING:

Before removing and refitting the components of the electric system, carefully read the **RULES AND PRECAUTIONS**.

Before starting any work, make sure that the ignition key is in the "parking" position and that the battery earth cable is disconnected and always:

- avoid connecting the output of control units directly to the load;
- never work directly on devices with cables connected to "positive" or to earth without before disconnecting the control units;
- avoid short circuiting the sensors of the system unless otherwise stated;
- before doing any electric welding, disconnect the control units to prevent possible damage to the electronic components caused by induced currents.



CAUTIONS:

Work on the systems foreseeing the possible consequences and do not intervene if you are not perfectly aware of the characteristics of the components concerned.

When re-assembling and/or refitting, reverse the sequence described for disassembly and/or removal, unless otherwise specified and restore the battery connection.

After replacing a component of the electric system you are strongly advised to re-stock with Genuine Alfa Romeo Spares. The use of non original Alfa Romeo components, with even slightly different features, can adversely affect the functional reliability and operating safety of the vehicle.


Never touch the glass surfaces of halogen bulbs with the hands. When replacing halogen bulbs only touch the parts in metal.

FUSES

LOCATION IN THE FUSEBOX

NOTE: in the centre, in the vertical position, there are some spare fuses.

The table below lists the fuses contained in the fusebox, with the corresponding symbol, amp rating and the services protected.



FUSE		SERVICES PROTECTED
SYMBOL	N° AMP.	
	1 10A	Hazard warning lights
	2 25A	Horns, stop lights, radio, Boot opening control
	3 20A	Windscreen wiper
	4 25A	Cigar lighter, ceiling lamps
	5 10A	Controls lighting, LH rear sidelights, RH no. plate light., RH front sidelights, sidelights warning light.
	6 10A	Controls lighting, cluster lighting, RH rear sidelights, LH no. plate light, LH front sidelight, headlamp aiming device
	7 10A	Right low beam
	8 10A	Left low beam
	9 15A	Right high beam
	10 15A	Left high beam, high beam warning light
	11 7.5A	Rear fog guard, fog guard warning light
	12 30A	Heated rearscreen, heated rearscreen warning light, mirror defroster
	13 30A	Fan, rear power windows, adjustable and heated seats, radio
SERVICES	15 15A	Instr. cluster, windscreen-headlamp washer electric pump, reversing lights, glovebox light, check panel, engine fan, ALFA ROMEO CODE
	16 10A	Clock, ceiling lamps, conditioner control unit, alarm remote control
	17 7.5A	Direction indicators, mirror adjustment
	18 20A	Door locking device
	19 20A	Fog lamps, fog lamp warning light
	20 30A	Electric sunroof
	21 30A	Adjustable and heated seats
	22 25A	Left front power window (*)
	23 25A	Rear power window

(*) Versions with automatic LH front power window control

LOCATION ON AUXILIARY BRACKET

There is a set of fuses on an auxiliary bracket (not removable) at the left of the main fusebox.

The fuses are distinguished by the colour of the fuse-holder base that connects them to the wiring, according to the following table:

COMPONENT	AMP.	COLOUR OF BASE
Headlamp fuse	20 A	Yellow
ABS fuse	- NOT CONNECTED -	Red
Front power window fuse	10 A	Red
Front left power window fuse (*)	25 A	White
Climate control fan fuse	25 A	White
Air conditioning system fuse	30 A	Green
	10 A	Red

(*) Versions with manual LH front power window control


N.B. In addition to the colour of the base, it is also wise to check the exact location of a fuse by the colour of the wires that converge on it (for this see the corresponding wiring diagram in "ELECTRIC - ELECTRONIC DIAGNOSIS").

LOCATION IN THE ENGINE COMPARTMENT

In the engine compartment there are the fuses for the following systems:
general and system supply;
injection and ignition system.

GENERAL AND SYSTEM SUPPLY

In the branch box, next to the A.B.S. control unit, there are the main supply fuses for all the systems of the vehicle:




1. Fan fuse (50A)
2. Services supply fuse (50A)
3. General supply fuse (70A)
4. General supply fuse (70A)

Outside there are two other fuses:
5. Motronic system supply fuse (40A);
6. ABS system supply fuse (60A).

INJECTION AND IGNITION SYSTEM

The fuses, together with the relays of the same system are to be found on two brackets next to the battery.


1. Fuel pump fuse (10A)
2. Lambda probe fuse (7.5) (Models 2.0 m.y. '95)
- Lambda probe fuse (8) (Models 1.6 - 1.8 - 2.0 m.y. '96)





ELECTROMECHANICAL DEVICES, TIMERS AND INTERMITTENCES

LOCATION IN THE FUSEBOX



- 1- Engine water cooling fan 1st speed relay (only air conditioned versions)
- 2- Sunroof relay
- 3- Hazard warning lights and direction indicator relay
- 4- Rear fog guard relay
- 5- High beam relay
- 6- Key-operated supply relay
- 7- Fog lamp relay
- 8- Low beam relay
- 9- Heated rear screen relay
- 10- Door locking control unit
- 11- Horns relay
- 12- Sidelights relay
- 13- Windscreen wiper electronic intermittence

LOCATION ON AUXILIARY BRACKET

A set of relays is located on an auxiliary bracket (not removable) at the left of the main fusebox; next to this there are the power window control unit and the ALFA ROMEO CODE control unit (see Group 43).

The relays are distinguished by the colour of the relay holder base which connects them to the wiring, according to the following table:

COMPONENT	COLOUR OF BASE
Boot opening relay (with 30 A fuse)	Red
Timer for headlamp washer	Black
Climate control auxiliary relay	Grey - Purple (*)
Compressor joint control relay	Grey
Engine cooling fan relay	Black


(*): Models 1.6 - 1.8 - 2.0 m.y. '96

N.B. In addition to the colour of the base, it is also wise to check the exact location of a relay by the colour of the wires that converge on it (for this see the corresponding wiring diagram in "ELECTRIC - ELECTRONIC DIAGNOSIS").



LOCATION IN THE ENGINE COMPARTMENT

A set of relays - for the injection/ignition system - is located on two auxiliary brackets next to the battery.



COMPONENT	COLOUR OF BASE
Main relay	Black
Secondary timer	Black
Fuel pump relay	Black
Timing variator relay	Black

N.B. In addition to the colour of the base, it is also wise to check the exact location of a relay by the colour of the wires that converge on it (for this see the corresponding wiring diagram in "ELECTRIC - ELECTRONIC DIAGNOSIS").



GROUP 43

INSTRUMENT CLUSTER AND ELECTRONIC INSTRUMENTS

INDEX

INSTRUMENT CLUSTER AND ELECTRONIC INSTRUMENTS.....	43-2	- ELECTRONIC CLUSTER	43-3
- RULES AND PRECAUTIONS	43-2	- Services warning lights	43-4

For all the parts not mentioned here see the corresponding group of manual "155 - INSTRUCTIONS FOR REPAIR" - PA46550000000 - (Pages with publication no. PA4655D1000000)



INSTRUMENT CLUSTER AND ELECTRONIC INSTRUMENTS

RULES AND PRECAUTIONS



WARNING

Before disconnecting and refitting components of the electric system, carefully read the following **RULES AND PRECAUTIONS**:

Before doing any work, make sure that the ignition key is in the "parking" position and that the battery earth cable is disconnected, and at all times:

- avoid connecting the output of control units directly to the load;
- absolutely avoid working directly on devices with cables connected to "positive" or earth without firstly disconnecting the control units;
- avoid short circuiting the sensors of the system unless otherwise specified;
- before doing any electric welding disconnect the control units to avoid damaging the electronic components due to induced currents.

CAUTIONS:


Work on systems foreseeing the possible consequences and do not intervene when you are not perfectly familiar with the specifications of the components involved.

When re-assembling and/or refitting reverse the sequence followed for dis-assembly and/or removal, unless otherwise specified, and restore the battery connection.

After replacing a component of the electric system, you are strongly recommended to replace the spare with Original Alfa Romeo Spare Parts. The failure to use original Alfa Romeo components, with even slightly different characteristics may adversely affect operating reliability and safety of the vehicle.



ELECTRONIC INSTRUMENT CLUSTER


























1. Engine coolant temperature gauge
2. Engine oil temperature gauge
3. Trip meter reset
4. Speedometer
5. Trip meter

6. Mileage recorder
7. Services warning light (see details on following page)
8. Rev counter
9. Engine oil pressure
10. Fuel level gauge

GROUP 80

SERVICES WARNING LIGHT

-  LH direction indicator
-  Sidelights and low beam lights
-  RH direction indicator
-  High beam lights
-  Hazard warning lights
-  Rear fog guards
-  Fog lamps
-  Low engine oil level
-  High engine coolant temperature
-  Water in fuel oil filter (N.C.)
-  Glow plugs (N.C.)
-  Catalytic silencer temperature
(only for certain Versions/Markets)
-  Heated rearscreen
-  Generator warning light
-  ABS wheel anti-lock system

-  Low brake fluid level/handbrake engaged
-  Worn brake pads
-  Electronically-controlled suspension (N.C.)
-  Injection system
-  Low engine oil pressure
-  ALFA ROMEO CODE
-  Seat belts
-  Fuel reserve

HEATING AND VENTILATION

INDEX

AUTOMATIC CLIMATE CONTROL WITH AIR CONDITIONER 80-2

AIR CONDITIONING CIRCUIT 80-2

- Operating principle 80-3

COMPRESSOR 80-3

- Composition and operation 80-4
- Flow rate control 80-5
- Lubrication 80-8
- Compressor engagement/disengagement strategy 80-8

LOCATION OF COMPONENTS 80-9

OPERATING PROCEDURES 80-10

- General precautions for work on the climate control unit 80-10
- Ducting/Distributor unit 80-10

- Compressor 80-11
- Condenser 80-12
- Drier filter 80-13
- Expansion valve 80-13
- Three-level pressure switch 80-13
- Antifrost pressure switch 80-14

SYSTEM EMPTYING AND RECHARGING OPERATION 80-14

TECHNICAL CHARACTERISTICS AND SPECIFICATIONS 80-16

- Minimum pressure switch setting 80-16
- Three-level pressure switch setting (Trinary) 80-16
- Expansion valve 80-16
- Compressor 80-16
- Fluids and lubricants 80-17
- Tightening torques 80-17
- Special tools 80-17

For all the parts not mentioned herein, see the corresponding Group of the manual "155 - INSTRUCTIONS FOR REPAIR" - PA465500000000 - (pages with publication no. PA4655D1000000)

AUTOMATIC CLIMATE CONTROL WITH AIR CONDITIONER

The climate control system is the same as the one fitted on the other versions of the 155.

In the other version with T.SPARK 16V engines the layout of the cooling system in the engine compartment is different.

While the compressor coupled with these engines is a NIPPONDENSO TV 1450 with variable displacement. Therefore the description given here only refers to the specific characteristics for this version, while for all the other shared parts, reference should be made to "155 - REPAIR INSTRUCTIONS - GROUP 80 "HEATING AND VENTILATION".

AIR CONDITIONING CIRCUIT


This circuit is shown schematically below and mainly comprises the following components:

- a compressor fitted on the engine, which compresses the refrigerant fluid from the evaporator outlet;
- a condenser, fitted in front of the engine refrigerant fluid radiator,
- an evaporator, located in the ducting unit;
- a drier filter.

The above-mentioned parts are connected to one another by suitable pipes. On the pipe connecting the condenser to the evaporator there is a three-level pressure switch which acts as a system control and safety device, protecting the circuit against over and underpressures.

For the 2.0 T.S. 16V engine also an antifrost pressure switch is installed - before the drier filter - which prevents excessively low pressures in the circuit that might "freeze" the evaporator and block the system.

An expansion valve is inserted on the high pressure line



High pressure circuit

Low pressure circuit

1. Compressor
2. Condenser
3. Condenser fan
4. Expansion valve
5. Evaporator fan
6. Evaporator
7. Drier filter
8. Three-level pressure switch (ternary)
9. Antifrost pressure switch


- a. Flow of air for cooling the condenser: leading from the front grille when the car is on the move.
- b. Flow of air for cooling the condenser: caused by the fan (3) when the car is at a standstill or travelling at low speed
- c. Flow of air for the evaporator: caused by the fan (5) fitted in the ducting-distributor unit.

COMPRESSOR

This compressor is a NIPPONDENSO TV145C with variable displacement: the change in this parameter is carried out automatically by the compressor in relation to the load (difference in the pressure up and downstream of it): a special valve controls the opening of a by-pass which shuts off part of the fluid from the compression stroke; the displacement can be reduced to 17% of the maximum rate.

Adjustment takes place on the inlet pressure:

- a low inlet pressure will make the system reduce the displacement. This happens for instance when the cooling cycle is working in the best conditions: high engine rpm (and of the compressor), high thermal exchange at the condenser etc.; (without a compressor with this variable configuration the compressor would cut in and out continuously);
- a high inlet pressure, on the other hand, increases the displacement to its maximum value. This happens for instance with low engine rpm and high requirements for "cold".



OPERATING PRINCIPLE

The purpose of the air conditioner is to cool and dehumidify the air directed to the passenger compartment. It works according to a common cooling cycle in the circuit of the - FREON R134a - fluid in which the changes of state (from liquid to gas and vice-versa) are exploited to absorb and release heat.

During operation, two levels of pressure are created in the circuit which are maintained on one side by the compressor and on the other side by an expansion valve at the evaporator inlet.

Two needle valves are fitted on the pipes for draining and refilling the system: one on the high pressure side and the other on the low pressure side.

The refrigerant fluid leaves the compressor as a gas at high pressure and high temperature. It then enters the condenser where it is cooled and comes out as a liquid.

The expansion valve, at the evaporator inlet lowers the pressure of the fluid thus also its temperature. The fluid, still in liquid form, enters the evaporator where it is vapourised, absorbing heat from the air pushed against its fins by the fan. The air in contact with the cold walls of the evaporator loses a high percentage of humidity which condenses and is drained off outside the car through a special drainage tube.

This way the air admitted inside the car is colder and less humid.

The fluid in a gaseous state leaves the evaporator and then passes through the drier filter which absorbs any water particles, which, if allowed to continue in the cycle could freeze and block the expansion valve, thereby reducing or nullifying the efficiency of the cycle; lastly, it returns to the compressor to resume the cycle.



Composition and operation

The compressor consists of a body (1) in which a chamber (2) has been made. Four blades (3) turn inside this chamber pulled by a hub (4) whose axis of rotation does not coincide with the chamber's theoretical axis. The particular geometry of the chamber is such that as the blades turn they always contact the inner surface of the chamber: this means that differences in the compartments between one blade and the next can be obtained during rotation.

Two covers, front (5) and rear (6) are fastened to the compressor body (1) to form an intake or low pressure chamber (7) and a high pressure chamber (8) respectively. The gas taken in through union (10) on cover (5) passes through the low pressure chamber (7) and slot (11) on the body (1).

The gas is then compressed and pushed through the duct (12) in the high pressure chamber (8) and sent to the system via union (13). The reed valve (14) prevents the high pressure gas from returning to the compressor. On the top section of the body there is a temperature sensitive contact (15) connected in series to an electromagnetic joint. When the temperature reaches dangerous limits (over 160°C), this contact (15) cuts out the compressor: it activates it again if the temperature falls below 140°C.

This way operation is prevented under dangerous conditions such as lack of fluid or oil. The pressure regulator (16) in the lower section of the compressor serves to adjust the flow rate of the fluid in the compressor, as described on the next page.



Flow rate control

The flow rate control is obtained through a pneumatic mechanism incorporated in the compressor, which by-passes part of the gas in the compression phase, at the intake, i.e. in the low pressure chamber.

When activated, this system makes it possible to reduce the compressor flow rate gradually and continuously to approx. 17% of the total capacity.

The mechanism comprises the piston (A) which can run in the cylinder (C) counteracted by the spring (B).


When the piston is positioned as shown in figure A, it cuts off holes (D) which connect compartment (E) - in which the gas begins to be compressed - with the low pressure chamber (F). Conversely, when the piston (A) is in the position shown in Figure B, the holes (D) connect the two chambers.

The piston is operated by a small amount of the pressurised gas withdrawn from duct (J) which communicates with the calibrated hole (G).

The pressure regulator (H) is adjusted by the difference in pressure between intake - chamber (F) - and delivery: when the intake pressure is high valve (I) is closed, and the pressure of the gas acts on piston (A) taking it to the position of figure A. Holes (D) are cut off and by-passing does not take place. This starts off compression of the gas in chamber (E) as described.

When the intake pressure falls, the regulator (H) opens the valve (I) allowing the pressurised gas in duct (J) and in cylinder (C), to discharge into the low pressure chamber (F). Because of, piston (A) is pushed by the spring (B) allowing the by-pass holes (D) to open.

This way, part of the gas in chamber (E) - start of compression - can flow into the low pressure chamber (F), until blade (K) has covered the holes (D); this reduces the amount of gas in chamber (E) resulting in the reduction of the compressor flow rate.







a - Normal operation
(100% Capacity - by-pass closed)

Intake



The gas is taken in through the inlet slot (D) as compartment (C) gradually expands between blades (A) and (B). This is the beginning of the intake phase.



The new position of blades (A) and (B) gives compartment (C) its maximum volume. Blade (A) cuts compartment (C) off from slot (D) thereby completing the intake phase.


Compression

The volume of compartment (C) is reduced and the gas pressure increases. This begins the compression phase.



Discharge

The pressure of the gas increases further until the reed valve (E) opens: this precise instant ends the compression phase and begins the discharge phase.




When blades (A) and (B) reach the position illustrated the discharge phase ends.



B - Operation with reduction of the displacement
(Down to 17% of the displacement - by-pass open)


Intake

The gas is drawn in by the intake port (D) due to the gradual expansion of compartment (C), delineated by blades (A) and (B); this is the start of the compression stage.




By - pass

If the holes (F) are open part of the gas flows out: the compression stage does not start yet.




Compression

Once past the holes (F), compartment (C) reduces in volume thereby increasing the pressure of the remaining gas (down to a minimum of 17% of the total): the compression stage starts.




Exhaust

The pressure of the gas further increases until it opens the reed valve (E): in this precise moment the compression stage ends and exhaust begins.



LOCATION OF COMPONENTS



- 1. Expansion valve
- 2. Evaporator
- 3. Needle valve on low pressure pipe
- 4. Antifrost pressure switch
- 5. Drier filler
- 6. Three-level pressure switch
- 7. Needle valve on high pressure pipe
- 8. Condenser
- 9. Compressor

Compressor cut-in and cut-out strategy

Compressor engagement is operated by the electromagnetic joint controlled by the electronic injection management system of the engine.

Indeed the compressor absorbs a fair amount of power to the disadvantage of the overall output of the engine, and in certain instances, this must be avoided:

- at idle speed the engine must adapt its own speed taking account of this increase in absorbed power;
- when the engine is started or when high load is required, the compressor is cut off to leave all the available power for the engine.

The control unit carries out the following strategies:

- adapts the engine idle speed each time the compressor is engaged; if the speed falls below the idle speed rate, the compressor is cut off;
- in the event of the need for high power, over 6000 rpm (high throttle opening speed), or full load, or high engine temperature (above 117°C), the compressor is momentarily disengaged;
- when the engine is started it prevents the compressor from being engaged until normal operating conditions are reached.

NOTE: You are reminded that the NIPPONDENSO TV14SC compressor with which this version is fitted, automatically cuts off the compressor if the temperature of the coolant fluid inside the compressor exceeds 160°C.

Lubrication

The lubricating oil is contained in the high pressure chamber (A).


When the compressor is operating the high pressure in the chamber pushes the oil through the calibrated hole (B) into the inner moving components.

The oil mixed with gas (C) is sent out through the reed valves (D) in the high pressure chamber.

A separator device (E) installed in the gas outlet union separates it from the oil (G) which falls by gravity into the bottom of the chamber (A) while the gas flows out of the union (F).

This device makes it possible to minimise the quantity of oil admitted into the system piping thereby increasing the thermal yield.

The compressor is also fitted with two safety valves (H) which relieve any overpressure in the compression chamber (I).



OPERATING PROCEDURES

GENERAL PRECAUTIONS FOR OPERATIONS ON THE CLIMATE CONTROL SYSTEM




- Before doing any maintenance and repair work you are advised to disconnect the battery negative terminal.
- Before dis-assembling the system it is necessary to drain the system and recover the coolant fluid.
- During operations, when the system components are disconnected, suitably plug the disconnected fittings to prevent the entrance of moisture and impurities in the system.
- When refitting the pipe fittings replace the O-rings on the fittings themselves.
- Lubricate pipe fitting threads with the specified anti-freeze oil and tighten the fittings to the specified torque.


DUCTING/DISTRIBUTOR UNIT

REMOVAL

- Dis-assemble and remove the tunnel console (see: GR. 66).
- Dis-assemble and remove the control unit (see corresponding paragraph).
- Dis-assemble and remove the underdash trim (see: GR. 66).
- Remove the battery after disconnecting the terminals.
- 1. Remove the corrugated air inlet pipe between the cleaner and the throttle after disconnecting the air flow meter.
- 2. Empty the power steering tank and remove it slackening the two screws fastening it to the services tray partition and disconnecting the pipes.




1. Using wrenches 1.822.111.000 and 1.822.113.000 disconnect the piping from the evaporator to the condenser.
2. Using wrenches 1.822.112.000 and 1.822.115.000 disconnect the piping from the evaporator to the drier filter.
- Remove the exhaust pipe - front section.
3. Open the clamps and disconnect the two engine coolant delivery and return pipes in the heater. N.B. recover the fluid.




NOTE: The two pipes are distinguished by only one notch (A) and two notches (B) so that it is impossible to invert them.

1. Lower the belt tensioner guide pulley slackening it slightly.
2. Remove the belt.



1. Working in the engine compartment disconnect the electrical connection of the compressor.
2. Disconnect the two pipes from the compressor.




Continue with the removal procedure following the instructions given - for on-vehicle operations - in the corresponding Group of manual "155 - INSTRUCTIONS FOR REPAIR" - PA465300000000 - (pages with publication no. PA4653D1000000).

COMPRESSOR


Removal

- Disconnect the battery negative terminal.
- Drain the coolant fluid.
- 1. With the car on the lift remove the right front wheel.
- 2. Using the special tool No. 1.823.015.000 remove the plastic buttons fastening the partition between the wheelhouse and the engine compartment.
- 3. Remove the partition.





1. Slacken the four fastening screws and remove the compressor, withdrawing from above.

**Refitting**

Tension the belt (see GROUP 00).


Lubricate the fittings with the specified oil.

Tighten to the specified torque where applicable.


NOTE: The spare compressor is supplied pressurised with nitrogen to prevent the entry of moisture and impurities; therefore when assembling it is necessary to remove the inlet and outlet fitting plugs slowly and with the compressor strictly positioned as illustrated below (with the cover facing upwards).

CONDENSER**Removal**

- Drain the coolant fluid;
 - Set the car on the lift.
 - Remove the front bumper (see GROUP 75).
1. Disconnect the coolant fluid pipe leading to the compressor
 2. Disconnect the pipe leading to the evaporator.



1. Slacken the fastening screws and remove the condenser withdrawing it from below.


**Refitting**

Take care not to damage the thermal fins of the condenser.

Lubricate the fittings with the specified oil and tighten them to the specified torque.

**DRIER FILTER****Removal**


- Drain the coolant fluid.
 - Set the car on the lift.
1. Disconnect the pipe leading from the compressor.
 2. Disconnect the pipe leading from the evaporator.
 3. Slacken the fastening clamp.
 4. Remove the filter.

**Refitting**

Lubricate the fittings with the specified oil. Tighten the fittings to the specified torque.

EXPANSION VALVE**Removal**


- Drain the coolant fluid.
 - Set the car on the lift.
 - Remove the front bumper (see GROUP 75).
1. Slacken the connection nut and gain access to the valve.
 2. Withdraw the valve using a pincer and taking care not to damage it.

**Refitting**

Lubricate the fittings with the specified oil. Tighten to the specified torque.

THREE-LEVEL PRESSURE SWITCH**Removal and Refitting**

- Disconnect the battery negative terminal.
- 1. Disconnect the pressure switch connector.
- 2. Using a suitable wrench remove the pressure switch.




NOTE: Due to the presence of a check valve, the pressure switch can be removed without having to drain the coolant fluid, like all the other components of the air-conditioning system.



ANTIFROST PRESSURE SWITCH

Removal and Refitting

- Disconnect the battery negative terminal.
 - Set the car on the lift.
 - Remove the front bumper (see GROUP 70).
1. Disconnect the pressure switch connector.
 2. Slacken the pressure switch and remove it.




NOTE: Due to the presence of a check valve, the pressure switch can be removed without having to drain the coolant fluid, like all the other components of the air-conditioning system.



SYSTEM EMPTYING AND RECHARGING OPERATIONS

N.B. Only use the special emptying and recharging station for R134a fluid no. 1.826.004.000.




For the following operations:

- Emptying the system and recovering the coolant fluid;
 - Recharging the coolant fluid;
 - Topping up the compressor oil level;
 - Flushing the system,
- follow the instructions given in the corresponding group of the manual "155 - INSTRUCTIONS FOR REPAIR" - PA4653D1000000).
- For the engine in question also observe the following instructions:

REPLACING THE COMPRESSOR OIL

- Remove the compressor (see specific paragraph);
- Remove the oil separator device (A) fastened next to the outlet union of the compressor and drain all the oil contained in the compressor.

- Fill with new oil of the type and in the quantity given in "TECHNICAL CHARACTERISTICS AND SPECIFICATIONS".
- Refit the compressor on the car and proceed with system recharging operations.



REPLACING THE DRIER FILTER

In production (and also as spare) the drier filter is supplied with a certain quantity of oil.

NOTE: this filter is easily distinguished by a label with the wording "CONTAINS 130 C.C. OF NIPPONDENSO N.D.9 OIL".

- Drain the R134a fluid from the conditioning system.
- Remove the filter (see specific paragraph).
- Drain the oil from the filter just removed, recovering it in a special recipient.
- Carry out the same operation for the new filter.
- In the new filter pour the same amount of oil as removed from the old filter (eliminate or add accordingly).
- Refit the filter on the car and proceed with system recharging operations.

RECHARGING OPERATIONS

1. Connect the R134a recharging station to the car.

2. Connect the R134a recharging station to the car.

3. Connect the R134a recharging station to the car.

4. Connect the R134a recharging station to the car.

5. Connect the R134a recharging station to the car.

6. Connect the R134a recharging station to the car.

7. Connect the R134a recharging station to the car.

8. Connect the R134a recharging station to the car.

9. Connect the R134a recharging station to the car.

10. Connect the R134a recharging station to the car.



TECHNICAL CHARACTERISTICS AND SPECIFICATIONS

MINIMUM PRESSURE SWITCH SETTING

Contact opening pressure	1.7 ± 0.02 bar
Contact closing pressure	3.4 ± 0.5 bar

THREE-LEVEL PRESSURE SWITCH (TRINARY) SETTING

1. Level	contact opens	2.45 ± 0.25 bar
	contact closes	2.60 ± 0.34 bar
2. Level	contact opens	15.2 ± 0.98 bar
	contact closes	11.28 ± 1.99 bar
3. Level	contact opens	25 ± 30 bar
	contact closes	17 ± 26 bar

EXPANSION VALVE

Diameter of calibrated hole	Brown mesh	1.55 mm
	White mesh	1.8 mm

COMPRESSOR

Brand	NIPPONDENSO	
Type	TV 14SC	
Number of blades	2	
Length of blades	72.5 mm	
Depth of blades	38.5 mm	
Cylinder displacement	127 cm ³ /turn	
Weight	4.05 kg	
Quantity of oil (type ND9)	160 ± 20 cm ³	
Operating voltage of electromagnetic joint	12V	
Minimum current absorbed by electromagnetic joint	2.2A	
Power absorbed by electromagnetic joint	min. 40W	



FLUIDS AND LUBRICANTS

TYPE	APPLICATION	QUANTITY	NAME
OIL	Oil for filling the compressor and lubricating system pipe fittings	290 ± 30 cm ³ (1)	NIPPONDENSO ND-9
FLUID	Filling conditioner system circuit	0.7 ± 0.05 kg (2)	RIVOIRA: SUVA R134a HOECHST - TAZZETTI: FRIGEN R134a ICI - TAZZETTI: KLEA R134a

(1) In the event of replacing components:

- the compressor is supplied with 160 ± 20 cm³ of oil.
- the drier filter is supplied with 130 ± 10 cm³ of oil.

(2) added quantity to be calculated taking account of the fluid remaining in the pipes of the recharging equipment.

TIGHTENING TORQUES

Part	Nm	kgm
Union fastening the evaporator/drier filter pipe on the evaporator	40 ± 44	4.1 ± 4.5
Union fastening the evaporator/drier filter pipe on the drier filter	40 ± 44	4.1 ± 4.5
Union fastening the drier filter/compressor pipe on the drier filter	40 ± 44	4.1 ± 4.5
Union fastening the condenser/evaporator pipe on the evaporator	17 ± 19	1.7 ± 1.9
Intermediate pipe union on which the expansion valve is installed	17 ± 19	1.7 ± 1.9
Trinary pressure switch fastening	7.5 ± 8.5	0.8 ± 0.9
Minimum pressure switch fastening	7.5 ± 8.5	0.8 ± 0.9

SPECIAL TOOLS

TOOL NUMBER	DESCRIPTION
1.822.111.000	Socket wrench for Freon pipe fittings
1.822.112.000	Polygon claw wrench for Freon pipe fittings
1.822.113.000	Square wrench for Freon pipe fittings
1.822.115.000	Toothed wrench for Freon pipe fittings
1.823.015.000	Puller tool for plastic buttons
1.826.004.000	Emptying and recharging station for R134a

GENERAL INDEX

This manual *155 T.SPARK 16v - REPAIR MANUAL - ELECTRICAL-ELECTRONIC DIAGNOSIS* has been divided into sections each of which deals with a subject inherent to an installation, electrical or electronic system present on the vehicle. The first sections are of a general nature and show the supply to the various systems and installations. This is followed by the sections relevant to the external and internal illumination and then those of the various accessory systems (windscreen wipers, door locks, power windows etc.).

The sections relative to the more complex systems (conditioner etc.) and to the engine and vehicle control systems (electronic ignition/injection, ABS etc.) are to be found towards the end of the manual.

The sections are divided and numbered thus:

INTRODUCTION	Section 1
POWER SUPPLY	Section 2
FUSEBOX	Section 3
LOCATION OF GROUNDS	Section 4
SIDELIGHTS	Section 5
MAIN AND DIPPED BEAM HEADLIGHTS	Section 6
ADJUSTING HEADLIGHT ALIGNMENT	Section 7
REAR AND FRONT FOG-LAMPS	Section 8
DIRECTION INDICATORS AND HAZARD WARNING LIGHTS	Section 9
STOP-LIGHTS	Section 10
REVERSING LIGHTS	Section 11
INTERIOR LIGHTING	Section 12
INSTRUMENT PANEL	Section 13
CHECK PANEL	Section 14
RADIO SYSTEM	Section 15
CIGAR LIGHTER	Section 16
HORNS	Section 17
WINDSCREEN WASHERSWIPERS - HEADLIGHT WASHERS	Section 18
HEATED REAR WINDOW - HEATED ADJUSTABLE REAR-VIEW MIRRORS	Section 19
BOOT RELEASE CONTROL	Section 20
DOOR LOCKING SYSTEM	Section 21
ANTI-THEFT DEVICE	Section 21A
FRONT POWER WINDOWS	Section 22
REAR POWER WINDOWS	Section 23
ADJUSTABLE HEATED SEATING	Section 24
SUNROOF	Section 25
HEATING-VENTILATION AND AIR CONDITIONING	Section 26
STARTING AND CHARGING	Section 27
ENGINE COOLING	Section 28
ALFA ROMEO CODE	Section 29A
CONTROL SYSTEM BOSCH MOTRONIC M2.10.3 Models 2.0 T.SPARK 16V (Version '95)	Section 29B
CONTROL SYSTEM BOSCH MOTRONIC M2.10.4 Models 1.6 - 1.8 - 2.0 T.SPARK 16V (Version '96)	Section 29C
ABS SYSTEM	Section 30

ALPHABETICAL INDEX

Section		Section	
ABS	30	Electronic ignition	29
ABS SYSTEM	30	Electronic injection	29B-29C
ADJUSTABLE HEATED SEATING	24	ENGINE COOLING (models with air conditioner)	26B
ADJUSTING HEADLIGHT ALIGNMENT	6	ENGINE COOLING (models without air conditioner)	28
Adjustment of rear-view mirrors	19	Engine electric fan (models with air conditioner)	26
Air recirculation	26	Engine electric fan (models without air conditioner)	28
Air vent actuators	26	Engine electric fan control (models with air conditioner)	26
ALFA ROMEO CODE	29A	Engine oil indicators	13
Alternator	27	Front fog-lights	7
ANTI-THEFT	21A	FRONT POWER WINDOWS	22
Anti-theft device	21A	FUSEBOX	2
Ashtray light	16	Fuses and relays on auxiliary bracket	2
Automatic air conditioner	26	General precautions	Introduction
Automatic heater	26	Glove compartment light	20
Automatic heating-ventilation with air conditioner	26	Grounds	3
Battery	27	Hazard warning lights	8
Battery recharging	27	Headlight alignment	6
Brake release	20	Headlight washers	18
ROOT RELEASE CONTROL	20	HEATED REAR WINDOW - ADJUSTABLE HEATED REAR-VIEW MIRRORS	19
Braking system warning lamps	13	Heater	26
Check of basic electrical components	Introduction	HEATING-VENTILATION AND AIR CONDITIONING	26
Check of basic electrical lines	Introduction	HORNS	17
CHECK PANEL	14	Identification of cables	Introduction
Check Panel supply	14	INSTRUMENT PANEL	13
CIGAR LIGHTER	16	Instrument panel lighting	12
Clock	14	Instrument panel supply	13
Colour of cables	Introduction	Instrument panel warning lamps	13
Compressor control (air conditioner)	26	INTERIOR LIGHTING	12
Control lighting and ideograms	12	Interior lighting	12
Dipped-beam headlights	5	Internal electric fan	26
DIRECTION INDICATORS AND HAZARD WARNING LIGHTS	8	INTRODUCTION	Introduction
DOOR LOCKING SYSTEM	21	Layout of the manual	Introduction
Door mirror defroster	19		
Door open signal	14		

Section		Section	
Stoplights check	14	Temperature sensors	26
SUNROOF	25	Various Indicators	13
Supply	1	WINDSCREEN WASHERS/WIPERS - HEADLIGHT WASHERS	18
		Windscreen washer	18
		Windscreen wipers	18

Section		Section
Level check	14	
Lights	12	
LOCATION OF GROUNDS	3	
MAIN AND-DIPPED BEAM HEADLIGHTS	5	
Main-beam headlights	5	
Manually controlled heater	26	
Mirrors	19	
MOTRONIC M2.10.3 IGNITION AND INJECTION SYSTEM (Models 2.0 T.SPARK 16V (Version '95))	29B	
MOTRONIC M2.10.4 IGNITION AND INJECTION SYSTEM (Models 1.6 - 1.8 - 2.0 T.SPARK 16V (Version '96))	29C	
Motronic system	29B-29C	
Numberplate lights	4	
Numberplate lights check	14	
POWER SUPPLY	1	
Radio	15	
RADIO SYSTEM	15	
REAR AND FRONT FOG-LAMPS	7	
Rear foglamps check	14	
Rear foglights	7	
REAR POWER WINDOWS	23	
Rear-view mirrors	19	
Remote control (anti-theft)	21A	
Rev counter	13	
REVERSING LIGHTS	10	
Roof lights	12	
Safety regulations	Introduction	
Seat warming	24	
SIDELIGHTS	4	
Sidelights check	14	
Speedometer	13	
Starter motor	27	
STARTING AND CHARGING	27	
STOPLIGHTS	9	

INTRODUCTION

INDEX

STRUCTURE OF THE MANUAL	II
WIRING DIAGRAMS	IV
DESCRIPTION	VII
LOCATION OF COMPONENTS	VII
FAULT FINDING	VII
FAULT-FINDING BY SELF-DIAGNOSIS	VII
COMPONENTS AND CONNECTORS	VIII
ELEMENTARY CHECKS FOR ELECTRICAL LINES AND COMPONENTS	VIII
LINE CHECKS:	IX
TESTING COMPONENTS:	X
GENERAL PRECAUTIONS AND SAFETY MEASURES	XIII

This Group "ELECTRIC SYSTEM DIAGNOSIS" contains all the necessary information regarding the electric and electronic systems and circuits on these models.

All the instruments which are useful in finding faults and failures that might occur in the above-mentioned systems are given particular attention.

Each circuit is dealt with separately in a specific section in which the following can be found:

- operation and description of the circuit,
- wiring diagram;


- locating the main components;
- table for locating the more frequent faults with relative test procedures for the components.

STRUCTURE OF THE MANUAL

This manual is subdivided into sections, each dealing with and analyzing a single circuit. All the sections are identical in layout and comprise 5 parts:

- A wiring diagram;

- B general description (description of the circuit and its operation) and functional description (analytical illustration of the wiring system); Sometimes the general description is extensive and detailed, as important service information is given; in this case it precedes the wiring diagram to introduce the subject.



12-3
INTERNAL LIGHTING

FUNCTIONAL DESCRIPTION

The instrument cluster is illuminated by the instrument cluster lighting. The instrument cluster lighting is controlled by the instrument cluster lighting switch. The instrument cluster lighting is controlled by the instrument cluster lighting switch. The instrument cluster lighting is controlled by the instrument cluster lighting switch.


Wiring Diagram

Diagram showing electrical connections for internal lighting, including a fuse, switches, and lamp sockets.

- C location of the components on the car;
- D trouble-shooting including "finding tables", "checking components" and tests;

- At the end of each section the following are given:

- tables of components and connectors, illustrated one by one completely (in alphabetical order);



12-8
FAULT-FINDING TABLE

Code	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	
Instrument cluster																					
Instrument cluster lighting																					
Instrument cluster lighting switch																					
Instrument cluster lighting fuse																					
Instrument cluster lighting switch fuse																					
Instrument cluster lighting fuse																					
Instrument cluster lighting switch fuse																					
Instrument cluster lighting fuse																					
Instrument cluster lighting switch fuse																					

CHECKING COMPONENTS

Checking fuse (12-8)

12-9
EXTERNAL LIGHTING

Code	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	
Instrument cluster																					
Instrument cluster lighting																					
Instrument cluster lighting switch																					
Instrument cluster lighting fuse																					
Instrument cluster lighting switch fuse																					
Instrument cluster lighting fuse																					
Instrument cluster lighting switch fuse																					
Instrument cluster lighting fuse																					
Instrument cluster lighting switch fuse																					

12-10
CHECKING COMPONENTS

Diagrams showing how to check various components, including fuses, switches, and lamps.

WIRING DIAGRAMS

The wiring diagrams are made following the operation of the circuit in order to make it easier to understand them, therefore quicker to identify a fault.

The lay-out follows the "flow" of the current and signals, starting from the power source (always placed higher up) passing the components and reaching the earths located lower down.

The power supply is represented schematically with different symbols which vary depending on the position of the key in the ignition:



— line under constant supply (directly connected to the battery)



— line supplied when the ignition key is turned to "RUN" (first position of the key)



— line supplied when the key is turned to "STARTING" (second position of the key which is disengaged when the key is released)



— line supplied when the key is either in the "RUN" or "STARTING" position.



— line supplied when the key is in the "PARKING" position (key turned in the opposite direction and withdrawn after pressing the special button).

A special section ("Power Supply") deals in detail with the power supply to all the lines and operation of the ignition switch.

The fusebox is not represented wholly in the single diagrams and only the components useful to the diagram under examination are given. A complete description of the whole fusebox is given in the specific section ("Fusebox").


All the components and connectors are represented in the diagrams by an alphanumeric code (eg. A10). The initial let-

ter of this code represents the type of component:

- A STARTING - RECHARGING
- B MANUAL ELECTRICAL CONTROLS
- C INSTRUMENTATION
- D WARNING LIGHTS
- E EXTERIOR LIGHTS
- F INTERIOR LIGHTS
- G FUSEBOXES - CONNECTORS - EARTHS
- H SWITCHES
- I RELAYS
- L SENDERS
- M ELECTROMAGNETS - SOLENOID VALVES
- N ELECTRONIC DEVICES - INTRUMENTS - TIMERS
- O SERVICES
- P ELECTRIC MOTORS
- Q HEATING/VENTILATION - AIR CONDITIONING
- R SAFETY DEVICES
- S ELECTRONIC INJECTION
- T DIAGNOSIS


A complete key is given at the end of all the wiring diagrams.

The names of the components are given in the charts and the codes are circled, but, for reasons of space, the codes for simple connectors (connections) are only underlined.



The components are always shown in their rest position; eg. the N.C. (normally closed) contacts are shown closed, the relays deactivated, etc.

The outline of a component is hatched to indicate that in the chart in question only part of it is shown; for example, the fusebox, due to the reasons mentioned above, will always be shown hatched. Wherever necessary, arrows indicate references to other relevant diagrams.



The earth lines only show the earth point (located in the lower part of the diagram) to which they are connected and not the other lines connected to it. A special section "Location of Earths" gives all the lines converging on each earthing point.

NOTE: these crossed references between the lines and on the earths make it possible to easily identify the faults in the event of failures in more than one circuit at the same time: for example, a faulty earth point will cause a failure to all the circuits which converge on it.

NOTE: The versions with a smaller number of accessories might not have all the solderings to be found in the wirings of the complete versions.

ELECTRICAL COMPONENTS

The electrical components are represented in the diagrams by the most frequently used and best-known international symbols.

The following table lists these symbols as they are shown in the diagrams:

SYMBOL	COMPONENT SYMBOLOGY	NAME
	Connector	Connector
	Earth point	Earth point
	Ultrasound solder	Ultrasound solder
	Fuse	Fuse
	Bulb	Bulb
	Led	Led
	Battery	Battery
	Branch point	Branch point
	Solenoid	Solenoid

CABLE IDENTIFICATION

Each cable shown in the diagrams is characterised by a code formed by numbers and letters: the numbers indicate the cable diameter in sq.mm (0.5 where not stated), while the letters indicate the colour according to the table given below:

CABLE IDENTIFICATION TABLE

COLOUR	IDENTIFICATION LETTER
Black	BLK
White	WHT
Light blue	LTB
Brown	BRN
Yellow	YEL
Red	RED
Green	GRN
Grey	GRY
Pink	PNK
Orange	ORN
Purple	PPL
Blue	BLU

NOTE: for combinations the colours are simply coupled:

Light blue-white	LTB-WHT
Green-black	GRN-BLK
Blue-Red	BLU-RED

Each of the above-mentioned tests is identified by a letter.

The tests are described in three column tables with the following arrangement:

1st column: "TEST PROCEDURE": this column indicates the "steps" to be carried out to check the circuit and locate the fault in question.

2nd column: "RESULT": this column indicates the two possible outcomes of the tests carried out: "OK" or "NOT OK" which indicate the remedy to be followed.

3rd column: "CORRECTIVE ACTION":


depending on the outcome of the tests, this column gives the possible remedies which may be used to restore the correct operation of the vehicle: for example, changing a component etc., or reference to the next step to be carried out towards localizing the fault.

All the operations and checks listed can be carried out with a simple multimeter, as shown below.

FAULT-FINDING BY SELF-DIAGNOSIS

Some of the electronic systems installed on the car possess a self-diagnosis function.

Fault finding on these systems can be carried out quickly and effectively using the ALFA ROMEO TESTER after inserting the suitable cartridge for the system concerned



DESCRIPTION

The first part (general description) describes the purpose of the circuit or system under examination and shows how it works: this is a condition which is necessary for each subsequent operation check and for any trouble-shooting found to be necessary.

The second part (functional description) shows the wiring diagram analytically, following the "flow" of the supply signals towards earth from the upper section downwards.

The components are identified by the same alphanumeric codes used in the diagrams (and in the key at the end of this publication).

A brief description is also given of the components which need to be outlined from an electrical point of view (eg. relays, contacts, fuses, connectors,...) in order to be able to check their functioning during the subsequent fault diagnosis tests.

LOCATION OF COMPONENTS

Schematic diagrams representing the silhouette of the car makes it easy to find the various components of the circuit under examination and to locate, where necessary, the routing of the cables fastened to the body of the vehicle itself.

FAULT FINDING

The descriptive section is followed by the "FAULT-FINDING TABLE" which lists the possible (and most frequent) faults which can affect the circuit in question: for each of these, the possible components involved are listed: the components are listed in the order of likelihood of a fault (for example first the fuses) or the ease with which access may be gained to them. In the

example below, the fault affecting function X involves components 1 and 5, that of Y involves components 2, 3 and 4.

Failure	Component				
	1	2	3	4	5
X
Y

N.B. All the fault finding procedures given in this publication begin from the hypothesis that there is ONLY ONE FAULT in the system. In the very unlikely event of simultaneous faults it will be necessary to combine more than one procedure.

If more than one circuit or system are out of order at the same time, there are at least two situations that can be easily recognized: the failure of a fuse protecting different lines (for this refer to the section "Fuseboxes") or a fault in an earth point on which different lines converge (for this, refer to the section "Location of Earths"). After the faultfinding table the list of COMPONENT CHECKS is given: this lists the characteristics and technical data needed to quickly check the operation of components that are not considered elementary (eg. bulbs, switches, fuses, etc.).

If the checking operation is complex, it is described in detail in a FAULT FINDING TEST to be found at the end of the section.

N.B.

If the fault persists when the single components and their connections have been checked, it is necessary to check the electrical continuity and for any short circuits or cut offs following the different lines concerned, referring to the wiring diagram at the beginning of each section.

COMPONENT SYMBOLOGY		
SYMBOL	NAME	NAME
	Electronic control unit	Switch/ contact
	Electronic device (eg. intermittence-timer)	Sensor/ sender
	Electric motor	Resistance
	Relay	Rheostat
	Relay with fuse	
	Relay with diode	
	Relay with double contact	

In this case, this manual only describes the preliminary checks to be carried out before connecting the Tester; special publications describe the use of the Tester and its different cartridges.

Where possible the data are given for checking the single components.


Some of these systems also give another possibility of diagnosis through a FLASHING CODE which indicates the failures recorded in the system control unit; in these cases all the tests to be carried out according to the failures recorded are described.

COMPONENTS AND CONNECTORS

A table lists all the components and connectors used in the wiring diagram of the section. Both parts ("male" and "female") are shown for the intermediate connectors.

Alongside the schematic diagram of the component the cables indicated in the corresponding wiring diagram are shown, indicating the cross-section, colour and the component to which this cable is connected.

N.B. In certain cases unconnected or spare cables will be shown.




N.B. The connectors are seen from the cable inlet side; only the electronic control units with combs with a high number of pins are shown from the connection side between combs and control unit.



In order to locate last voltage changes, for example the control voltage at the terminals of the door lock gear motors, the use of a polarity detector is recommended.

The polarity indicator shows if there is a difference in potential between the prod and the terminal, regardless of its value and polarity.

This is signalled by the turning on of a telltale, for example a green one if the terminal is connected to earth and the pushbutton to a positive, while for example the red telltale lights up if the terminal is connected to the positive and the prod is connected to earth.



LINE CHECKS:

MEASURING ELECTRICAL CONTINUITY:

NOTE: first of all ensure that the supply to the component in question is disconnected! This applies to all resistance measurements.

Set the millimeter to measure ohms and set it to read 0 Ω when the two prods of the instrument are touched together.


Place the two prods of the instrument at the ends of the component or cable being examined and read the resistance: 0 Ω means electrical continuity in a cable, fuse, etc.; ∞ (infinite) means a cut off.

For certain components, such as resistances, sensors, electric motors, etc., a specific value should be read corresponding to the impedance of the component itself.

MEASURING VOLTAGE:
NOTE: before taking any readings, ensure that the component or line being examined is connected to the power supply as shown in the wiring diagram.

Connect the negative prod of the multimeter to earth (for example the battery earth).

Connect the positive prod to the point to be measured and take the reading selecting the appropriate scale. If the exact voltage at various points along a line or circuit is known, the affected part can be quickly located.



CHECKING FOR A SHORT CIRCUIT:


using the voltmeter:

NOTE: before taking any readings, ensure that the component or line being examined is connected to the power supply as shown in the wiring diagram

Set the multimeter to measure volts. Remove the fuse of the circuit concerned (which will be burnt out) and disconnect the charge.

Connect the prods of the multimeter to the fuse terminals: the positive prod should be connected to the part nearest the power source.

If the voltmeter gives a reading indicating that voltage is present, part of the circuit will be short circuited to earth (in a red, worn, pinched wire, etc.); the part concerned can be located by moving the wire to find a point in which the reading is not 0 V.



NOTE: measurements taken with a voltmeter are more accurate and if both options are possible the voltmeter should be chosen.

MEASURING CURRENT

It may sometimes be necessary to measure the current absorption; in this case the multimeter will not suffice. It is therefore necessary to use another instrument such as a snap on ammeter, operating as follows:

- Insert the lead of which the current is to be measured in the pincers, suitably connected to the multimeter set for volt measurement (mV);
- **NOTE:** ensure that the flow of current (from positive towards earth) is the same as indicated on the pincers;
- take a reading in mV which corresponds to the value of the current in A.

HALOGEN BULBS:

Halogen lamps have the bulb made of quartz instead of glass: due to the high temperature reached when the bulb is working, the presence of grease on the bulb surface causes "deveritrication" of the quartz, thereby lowering its luminosity. Therefore, halogen bulbs must be handled by the metal collar taking care not to touch the bulb with the hands: should this occur, carefully clean the bulb with ethane or an equivalent degreasing product.

FUSES:

A fuse is an electrical conductor the cross section of which is such that if the load passing through the cable exceeds a certain value called fuse amperage, it will blow and interrupt the circuit. If it is not possible to see visibly whether the fuse filament is intact or not, it can be checked by connecting the prods of the multimeter set to measure ohms to its terminals: a 0 value (0 Ω) means that the fuse is still working, whereas a resistance of ∞ (infinite) means that the filament has "blown".

CAUTION!

Before changing a fuse the cause of the damage to it should be eliminated. If the fuse supplies more than one circuit, it might have blown due to a failure on a different circuit than the one suspected.




TABLE OF FUSE COLOURS

Standard fuses (for example those of fusebox G1) are identified according to a colour correlated with the amp rating:

AMP.	COLOUR
7.5 A	Brown
10 A	Red
15 A	Light blue
20 A	Yellow
25 A	White
30 A	Green



The wandler "maxifuses" are distinguished according to their colour:

AMP.	COLOUR
40 A	Orange
50 A	Red
60 A	Light blue
70 A	Yellow




RELAYS:

In its simplest form, a relay is composed of a coil and a contact: when "excitation" or "drive" voltage is applied to the ends of the coil, the contact closes. Normally the coil terminals are identified as pin 85 and 86, while the contact terminals are pin 30 (from the power supply) and pin 87 towards the load. There may also be two output pins towards the load: 87 and 87a when the contact closes simultaneously on both; 87 and 87b when it closes separately. The contact can also be a switch and close itself on one pin (87a) at the same time as opening the other (87).

(For the different types of relays refer to the previous table of component symbols).

To check a relay, connect pins 85 and 86 with a 12 V power source (the coil does not have a polarity and therefore the two pins are interchangeable) and measure with the multimeter set to read ohms: when the coil is "energized" (between the ends of the coil there will be a difference in voltage of -12 V -) the multimeter should read continuity (0 Ω)




NOTE: some relays have a built-in fuse: this must always be checked separately, before checking the relay. In other relays a resistance is placed in parallel to the excitation circuit, in others a diode protects the excitation; in all these cases, the method for checking the operation of the relay does not differ from the one given above.

THERMAL CONTACTS:

Thermal contacts change their state (circuit open or closed) when a certain temperature is reached. **NOTE:** they can be N.C. (normally closed) or N.O. (normally open); in the diagrams they are shown in their rest position.

To check a thermal contact, remove it from the car and connect the terminals to a multimeter set to measure ohms. Using suitable equipment (containers

which can be heated and cooled) check that at the pre-established temperature for each thermal contact, the resistance passes from 0 Ω to ∞ or vice-versa.



SENSORS:

These are components of varying types, but in general they are similar to contacts (N.O. or N.C.) which change their state when a certain measured physical value changes (for example temperature, see thermal contacts, or pressure etc.). For these components the same rules apply as for checking thermal contacts.

Other sensors measure specific values and emit a signal which is proportional to them: as each occasion arises, these will be given in the table load diagram, through which it will be possible to locate the correct resistance or voltage ratings and check them using a multimeter.


RHEOSTATS:

Rheostats are variable resistances: when voltage (12 V) is applied to the main terminals, the output signal from the third terminal is changed by a mechanical action (eg. rotating an adjustment washer...)

To check correct operation connect one end of a multimeter set to measure ohms to one of the main terminals and the other to the third terminal: by acting on the adjustment washer for example, the resistance measured should change noticeably

TERMOSTATS/PRESSURE SWITCHES:

These are instruments which emit a signal which is directly proportional to the temperature/pressure they measure.




From a schematic electrical point of view they are rheostats of which the resistance varies with the readings taken.

To check these devices therefore, follow the indications given for rheostats using suitable equipment to enable the temperature or pressure to be changed.

ELECTRIC MOTORS/SOLENOIDS:

Electric motors and solenoids are mechanisms which are essentially composed of electrical windings and for this reason checking the operation of these components consists in verifying if electrical continuity has reached the windings or not; then proceed as mentioned above using the multimeter.

It is also possible to check a component when it is installed on the vehicle: disconnect it and check the operation (for instance the rotation of the motor) connecting the terminals to a 12 V power source.



N.B. Inverting the polarity (positive and earth) of an electric motor inverts its direction of rotation; therefore, particular attention must be paid that the two terminals are connected correctly, using for example a polarity detector.

NOTE: for these mechanisms it is possible for faults to be caused by mechanical and not electric problems. In this case the other groups of the manual should be consulted.

EARTH POINTS:

An earth point is not correctly connected if oxidation is present, if it is not securely fastened to the body or if the cables reaching it are bare or damaged.

To check whether an earth point is really at "0 potential", connect it to the prod of a multimeter set to measure ohms; connecting the other prod to the battery negative pole the resistance reading should be = 0 Ω; if this is not the case, carefully inspect the earth as it is faulty.

SOLDERS:

Numerous solders between wires are present on the vehicle: they are carried out using the ultrasonic technique which makes them extremely reliable and safe.

If it becomes necessary to check a solder, simply check the continuity between the different wires which converge on it: if this proves unsuccessful the solder cannot be repaired and the wiring must be replaced.

CONTROL UNITS AND ELECTRONIC DEVICES IN GENERAL:

Nowadays, electronic control units are the most important components of the car. Because of this reason, they are almost 100% reliable as their protection circuits have been designed especially for this purpose.

Because of their complexity, electronic control units require special diagnosis

devices as the use of the multimeter is neither sufficient nor advisable.

Generally, the control units are provided with a special diagnosis socket for connection to the ALFA ROMEO TESTER.

These components cannot be dealt with in a general context, therefore reference should be made to the single fault-finding procedures in the specific sections. You are however reminded that it is not possible to work on these electronic components internally and they have to be replaced if found to be faulty.

GENERAL PRECAUTIONS AND SAFETY MEASURES

Before carrying out any work on the electrical components, carefully follow the precautions given below:

- Remove rings, wrist-watches or other metal objects.

- Disconnect one of the battery terminals each time an electrical component has to be removed.

- Only use original Alfa Romeo spare parts when a component needs replacing.

When working on the electric system of a car never forcibly pull wires or cables, as this might accidentally disconnect them from connectors or terminals.

Disconnect all the control units and electronic devices when arc welding on the vehicle body.

AVOIDING ELECTRICAL ARCHING

Even if the voltage of the electric system is only 12 V, the power of the battery can cause high voltage in the event of a short circuit causing arches or sparks that can cause a fire hazard or direct danger to the operator.

BEWARE OF HIGH VOLTAGE
The electronic ignition system generates voltages of 20.000 V and over which could be very dangerous, especially to people suffering from heart problems.
Therefore, always proceed with the utmost care when operating on or near these components.

AVOIDING FIRES

Do not smoke while working near the battery or components containing fuel or other engine fluids.

HEAT SOURCES

When it is necessary to operate on components which are subject to heating during use (eg. halogen bulbs), or inside the engine compartment when the engine is still warm, particular care must be taken to avoid burns or damage to tools or components.

POWER SUPPLY

INDEX

WIRING DIAGRAM	1-2
GENERAL DESCRIPTION	1-3
FUNCTIONAL DESCRIPTION	1-4
LOCATION OF COMPONENTS	1-5

FUNCTIONAL DESCRIPTION

The supply leading from the battery A1 is divided among various lines in the branch terminal board G56, from where numerous cables lead, directly supplying some systems (protected by special "wander" fuses) and the line that supplies the fusebox G1 inside the fusebox the power is distributed to the various circuits, protected by the corresponding fuses.

The battery recharging line leads from the alternator A3, through the starter motor A11.

The ignition switch B1 is also supplied via the terminal board G56 and fuse G384 (50A) at pin B of connector B.


The line that leaves pin A of connector B corresponds to the "STARTING" position and it supplies the starter motor A11, either directly or through the alarm control unit.

The two lines leaving pin 3 of connector A - "RUN" position - via the fusebox G1, supply the "key-operated" circuits, which are however disengaged in the "STARTING" position.

The three lines that leave pin 1 of connector A and pin C of connector B supply, either directly or through the fusebox G1, (relay R35) the "key-operated" circuits which also remain engaged in the "STARTING" position.

Lastly, the line that leaves pin 2 of connector A corresponds to the "PARKING" position and supplies the sidelights circuit inside the fusebox G1.

LOCATION OF COMPONENTS



FUSEBOX

INDEX


WIRING DIAGRAM 2-2

GENERAL DESCRIPTION 2-3

LOCATION OF FUSES AND RELAYS 2-10

REAR VIEW, CONNECTOR SIDE 2-10


FUSES AND RELAYS ON AUXILIARY BRACKET 2-12



WIRING DIAGRAM

FUSEBOX

WIRING DIAGRAM





GENERAL DESCRIPTION





The fusebox houses a number of relays and other devices, shown here with the corresponding codes, and the fuses (F1.....F19).



This section describes the complete printed circuit that makes the connections inside the fusebox G1. In the various diagrams referring to the individual systems and circuits only the lines associated with the case under examination are shown: this chart gives a complete, overall view of the entire fusebox G1.

NOTE: not all the output pins of the box G1 are actually connected for all versions of the car: some lines therefore may be found to be redundant though they will be present on the printed circuit. Next to the schematic drawings of the connectors a list of output signals from the different pins is given: this simplifies for instance faultfinding work on the different circuits affected.



NOTE: the letters N.C. indicate pins connected inside the fusebox but not used for the present versions of the car).













(*) Versions with manual LH front power window control
 (**) Versions with automatic LH front power window control




(*) Versions with automatic LH front power window control



The following diagram shows the location of the fuses and relays and the position of the connectors:

LOCATION OF FUSES AND RELAYS




- Relays
- 12 Heated rear screen relay
 - 13 Horn relay
 - 117 Fog lamp relay
 - 125 Fog guard relay
 - 135 Key-operated supply relay
 - 149 Low beam relay
 - 150 High beam relay
 - 158 Sunroof relay
 - 164 Sidelights relay
 - 199 Engine water cooling fan 1st speed relay
 - N11 Door locking control unit
 - N13 Hazard warning and direction indicator intermit-
 - tence
 - N14 Electronic windscreen wiper intermittence

Fuses (see following page).

N59 Check Panel Control Unit

REAR VIEW, CONNECTOR SIDE



FUSES

The following list gives the fuses contained in fusebox G1, with the corresponding symbol, amp rating and type of supply and the protected circuits

FUSE		SYMBOL	AMP.	SUPPLY	SERVICES PROTECTED
N°	AMP.				
1	10A			Hazard warning lights	
2	25A			Horns, stop lights, radio, boot opening control	
3	20A			Windscreen wiper	
4	25A			Cigar lighter, ceiling lamps	
5	10A			Controls lighting, LH rear sidelights, RH no. plate light, RH front sidelight, sidelights warning light	
6	10A			Controls lighting, cluster lighting, RH rear sidelights, LH no. plate, LH front sidelight, headlamp aiming device	
7	10A			Right low beam	
8	10A			Left low beam	
9	15A			Right high beam	
10	15A			Left high beam, high beam warning light	
11	7.5A			Fog guard, fog guard warning light	
12	30A			Heated rear screen, heated rear screen warning light, mirror defroster	
13	30A			Fan, rear power windows, adjustable and heated seats, radio instrument cluster, windscreen-headlamp washer electric pump, reversing lights, glovebox light, check panel, engine fan, ALFA ROMEO CODE	
15	15A			Clock, ceiling lamps, conditioner control unit, alarm remote control	
16	10A			Sidelights, door mirror adjustment	
17	7.5A			Door locking device	
18	20A			Fog lamp, fog lamp warning light	
19	20A			Electric sunroof	
20	30A			Adjustable and heated seats	
21	30A			Left front power window (*)	
22	25A			Rear power windows	
23	25A				

(*): Versions with automatic LH front power window control

FUSES AND RELAYS ON AUXILIARY BRACKET

A set of fuses and relays is located on the auxiliary bracket (not removable) to the left of the main fusebox; next to these there are also the power window control unit N38 and that of the ALFA ROMEO CODE N77.

The fuses and relays can be distinguished according to the colour of the base (fuse holder or relay holder) which connects them to the wiring, according to the following table:

COMPONENT	CODE	BASE COLOUR
Boot opening relay (with 30A fuse)	I52	Red
Timer for headlamp washer	N12	Black
Climate control auxiliary relay	Q32	Grey
Compressor joint control relay	Q22	Grey
Engine cooling fan relay	11/N100	Black
Headlamp washer fuse (20A)	G312	Yellow
ABS fuse (10A) - NOT CONNECTED	G125a	Red
Front power window fuse (25A)	G310	White
LH front power window fuse (25A) (*)	G311	White
Climate control fuse (30A)	G255	Green
Conditioner system fuse (10A)	Q65	Red

(*) : Versions with manual LH front power window control

N.B. In addition to the colour of the base, it is wise to check the exact location of a relay or fuse by the colour of the wires which converge on it (for these, see the wiring diagram on the next pages).

LOCATION OF GROUNDS

INDEX

GENERAL DESCRIPTION 3-2

WIRING DIAGRAMS 3-2

LOCATION OF COMPONENTS 3-9

GENERAL DESCRIP-
TION


The following diagrams show the dif-
ferent earths present on the vehicle and
the connecting cables for each of them;
each cable shows the circuit to which it
refers, and the component earthed
through that line.

- G53a Right-hand engine compartment earth
- G53b Left-hand engine compartment earth
- G55b Left-hand side panel earth
- G60 Injection wiring earth
- G63a Right-hand rear earth
- G63b Left-hand rear earth
- G92 Earth for electric aerial
- g106 Earth under seat


- G148b Earth under left-hand dashboard
 - G381 Earth on gearbox
 - Q36 Conditioning system earth
- There is also an earth braid, which con-
nects the power unit to the body.
- NOTE: Using these diagrams it is easy
to locate those circuits which are con-
nected to earth by the same line. This
simplifies faultfinding work in the event
of problems affecting more than one
system.

WIRING DIAGRAMS

G53a



G53b




SIDELIGHTS

INDEX

WIRING DIAGRAM	4-2
GENERAL DESCRIPTION	4-3
FUNCTIONAL DESCRIPTION	4-3
TROUBLESHOOTING TABLE	4-3
LOCATION OF COMPONENTS	4-4

WIRING DIAGRAM



Only for versions with Check Panel

GENERAL DESCRIPTION

N.B. Two distinct wiring diagrams are given, one for the models equipped with the Check Panel and one for models without this device.

The sidelights are illuminated when the switch on the lever group is rotated to the first position, and only when the ignition key is engaged; this prevents the battery from being drained if the lights are inadvertently left on when the vehicle is left.

They can also be illuminated though, by slightly withdrawing the ignition key and rotating it in the opposite direction, and holding down the special button: key in the "PARKING" position (see also "Power Supply").

When the sidelights are illuminated, the numberplate lights and numerous interior lights for the illumination of the passenger compartment, instruments and controls are also illuminated (see "Interior Lighting").

A warning lamp on the instrument panel signals that the sidelights are on. For safety reasons the circuit is protected by two fuses employed in the

"crossed" system: one for the front right and rear left lights and the other for the front left and rear right lights.

The correct operation of the sidelights and numberplate lights is - for some versions - verified by the Check Panel device which signals any malfunction affecting these important circuits (see "Check Panel").

FUNCTIONAL DESCRIPTION

The sidelights circuit is activated by relay I64 located in fusebox G1. Moving the switch on the lever group B68 to position "I" when the ignition key is engaged, the coil of relay I64 is supplied and the circuit is closed which sends supply to the sidelights; this circuit is protected by two fuses in fusebox G1: F5 (10A) for the front right and rear left lights and F6 (10A) for the front left and rear right lights. In this way the front sidelights E23 (right) and E24 (left) are supplied along with the rear lights E25 (right) and E26 (left) and the numberplate lights E17.

The line supplying fuse F5 sends a sig-

nal to the instrument panel C10 to illuminate the relative warning lamp.

As the sidelights are controlled by the Check Panel device, signals (both direct and by "SH" shunt) are emitted from the circuit supplying the lights themselves and are received by the control unit N59 which can then check the line load (for greater detail see "Check Panel").

With the ignition key at the "PARKING" position, all the sidelights are illuminated as the fuses F5 and F6 in fusebox G1 are supplied directly, by-passing the relay I64.


NOTE: Selecting the sidelights supplies numerous other circuits with "consensus" signals (circuits which operate only when the sidelights are illuminated) or by supply lines in the real sense of the term (for example by illuminating the ideograms of the various buttons and controls...).

These lines are described and illustrated in the diagrams relative to the components to which they refer, or in the section "Interior Lighting".

TROUBLESHOOTING TABLE

Malfunction	Component to be checked										
	I64	B68	E5	E6	E23	E24	E25	E26	E17B	E17A	C10
All sidelights	•	•									
Front right			•		•						
Front left				•		•					
Rear right							•				
Rear left								•			
Right numberplate										•	
Left numberplate											•
Sidelights warning lamp											•

LOCATION OF COMPONENTS



MAIN AND DIPPED BEAM HEADLIGHTS

INDEX

WIRING DIAGRAM 5-2


GENERAL DESCRIPTION 5-3

FUNCTIONAL DESCRIPTION 5-3

TROUBLESHOOTING TABLE 5-3

LOCATION OF COMPONENTS 5-4

WIRING DIAGRAM



GENERAL DESCRIPTION

The vehicle is equipped with two lamps for the dipped beam and two for main-beam.

Dipped beam is selected by rotating the switch located on the lever group one position on from the sidelights position.

From this position the main-beam can be permanently selected by acting on the main/dipped beam switch; lightly pulling the lever activates the mainbeam "flashing" function which will continue to flash for as long as the lever is pulled.

A warning lamp on the dashboard signals the selection of the main-beam.

For safety reasons each light is protected by two fuses, one for the right-hand lamp and the other for the left.

NOTE: some versions are equipped with an electrically operated device which regulates the alignment of the headlights (see "Adjusting headlight alignment") however a manual device permits a rapid and simple adjustment of the beam to the loading conditions of the vehicle.

FUNCTIONAL DESCRIPTION

The circuit of the dipped beam headlights is activated by relay 149 located in fusebox G1.

Moving the lever group switch B68 to position II - one position on from the sidelights position - and with the switch at the dipped beam position, the coil of relay 149 is "turn key" supplied closing the circuit supplying the lamps E24 (left)

and E23 (right). Each circuit is protected by a fuse in box G1: F7 (10A) for the right-hand lamp and F10 (10A) for the left.

The main-beam circuit is activated by relay 150 located in fusebox G1.

Moving the switch to the main-beam position, with the switch on the lever group to position II, or by closing the "flashing" contact, the coil of relay 150 is "turn key" supplied and closes the circuit which supplies the lamps E24 (left) and E23 (right). Each circuit is protected by a fuse in fusebox G1: F9 (15A) for the right-hand lamp and F10 (15A) for the left.

The supply line of the left lamp also sends a signal to the instrument panel C10 which illuminates the "main-beam on" warning lamp.

TROUBLESHOOTING TABLE

Malfunction	Component to be checked									
	(149)	(150)	EZ	ER	F9	F10	(B68)	(E23)	(E24)	(C10)
Both dipped beam lamps	.							.		
RH dipped beam lamp			.					.		
LH dipped beam lamp									.	
Both main beam lamps										
RH main beam lamp									.	
LH main beam lamp										.
Main beam warning lamp										.

FUNCTIONAL DESCRIPTION

The headlamp aiming device B69 is supplied at pin 56b by a line leading from the side lights circuit; this line receives voltage only when the side lights are on. The same supply (pin 58) turns on the led inside device B69 itself which illuminates the ideogram identifying the function.

Pins 31 of device B69 are earthed, while the adjustment signal obtained by pressing the four-position selection knob leads from pin G. This signal varies the output voltage through a potentiometer (100% voltage at position "0"; with voltage decreasing for the successive positions).

Motors P35a and P35b are formed by a motor in the strict sense of the word controlled by a transducer which establishes the stroke on the basis of the voltage of the adjustment signal reaching pin g, from device B69.

The transducers are supplied at pins 56b, by the same line that supplies device B69, while pins 31 are earthed.

Il sistema è azionabile solo a luci di posizione inserite - linea del fusibile F5 (10A); in caso contrario è completamente disattivato.

NOTA: Il sistema è realizzato in modo tale che, in caso di avaria, non può essere portato in una posizione "più alta" di quella in cui si trova, questo per evidenti ragioni di sicurezza.

GENERAL DESCRIPTION

For certain markets the car offers the possibility to adjust the headlight beam in relation to the load directly from the driver's seat.

In this way the problem of interventions caused by incorrect headlamp aiming is avoided and the delicate task of direct lamp adjustment is simplified (this is not substituted with the electrical device but integrated with it). For further details, see "155 - INSTRUCTIONS FOR REPAIR - BODY", Group 40.

The adjustment device consists of a motor fitted on each of the two headlamps which suitably slopes them to lower the beam when the car is heavily loaded and raise it when the load is lightened.

The driver operates the system directly by turning a knob on the dashboard, which allows four positions to be chosen according to the following table.

Knob position	Load conditions
0	driver only or driver and passenger on front seat
1	all seats occupied
2	all seats occupied plus load in the luggage compartment (up to the maximum allowable load on the rear axle)
3	driver plus load in luggage compartment up to the maximum allowable load on the rear axle


The system can be operated only when the side lights are on - line of fuse F6 (10A): it is completely de-activated when they are off.

NOTE: for safety reasons the system is designed so that in the event of a failure it cannot be moved to a higher position than the one it is already at.


FAULT-FINDING TABLE

Fault	Component to be checked	
	F6	B69 P35a P35b
Adjustment not working	•	•
RH headlamp		•
LH headlamp		•
Control device lighting	•	•

WIRING DIAGRAM





LOCATION OF COMPONENTS




CHECKING COMPONENTS

RH/LH headlamp adjustment motor (P35a) (P35b)



Operating diagram: trend of stroke C in relation to the voltage V/VG
 V = voltage between pin 56b and pin 31 (12V)
 VG = voltage between pin G and pin 31

Headlamp aiming control device (B69)



SPECIFICATIONS	
R1	390 Ω ± 2%
R2	1 kΩ
Voltage between terminals G and 31 (UG)	
Knob position 0	100% UB ± 3%
1	88.7% UB ± 3%
2	80% UB ± 3%
3	66.3% UB ± 3%

(UB: voltage between pins 31 and 56b = 12V)

REAR AND FRONT FOG-LAMP

REAR AND FRONT FOG-LAMPS

INDEX

WIRING DIAGRAM 7-2

GENERAL DESCRIPTION 7-3

FUNCTIONAL DESCRIPTION AND FUNCTIONAL TABLE 7-3

TROUBLESHOOTING TABLE 7-3

LOCATION OF COMPONENTS 7-4

INDEX

WIRING DIAGRAM


GENERAL DESCRIPTION

FUNCTIONAL DESCRIPTION

TROUBLESHOOTING TABLE

LOCATION OF COMPONENTS

WIRING DIAGRAM



GENERAL DESCRIPTION

Upon request, the vehicle is equipped with special halogen type fog-lamps and high luminosity rear lights located in the central part of the rear light assembly, necessary under low visibility conditions.

The entire system ensures the greatest visibility possible both active and passive under any conditions.

The front fog-lamps are illuminated by the switch located on the central console between the front seats; the rear fog-lamps by the control located on the lever group.

The front fog-lamps can be illuminated when the sidelights are on while the rear-fog-lamps only when the headlights are on dipped beam, or fog lamps are on.

A warning light on the instrument panel signals that the front fog-lamps are on and another signals illumination of the rear fog-lamps. Each of the two circuits is protected by a fuse.

The rear fog-lamps are controlled - for some versions - by the Check Panel device which immediately signals any

possible malfunction (see "Check Panel").

NOTE

In a few countries the vehicles are equipped with a single rear fog-lamp located on the left light assembly E31. The right light assembly E30 and the relative wiring is not altered in comparison to other versions apart from the simple elimination of the rear fog-lamp. These specific light assemblies are identified with a green spot located on the inner part.

FUNCTIONAL DESCRIPTION

The circuit pertaining to the front fog-lamps is controlled by relay B17 located in the fusebox G1.

By actuating switch B10 when the sidelights are on (switch on the lever group B68 at position "I"), a ground is sent which excites the coil of relay B17 and in this way closes the circuit which supplies the two front fog-lamps E10. Switch B10 is illuminated when the sidelights are on. The circuit is protected by fuse F19 (20A) in box G1.

The supply line also sends a signal to the instrument panel C10 to illuminate

the relative warning lamp; the line differs depending on the type of instrument panel C10 used (see "Instrument Panel").

The circuit of the rear fog-lamps is controlled by relay I25 located in fusebox G1.

With the switch on the lever group B68, when the headlights are on dipped beam (switch on the lever group at position "II"), voltage and ground are sent to the coil of relay I25 in this way closing the circuit which supplies the voltage to the rear fog light E31 (left) and E30 (right), the same takes place with the fog lamps on, via the special circuit inside the fusebox.

The circuit is protected by fuse F11 (7.5A) in box G1.


The supply line also sends a signal to the instrument panel C10 to illuminate the relevant warning lamp.

The rear fog-lamps are controlled by the Check Panel device and therefore signals are sent from the supply circuit both direct and by "SH" shunt) to the control unit N59 which checks the voltage of the line (for more details see (Check Panel)).

TROUBLESHOOTING TABLE

Malfunction	Component to be checked										
	(I25)	E11	(B68)	(E30)	(E31)	(I17)	F19	(B10)	(E10)	(E10)	(C10)
Both rear fog-lamps	•										
RH rear fog-lamp			•								
LH rear fog-lamp				•							
Rear fog-lamp warning light						•					
Both front fog-lamps											•
RH front fog-lamp											
LH front fog-lamp											
Front fog-lamp warning light											•
Front fog-lamp switch illumination											

LOCATION OF COMPONENTS



DIRECTION INDICATORS AND HAZARD WARNING LIGHTS

INDEX

WIRING DIAGRAM 8-2

GENERAL DESCRIPTION 8-3


FUNCTIONAL DESCRIPTION 8-3

TROUBLESHOOTING TABLE 8-3

LOCATION OF COMPONENTS 8-4

CHECKING COMPONENTS 8-5

WIRING DIAGRAM



GENERAL DESCRIPTION
 The intermittent direction indicators and hazard warning lights are positioned at the corners of the vehicle.

The right and left direction indicators are selected by raising or lowering the specific lever located in the lever group; the hazard warning lights (right and left direction indicators activated simultaneously) are switched on by acting on the switch located behind the steering wheel near the instrument panel.

The direction indicators operate when the ignition key is inserted, the hazard warning lights, for obvious reasons of safety, are supplied directly by the battery.

Two intermittent warning lamps located on the instrument panel flash when either the right or left direction indicator

has been selected. Another intermittent warning lamp signals the operation of the hazard warning lights.

The circuits of the direction indicators and the hazard warning lights are both protected by their own separate fuses.

FUNCTIONAL DESCRIPTION


The circuit is controlled by the hazard warning lights and direction indicators intermittence N13 located in fusebox G1.

The intermittence, grounded, pin 31, receives a supply signal, pin 49, through the hazard warning lights switch B12; when these are not selected, supply is key-operated through fuse F17 (7.5A) of fusebox G1; when the hazard warning lights are selected, the supply comes

TROUBLESHOOTING TABLE


Malfunction	Component									
	E1	E12	N13	B68	B12	E23	E24	E25	E26	C10
All direction indicators
Hazard warning lights
RH direction indicator
LH direction indicator
Front right light
Right side light
Right rear light
Front left light
Left side light
Left rear light
RH warning lamp
LH warning lamp
Hazard warning lights warning lamp

LOCATION OF COMPONENTS



CHECKING COMPONENTS

Hazard warning lights and direction Indicator intermittence (N13)



Check device: see TEST A

CHECK HAZARD WARNING LIGHTS AND DIRECTION INDICATOR INTERMITTENCE (N13)

TEST A


TEST PROCEDURE	RESULT	CORRECTIVE ACTION
<p>A1 CHECK VOLTAGE</p> <p>- Disconnect the intermittence N13 from the fusebox G1, and check on the base - with the key engaged or with the hazard warning lights on - for 12V at pin 49 of N13</p>	<p>OK</p> <p>OK</p>	<p>Carry out step A2</p> <p>Check fuses F17 and F1 of fusebox G1. If necessary, restore the wiring between G1 and B12</p>
<p>A2 CHECK EARTH</p> <p>- Check for 0V at pin 31 of N13</p>	<p>OK</p> <p>OK</p>	<p>Insert device N13 on the base and continue with step A3</p> <p>Restore the wiring between G1 and earth G148b</p>
<p>A3 CHECK INTERMITTENT VOLTAGE</p> <p>- With the key turned, operate the RH blinker and check for intermittent 12V at pin 49a of N13; in the same way operate the LH blinker, or the hazard warning lights</p>	<p>OK</p> <p>OK</p>	<p>DEVICE N13 IS WORKING PROPERLY</p> <p>Check the connections with the other components.</p> <p>NOTE: If the flashing frequency doubles, one of the bulbs has blown.</p> <p>CHANGE DEVICE N13</p>

STOP-LIGHTS

INDEX

WIRING DIAGRAM	9-2
GENERAL DESCRIPTION	9-3
FUNCTIONAL DESCRIPTION	9-3
TROUBLESHOOTING TABLE	9-3
LOCATION OF COMPONENTS	9-4

WIRING DIAGRAM



--- Only for versions with Check Panel
 (*) present for some markets only

GENERAL DESCRIPTION

The lights indicating that the vehicle is braking ("stop-lights") are operated each time the brake pedal is depressed; they are located at the rear of the vehicle in the side light assemblies. A third, central brake light is fitted for some markets. The lights are illuminated automatically by a switch located on the brake pedal and operate under all conditions, even when the ignition key is disengaged. The circuit is protected by its own fuse.

The correct functioning of the stop-lights is - for some versions - verified by the Check Panel which immediately alerts the driver in the event of a malfunction in the circuit. This is vital to safety. (see "Check Panel").

The braking signal from the switch is also sent to the ABS system control unit which recognizes the situation and as a consequence controls the braking parameters (see "A.B.S. System").

A radio anti-interference condenser has been fitted to vehicles equipped with radio-system to prevent disturbances from the brake switch.

FUNCTIONAL DESCRIPTION

The stop-light circuit is supplied directly by battery voltage through fuse F2 (25A) in the fusebox G1.
 The stop-lights switch H3 is formed by two contacts: the "rest position" contact is closed when the brake pedal is not

depressed and signals the continuity of the circuit to the Check Panel control unit N59.

By depressing the brake pedal the "operating position" contact is closed and the stop lights located in the rear light assemblies E25 (right) and E28 (left) and for markets where applicable - in the central brake light E28. From these supply circuits the signals (both direct and by "SH" shunt) are then sent to the control unit N59 which verifies the line load (see "Check Panel").


A radio anti-interference condenser N66 is connected in parallel to switch H3.

TROUBLESHOOTING TABLE

Malfunction	Component to be checked			
	E2	H3	E28	E29
All brake lights	•	•		
RH stop-light			•	
LH stop-light				•
"Third brake light" (*)				•

(*) Present for some markets only.

LOCATION OF COMPONENTS



REVERSING LIGHTS

INDEX

WIRING DIAGRAM 10-2

GENERAL DESCRIPTION 10-3


FUNCTIONAL DESCRIPTION 10-3

TROUBLESHOOTING TABLE 10-3

LOCATION OF COMPONENTS 10-4

- 1 present for some markets only

WIRING DIAGRAM



GENERAL DESCRIPTION

The vehicle is equipped with reversing lights located in the central part of the rear light assembly. When reverse gear is selected, the reversing lights are automatically engaged by way of a switch located on the gearbox.

The circuit is protected by a fuse.

The reversing lights are operated when the ignition key is inserted and are independent from the other lights on the vehicle.


FUNCTIONAL DESCRIPTION

The circuit of the reversing lights is under key operated supply and is routed through fuse F15 (15A) in fusebox G1. When reverse gear is engaged, switch H2 supplies the right (E30) and left (E31) reversing lights.

TROUBLESHOOTING TABLE

Malfunction	Component to be checked		
	E15	H2	E30 E31
Both reversing lights	•	•	
RH reversing light			•
LH reversing light			•

LOCATION OF COMPONENTS



INTERIOR LIGHTING

INDEX

GENERAL DESCRIPTION 12-2

LIGHTING OF CONTROLS AND IDEOGRAMS 12-2

CEILING LAMPS 12-4

INSTRUMENT CLUSTER LIGHTING 12-5

LOCATION OF COMPONENTS 12-7

FAULT-FINDING TABLE 12-8

CHECKING COMPONENTS 12-8

GENERAL DESCRIPTION

The numerous light sources make it easy to locate the controls and switches, and when necessary offer good lighting of the entire passenger compartment and/or of certain specific points. The wiring diagram referring to the interior lighting has been subdivided into three sections:

- the first one shows the lights which illuminate the ideograms of the controls and switches when the sidelights are on;
- the second one includes the ceiling lights and light points operated via the special limner which turns them off or on; for a few seconds when the doors are opened or closed;
- a third specific diagram is dedicated to instrument cluster lighting, as this is adjustable in intensity with a special rheostat.

Lighting of controls and ideograms: When the sidelights are on, the ideograms on the steering column lever unit are illuminated, and also the heater controls (for the automatic air conditioner, see "Climate control - control unit: supply and diagnosis").

The specific diagrams show the lighting of the ideograms of the Check Panel display, ashtray, seats adjustment, fog lamp switch.

In addition, the opening of the glovebox turns on a special light (see "Boot opening control").

N.B. Therefore, reference should be made to the above-mentioned sections for further details, and for fault-finding if the various ideograms fail to light up.

Ceiling lamps:

When the doors are opened and closed a timer device N10 turns on and off the front centre ceiling lamp F35, and the rear one F3. This device works according to the following logic:

- when any one door is opened the lights are turned on, the go off after appr. 100-200 seconds or if the doors are closed again;
- after closing the lights stay on for appr. 15 seconds, then they go off definitively;
- Turning the key to "MARCIA", liming is cut out;
- with the engine running, normal liming as described above takes place.

Of course, the two ceiling lamps may also be turned on manually, using the switch provided.

On the same element of the ceiling lamp there is also a spot light, supplied directly by the battery, which for example makes it possible to read without disturbing the driver.

NOTE: In the versions with alarm system, the rear ceiling lamp F3 incorporates the receiver for the signals of the remote control N67.

Lastly, a special lamp F5 illuminates the luggage compartment, controlled by the opening of the boot lid.

Instrument cluster lighting:

The instrument cluster C10 is illuminated through a rheostat B16, which adjusts the luminosity to the required level.


LIGHTING OF CONTROLS AND IDEOGRAMS

Functional Description

The steering column lever unit ideograms B68 are lit when the side lights are turned on: the left ones directly by the sidelights switch the right ones via a supply which returns from the fusebox G1.


Through the sidelights relay B64 and fuse F5 (10A) of G1 also the heater controls F8 are supplied (for the automatic conditioner see "Climate control - control unit: supply and diagnosis").

Wiring diagram



(*) Manual heater (for the automatic conditioner, see Sect. 26)

CEILING LAMPS
Wiring diagram



Functional Description
Passenger compartment ceiling lamps

The ceiling lamp with passenger compartment lighting controls (reading lamp) F35 receives the direct supply from the battery via fuse F16 (10A) of fusebox G1; this makes it possible to turn on the reading lamp or the ceiling lamp using the corresponding switch. When the sidelights are on F35 receives another supply which lights up the ideograms of the controls. The rear passenger compartment ceiling lamp F3 also receives a supply directly from the battery, still via fuse F16 (10A).

Timed ceiling lamps:

The electronic ceiling lamp timer device N10 - located in the rear under the seat - controls the turning on of ceiling lamps F35 and F3.

The battery voltage is supplied via fuse F16 (10A) of fusebox G1 to the electronic devices Ta and Tb of N10. The

timer also receives the "doors open" signal, at pin 11, from the Check Panel C16 which informs of the opening of any one door (this signal is the same that prevents the locking/release of the doors - see "Door locking device").

The timer Ta sends an earth signal, from pin 8 and 9, to the timed lamps F3 and F35 (supplied with battery voltage by the line of fuse F16) turning them on for appr. 1000-200 seconds when the doors are opened; when the "doors open" signal ceases the timer Tb sends the same earth signal turning on the lights again for appr. 15 seconds.

The "key-operated supply" reaches pin 2 which cuts out timing when the key is engaged.

Luggage compartment lighting:

The luggage compartment light F5 - not timed - is also supplied with battery voltage through the line protected by fuse F16 (10A); it is turned on when the boot is opened and switch H24 sends an earth signal.


INSTRUMENT CLUSTER LIGHTING

Functional Description


The instrument cluster C10 is illuminated supplying a series of bulbs (10) to be found inside it; this supply takes place through the cluster light dimming rheostat B16, which makes it possible to adjust the lighting to the level required.

The rheostat B16 is supplied with battery voltage, when the sidelights are on through the switch on the steering column lever unit B68, via relay R64 and fuse F6 (10A) of fusebox G1. Adjustment takes place on the earth signal which reaches the cluster bulbs, supplied by the "key-operated supply" (see also "Instrument Cluster").

Wiring diagram



LOCATION OF COMPONENTS




FAULT-FINDING TABLE

Fault	Component to be checked													
	(FB) (2)	E5	E6	(I63)	(B6B) (1)	E16	E4	(N10)	(F35) (2)	(F3) (2)	(F5) (2)	(H24)	(C10) (2)	(B16)
rear lights	•			•										
steering column lever				•										
all timed lights								•						
interior ceiling lamp								•						
rear passenger compartment lamps								•						
trunkage compartment light								•						
cluster lighting										•				•
cluster lighting adjustment														•

In the event of a fault on the lights/levers it is necessary to change the whole component only replace the bulbs with bulb holder

HECKING COMPONENTS

ceiling lamp timer (N10)



SPECIFICATIONS	
Door opening timer (Ta)	100 ± 200 sec.
Door closing timer (Tb)	15 ± 5 sec

Checking the device: see TEST A

CHECK CEILING LAMPS TIMER (N10) TEST A

TEST PROCEDURE	RESULT	CORRECTIVE ACTION
A1 CHECK VOLTAGE - Disconnect device N10 and check on the connector for 12 V at pin 5 and 6; with the key at MARCIA, 12 V at pin 2 of N10	OK	Carry out step A2
	OK	Check fuses F4 and F16 of G1. If necessary restore the wiring between N10 and G1
A2 CHECK EARTH - Check for 0 V at pin 7 of N10	OK	Carry out step A3
	OK	Restore the wiring between N10 and earth G63b
A3 CHECK EARTH SIGNAL - Open one of the four doors and check for an earth at pin 11 of N10	OK	Insert the device N10 on the connector, then carry out step A4
	OK	Restore the wiring between N10 and the Check Panel display C16
A4 CHECK EARTH SIGNAL - With the key at STOP, open one of the doors and check for 100 ± 200 sec. for an earth leaving pin 8 and 9 of N10; after re-closing the earth remains for approx. 15 sec.; with the key at MARCIA this signal must cease	OK	Restore the wiring between N10 and ceiling lamps F35 and F3
	OK	CHANGE DEVICE N10

INSTRUMENT PANEL

INDEX

GENERAL DESCRIPTION	13-2
INSTRUMENT CLUSTER SUPPLY	13-2
REV COUNTER AND SPEEDOMETER	13-4
BRAKING SYSTEM WARNING LIGHTS	13-6
ENGINE OIL INDICATORS	13-8
VARIOUS INDICATORS	13-10
INTERNAL CIRCUITRY	13-11
LOCATION OF COMPONENTS	13-13
TROUBLESHOOTING TABLE	13-14
CHECKING COMPONENTS	13-15

GENERAL DESCRIPTION


The instrument cluster provides all the indications and information concerning conditions of the vehicle which are indispensable for safe driving. The instrument cluster is of the analogue type with two generously sized indicators for the speedometer and rev counter, other gauges for the engine oil temperature and pressure, fuel level and coolant fluid temperature. A series of plainly visible warning lights complete the information given to the driver.

(B): The instrument cluster is made as a single component, all the internal connections are made on a printed circuit which contains the contacts of the instruments and of the different warning lights. Therefore, repair operations are not possible except for the replacement of warning light bulbs (see "CHECKING COMPONENTS").

Note: the wiring diagram has been subdivided into 6 parts:

- the first 5 diagrams describe certain specific functions: here a description is only given of those functions that are not dealt with elsewhere and connected only with the indications of the instrument cluster; other functions, i.e. the check warning lights, are included in the diagram of the system to which they belong; for example the high beam warning light is to be found in the diagram: "High-Low beam headlights", etc....
- the sixth diagram involves all the internal connections of the printed circuit of the cluster itself.

The instrument cluster lighting, supplied when the sidelights are on, is adjusted by a special rheostat (B16) in a circuit described separately (see "Interior lighting").




INSTRUMENT CLUSTER SUPPLY

Functional Description


The instrument cluster is supplied by battery voltage via fuse F15 (15A) of fusebox G1. Connection takes place at pin 2 of connector E of the cluster C10. The cluster C10 is earthed through the cable leading from pin 4 of connector E to earth G148b.

Wiring Diagram



REV COUNTER AND SPEEDOMETER

Wiring Diagram



car at all times.

This is a pulse generator which, through a Hall-effect probe, generates and processes a signal that is proportionate with the speed of the transmission shaft at the gearbox output, and therefore that of the wheels.

Sensor L17 is supplied at pin 3 with stabilized voltage through an electronic device inside the cluster (from pin 1 of connector A of C10); pin 1 is connected to earth G53b, while the tachometric signal (proportionate with the speed of the car) leads from pin 2 and is sent to the cluster C10 at pin 4 of connector A, and from here to the electronic device that operates the speedometer and the two odometers (total and trip).

Functional Description

The rev counter signal is sent to the instrument cluster by the Motronic control unit S11, which receives a signal proportionate with engine rpm from sensor S31 (see "MOTRONIC supply system").

The signal reaches the cluster C10 at pin 6 of connector D, leading from connector G133a which connects the Motronic system with the other circuits; inside the cluster it then reaches the electronic device which operates the rev counter.

The speedometer signal is sent by the tachometric sensor L17; this is fitted on the gearbox and detects the speed of the


The same signal is also sent to certain other systems which need the "car speed" information:

- through connector G59 to the air conditioning system, i.e. to control unit Q21a, the control of which engages the radiator fan when the car is stationary (see "Climate control: automatic climate control with air conditioner");

- through connector G133a to the Motronic control unit S11 which optimises certain operating strategies according to the speed of the car.

BRAKING SYSTEM WARNING LIGHTS

Wiring Diagram



Functional Description

Three warning lights alert the driver in the event of problems in the braking system.

The brake pad switch H10, which comprises a microswitch on the pad, connects to earth when the pad thickness is reduced, sending a signal to the cluster C10 at pin 1 of connector D thereby

turning on the "brake pad wear warning light".

The handbrake switch H1 and the minimum brake fluid level control switch H17 (two microswitches which send an earth signal) send a signal to the cluster C10, to pin 7 of connector C; both turn on the "handbrake engaged or low brake fluid level warning light".


The former closes when the handbrake

lever is pulled, and the latter when the level of the fluid in the braking system, in the storage reservoir, falls below a certain reference level.

The third warning light involving the braking system is the "ABS system failure" warning light described in the corresponding chapter (see "ABS System").

ENGINE OIL INDICATORS

Wiring Diagram



Functional Description

The oil pressure transmitter L8 sends an earth signal to the cluster C10, at pin 8 of connector D, for the analogue oil pressure indicator. This is a pressure switch fitted in a suitable position on the crankcase which generates a signal proportionate with the pressure of the engine oil. Similarly the oil temperature transmitter


L44 sends an earth signal to the cluster C10, at pin 3 of connector B, for the analogue oil temperature indicator. A thermostat in contact with the engine oil detects its temperature.

In addition the minimum oil pressure contact L2, also fitted on the crankcase, closes when the pressure falls below the limit of 0.2 + 0.5 bar, thereby sending an earth signal to the cluster C10 at pin 2 of connector D turning on the "minimum oil

pressure" warning light. The "minimum oil pressure" warning light is connected to the Check Panel C16 (see "Check Panel") which, if the oil level in the sump is low, turns on the corresponding led and sends a signal to the cluster C10 at pin 11 of connector E.

VARIOUS INDICATORS

Wiring Diagram



Variant for models 1.6 - 1.8 - 2.0 m.y. '96

when the tank is empty).

An earth signal reaches pin 1 of L9, while a signal proportionate with the level is sent from pin 2, through the fusebox, to the cluster C10, at pin 3 of connector E.

Inside the fuel level gauge an electronic device selects the signal corresponding to reserve (262 Ω, corresponding to approx. 7 litres) and turns on the warning light.

The switch on the seat belts R9 is located on the driver's buckling device; when the belt is correctly inserted it opens the contact and cuts off the earth signal to the cluster C10 (pin 6 of connector E) thereby turning off the "seat belts unfastened" warning light.

The other warning lights not described here are to be found in the wiring diagram of the system to which they belong.

Functional Description

The engine coolant temperature is continuously displayed by the analogue indicator, while if the temperature is too high the "maximum coolant temperature" warning light turns on.

The engine coolant temperature transmitter and maximum temperature warning light contact L10 is fitted on the engine head and comprises a thermistor which generates a signal proportionate with the temperature of the fluid and a contact which closes to earth when the fluid reaches 122°C. The first signal is sent to the cluster C10 at pin 1 of connector B, and the second to pin 4 of connector D.

The fuel level transmitter L9 is a sensor submerged in the fuel tank, the resistance of which changes as the level of the fuel in the tank changes (from 0-7 Ohm with a full tank to 280-310 Ohm


INTERNAL CIRCUITRY

This wiring diagram represents the printed circuit and the connections inside the instrument cluster C10.


In the other diagrams referring to the outside connections of the cluster itself (or in those of the single circuits connected with the warning lights inside the cluster) only the lines concerned are shown, while this diagram gives an overview of the whole cluster C10.

NOTE: not all the output pins are connected for all the versions of the vehicle; therefore this diagram may not contain - as indicated - lines not used (for example warning lights not connected but present in the printed circuit).

Wiring Diagram



LOCATION OF COMPONENTS



TROUBLESHOOTING TABLE

NOTE: The faults of warning lights not described here are to be found in the section concerning the system to which they refer: for the high beam warning light, see the section "High and low beam lamps". The faults described here as "warning light not working" summarize all the cases in which the behaviour of the warning light does not correspond to correct operation, es. the warning light turns on to signal a fault and the fault does not exist, or vice-versa a function is engaged but the warning light fails to show it etc...


Fault	Component to be checked											
	E15	C10	L17	L8	L43	L2	L10	L9	R9	H17	H1	H10
All the cluster is off	•											
Tachometer		•										
Rev counter			•									
Oil p. gauge			•									
Oil t. gauge				•								
Water t. gauge						•						
Fuel gauge								•				
Handbrake warning light										•		
Brake pad warning light											•	
Min oil p. warning light									•			
Max water t. warning light											•	
Seat belt warning light												•

CHECKING COMPONENTS



Instrument cluster (C10)

N.B.: The cluster is made as a single component: all the internal connections are made on a printed circuit which joins the contacts of the instruments and various warning lights. Therefore it is not possible to carry out repairs, other than changing warning light bulbs:


- warning light bulbs (A);
- cluster lighting bulbs (B).



Tachometric sensor (L17)




Engine coolant temperature gauge warning light and max. temperature warning light contact transmitter (L10)




SPECIFICATIONS		
Transmitter		
Temperature °C	Resistance Ω	Type of fluid for test
60	525 ± 605	Water
90	195 ± 245	Water
120	82 ± 94	Glycerine
Contact		
Contact closing	122 ± 2°C	
Contact opening	112 ± 3°C	

Transmitter for oil pressure gauge (L8)




SPECIFICATIONS	
Pressure bar	Resistance Ω
0	305 ± 15
2	190 ± 15
4	118 ± 15
8	20 ± 20

Transmitter for oil temperature gauge (L44)



SPECIFICATIONS	
Oil temperature °C	Resistance Ω
50	800 ± 900
70	350 ± 450
90	180 ± 220


Fuel level transmitter (L9)



SPECIFICATIONS	
Level (see figure)	Resistance (Ω)
4/4	0 ± 7
3/4	56 ± 71
1/2	111 ± 131
1/4	181 ± 206
start of reserve (*)	262
0	290 ± 320

(*) appr. 7 litres


Min. engine oil pressure contact (L2)



SPECIFICATIONS	
Contact closing (pressure falling)	0.2 - 0.5 bar
Contact opening (pressure rising)	0.2 ± 0.5 bar

NOTE: In certain versions engine oil minimum pressure contact (L2) is fitted instead of the oil pressure gauge sender (LB)

Min. brake fluid level switch (H17)



SPECIFICATIONS	
The float closes the contact if dimension C (see figure) exceeds 40 ± 1 mm.	

NOTE: to check whether the switch is working it is sufficient to lightly press on the upper end of the cover. In this case the contact closes and it is possible to check that the warning light is working properly.