



GROUP 13

MECHANICAL TRANSMISSION

TABLE OF CONTENTS

| | | | |
|--|---------|--|---------|
| GEARBOX | 13 - 3 | ON VEHICLE OPERATIONS | 13 - 37 |
| - Description | 13 - 3 | GEARBOX OUTER LINKAGE | 13 - 39 |
| - Removal/Installation | 13 - 5 | - Description | 13 - 39 |
| - Bench disassembly | 13 - 11 | - Removal/Installation | 13 - 40 |
| - Transmission shaft disassembly | 13 - 16 | - Disassembly/Reassembly | 13 - 40 |
| - Main shaft disassembly | 13 - 18 | - Checks and Inspections | 13 - 41 |
| - Checks and Inspections | 13 - 19 | TECHNICAL CHARACTERISTICS AND | |
| - Main shaft reassembly | 13 - 21 | SPECIFICATIONS | 13 - 42 |
| - Transmission shaft reassembly | 13 - 22 | - Technical data | 13 - 42 |
| - Bench reassembly | 13 - 24 | - Fluids and lubricants | 13 - 42 |
| DIFFERENTIAL | 13 - 29 | - Sealants and adhesives | 13 - 43 |
| - Description | 13 - 29 | - Checks and adjustments | 13 - 43 |
| - Removal | 13 - 30 | - Tightening torques | 13 - 43 |
| - Bench disassembly | 13 - 30 | - Special tools | 13 - 45 |
| - Checks and Inspections | 13 - 32 | TROUBLESHOOTING PROCEDURE | 13 - 46 |
| - Reassembly | 13 - 34 | | |
| - Installation | 13 - 35 | | |
| - Adjustment | 13 - 36 | | |

[Page 53](#)

[Page 54](#)

[Page 55](#)

[Page 56](#)

[Page 57](#)

[Page 58](#)

[Page 59](#)



GROUP 13

MECHANICAL TRANSMISSION

TABLE OF CONTENTS

GEARBOX 13 - 3

- Description 13 - 3
- Removal/Installation 13 - 5
- Bench disassembly 13 - 11
- Transmission shaft disassembly 13 - 16
- Main shaft disassembly 13 - 18
- Checks and Inspections 13 - 19
- Main shaft reassembly 13 - 21
- Transmission shaft reassembly 13 - 22
- Bench reassembly 13 - 24

DIFFERENTIAL 13 - 29

- Description 13 - 29
- Removal 13 - 30
- Bench disassembly 13 - 30
- Checks and Inspections 13 - 32
- Reassembly 13 - 34
- Installation 13 - 35
- Adjustment 13 - 36

ON VEHICLE OPERATIONS 13 - 37

GEARBOX OUTER LINKAGE 13 - 39

- Description 13 - 39
- Removal/Installation 13 - 40
- Disassembly/Reassembly 13 - 40
- Checks and Inspections 13 - 41


TECHNICAL CHARACTERISTICS AND SPECIFICATIONS 13 - 42

- Technical data 13 - 42
- Fluids and lubricants 13 - 42
- Sealants and adhesives 13 - 43
- Checks and adjustments 13 - 43
- Tightening torques 13 - 43
- Special tools 13 - 45

TROUBLESHOOTING PROCEDURE 13 - 46


ILLUSTRATED INDEX

GEARBOX
REMOVAL/INSTALLATION (page 13 - 5)
BENCH DISASSEMBLY (page 13 - 11)
TRANSMISSION SHAFT DISASSEMBLY (page 13 - 16)
MAIN SHAFT DISASSEMBLY (page 13 - 16)
CHECKS AND INSPECTIONS (page 13 - 19)
MAIN SHAFT REASSEMBLY (page 13 - 21)
TRANSMISSION SHAFT REASSEMBLY (page 13 - 22)
BENCH REASSEMBLY (page 13 - 24)




GEARBOX OUTER LINKAGE
DESCRIPTION (page 13 - 39)
REMOVAL/INSTALLATION (page 13 - 40)
DISASSEMBLY/REASSEMBLY (page 13 - 40)
CHECKS AND INSPECTIONS (page 13 - 41)


DIFFERENTIAL
REMOVAL (page 13 - 30)
BENCH DISASSEMBLY (page 13 - 30)
CHECKS AND INSPECTIONS (page 13 - 32)
REASSEMBLY (page 13 - 34)
INSTALLATION (page 13 - 35)
ADJUSTMENT (page 13 - 36)



ON VEHICLE OPERATIONS
DIFFERENTIAL CASING OIL SEAL REPLACEMENT -
GEARBOX SIDE (page 13 - 37)
DIFFERENTIAL CASING OIL SEAL REPLACEMENT -
ENGINE SIDE (page 13 - 38)







GEARBOX

DESCRIPTION

The gearbox is of the transversal "cascade" type, and offers five forward speeds, all synchronized, with gears always driven and final reduction cylindrical gear pair.

The gearbox gearing is contained in the aluminum casing, whilst the 5th speed gear is contained in the rear cover.

The gearbox is connected to the engine through the clutch cone. On top side of the gearbox on differential side, is located an oil dipstick used to check level of oil (Min-Max) in the gearbox.


Draining of the oil, on both differential and gearbox sides, is performed removing drain plugs (A) and (B).

The shape of the gearbox divides this unit into three distinct sections.

The intermediate section consists of an independent casing that contains and supports the direct drive shaft, the main shaft, the transmission shaft, and the speed engagement rods and forks.

The rear section (rear cover) supports the speed selection and engagement cross, directly connected to the "cloche" type speed selector lever.

The front section (clutch cone) includes the clutch unit and thrust bearing, and the relevant actuating system.



CROWN GEAR



DIFFERENTIAL CASING

13 - 3

The gears for 1st, reverse and 2nd speeds have been machined directly on main shaft, while gears for 3rd, 4th and 5th speeds and relevant synchronizers are installed on bearings; furthermore, the main shaft is supported by two ball bearings.

On transmission shaft are installed, by means of bearings, the gears and relevant synchronizers for 1st-2nd speed, whilst those for 3rd, 4th and 5th speed are keyed to the shaft; the transmission shaft is supported by two bearings: the bearing at pinion end is of the roller type, while the opposite one is of the ball type.

Gears for forward speeds are of the helical type with all speeds synchronized; reverse speed gears are of the straight toothing type.

A new feature of this gearbox concerns the 3rd, 4th and 5th speed gears and relevant synchronizers which have been installed on main shaft to reduce engagement loads during synchronization phase, and noise produced by the gearbox during idle operation.

Unlike other gearboxes, the drive coming from the engine, when the gearbox is idling, is transmitted only to the gears of 1st and 2nd speeds.



The reverse speed driven gear is machined on the 1st-2nd speed engagement sleeve.

This solution reduces the overall dimensions of the gears in the gearbox.

All the idle gears are mounted on needle bearings that, reducing the frictions, minimize the radial runout.

The synchronizers are of the tapered ring, Borg Warner type; they are identical for the 3rd, 4th and 5th speeds, and smaller than those for the 1st and 2nd speeds installed on the transmission shaft, thus reducing the noise produced by gears when in drive.


A first pawl device prevents simultaneous engagement of two speeds. A second device (pawl-pin-spring) acts on 3rd-4th-5th and reverse speed rods to maintain the reverse speed pawl in a safe position and prevent dangerous movements of reverse speed fork, and consequent possibility of engagement of reverse speed. A third device consisting of a lever and a spring prevents inadvertent engagement of reverse speed when shifting from 5th to 4th




To reduce frictions and increase accuracy of gear engagement, the gearbox has been provided with a spheric control that transmits the movement to the selector prong through a shaft. The selector prong actuates the sliding rods carrying the synchronizer sleeve control forks. Therefore, a fork and rod is provided for the engagement of 1st-2nd speed, another one for engagement of 3rd-4th speed, another for engagement of 5th speed and a last

speed.

one for engagement of reverse speed.




A substantial modification has been embodied to forks: on forks of the new gearboxes (A) the center of thrust coincides with centerline of sleeve, in order to prevent crawling during engagement of speeds. The above mentioned coincidence is not present on forks of conventional gearboxes (B).



REMOVAL/INSTALLATION


1. Place vehicle on autolift.
2. Place jacks at the front of vehicle.
3. Position chocks to rear wheels.
4. Remove engine hood (refer to Group 55).

6. Disconnect battery leads.



70.11 to 77.49 N.lbs
(95 to 105 N-m)

7. Disconnect oil vapor recirculation hose.
8. Disconnect idle speed adjustment pipe.
9. Remove clamp and disconnect duct from intake box.
10. Disconnect air flow meter electrical connector.
11. Release clips securing air filter cover.
12. Remove air filter cover - air flow meter - intake duct assembly.
13. Remove air filter.




4. Remove engine hood (refer to Group 50).
5. Remove front wheels.



- 14. Remove air filter canister.
- 15. Disconnect electrical connector, vacuum pipe and cruise control cable, then remove cruise control actuator (refer to **Group 04**).
- 16. If the vehicle is equipped with a vibration damper on


the clutch circuit, detach the damper fixing bracket from the air filter support, and move it aside without disconnecting the pipes.

- 17. Remove air filter support bracket.



- 18. Remove front exhaust pipes.

- 19. Remove rear exhaust manifold complete of engine starter shroud.







MECHANICAL TRANSMISSION


164



- 20. Remove clutch master cylinder complete of support bracket, and fix them to sidewall of vehicle.
- 21. Disconnect back-up lamps switch.
- 22. "S" version only: disconnect gearbox sensor electrical connector.
- 23. Disconnect ground strip.
- 24. Disconnect odometer sensor.
- 25. Release clips and remove gear selector cover.




- 26. Remove left front fender.






17.7 to 22.8 ft.lbs
(24 to 31 N·m)




FRONT
FENDER


27. Remove the left front suspension electrical connector protective cover from rear fender ("S" version only).
28. Disconnect left front suspension electrical connector ("S" version only).




29. Remove brake caliper and place it in the upper side of wheelhouse.
30. Disconnect left constant speed joint from differential flange.
31. Withdraw pin of steering cross tie-rod spherical joint using tool No. 1.821.174.000.



32. Disconnect spherical joint from suspension arm.
33. Disconnect shock absorber group, complete of hub and axle shaft, from dome.



34. Remove flywheel cover.
35. Disconnect speed engagement control rod
36. Remove speed selection rod bracket.





34.7 to 42.8 ft.lbs
(47 to 58 N-m)

STEERING CROSS
TIE-ROD SPHERICAL
JOINT


1.821.174.000

FLYWHEEL
COVER







- 37. Remove gearbox attaching screw and install lifting bracket on gearbox unit using the screw.
- 38. Install engine support cross beam No. 1.820.581.000 and engage it to relevant lifting brackets.
- 39. Remove gearbox mount.
- 40. Remove plug and drain oil from gearbox-differential. (Refill gearbox with prescribed oil at installation).




- 41. Remove right front fender.



- 42. Disconnect right axle constant speed joint from intermediate shaft.





AGIP DEXRON II
SHELL ATF DEXRON II




14 to 22.1 ft.lbs
(19 to 30 N·m)




34.7 to 42.8 ft.lbs
(47 to 58 N·m)

43. Remove screw securing intermediate shaft flange to rear engine mount and withdraw shaft from differential.

NOTE: Slightly lift engine with a column type hydraulic jack, if required.



44. Disconnect speed selector control rod to gain access to screw securing gearbox mount.
45. Remove screws securing gearbox to engine, with the exception of screw (*) which must be left installed.
46. Connect hook of a suitable hoist and lift gearbox after




Engine compartment

47. Remove solenoid valve group from support and fix it properly, paying particular care to prevent damaging of connected pipes.

NOTE: Disconnect solenoid valve group, if required (refer to Group 22).


screw (*) has been removed.

48. Remove solenoid valve group support.




Wheel hub

49. Remove the ABS inductive sensor.




BENCH DISASSEMBLY

1. Fix support plate No.1.820.146.000 to gearbox flange.
2. Install gearbox on rotary stand.
3. Extract flange from differential (using tool No. 1.821.059.000 and 1.821.161.000).
4. Remove rear cover.







(4.8 to 6 N·m)



5. Remove caulking of main and transmission shaft ring nuts.
6. Remove screw securing 5th speed engagement fork to main shaft.
7. Lock gearbox shaft engaging 5th speed by hand (pressing the fork on main shaft) and engaging a speed by means of the selection lever.
8. Loosen main and transmission shaft ring nuts.
9. Return main shaft fork to idle position.




10. Remove ring nuts securing main and transmission shaft gears.
11. Withdraw hub-sleeve assembly with fork and drive gear with 5th speed synchronizer ring from main shaft.
12. Remove roller bearing and bushing of 5th speed gear from main shaft.




13. withdraw 5th speed driven gear from transmission shaft.




14. Remove gearbox rear bearings retaining plate.



- 15. Remove retaining rings securing gearbox rear bearings.
- 16. Remove retaining cover of speed control rod positioning balls and springs.
- 17. Remove speed engagement idler arm.
- 18. Remove gearbox casing backing speed control




19. Remove reverse speed idle gear fork lever.




10. Remove gearbox casing backing speed control shaft.




- 20. Remove 1st and 2nd speed rod and fork.
- 21. Remove 3rd and 4th speed rod and fork.
- 22. Remove 5th and reverse speed rod.




- 23. Remove safety pawls.
- 24. Remove reverse speed idle gear and shaft.




- 25. Remove main shaft assembly.
- 26. Remove transmission shaft assembly.



- 27. Remove thrust bearing control shaft and fork.
- 28. Remove thrust bearing sleeve.
- 29. Remove idler lever and speed control rod.




"S" version only







30. Remove complete speed selector shaft.



TRANSMISSION SHAFT DISASSEMBLY

1. Using a press and suitable equipment, remove rear bearing, washer ("S" version only) and 4th speed driven gear.
2. Withdraw spacer.

3. Using a press and suitable equipment, remove 3rd and 2nd speed driven gears and 2nd speed synchronizer ring.
4. Withdraw 2nd speed driven gear needle bearing.









5. Remove retaining ring securing 1st and 2nd speed engagement sliding hub.
6. Using a press and suitable equipment, remove 1st-2nd speed engagement sliding hub and reverse gear assembly.
7. Withdraw 1st speed driven gear needle bearing.

8. Remove retaining ring securing front bearing.
9. Using press and suitable equipment, remove front bearing from transmission shaft.







MAIN SHAFT DISASSEMBLY

1. Using a press and suitable equipment, remove rear bearing and 4th speed drive gear assembly with relevant needle bearing and bushing.
2. Withdraw 3rd speed drive gear and 3rd-4th speed engagement sliding sleeve assembly complete of hub and 3rd-4th speed synchronizer rings.
3. Withdraw 3rd speed drive gear needle bearing.

4. Using a press and suitable equipment remove front bearing from main shaft.







CHECKS AND INSPECTIONS


Gearbox support - Central casing - Cover


1. Check rods and bearing seating for cracks, wear or damages.
Check that contact surfaces are level (minor defects can be removed with a fine file).
2. Check for oil leaks: replace sleeve and seal assembly, if necessary.
3. Check fork control shaft for excessive play; replace bushings, if necessary.
4. Check bushing surfaces for seizing.
5. Check speed control rod for distortion or eccentricity, and wear of surfaces in contact with bushings.



Main and transmission shafts

1. Check gear teeth for nicks or excessive wear, and inner surfaces for seizing or abnormal wear.
2. Check hubs and sliding sleeves for nicks, freedom of movement, excessive play and seizing. Check sleeve inner teeth for excessive wear.
3. Check synchronizer rings for ovalization of inner surface.
4. Check rear bearing for scoring of outer race, inner ring and balls, signs of overheating or excessive wear.






"S" version only




5. Check main and transmission shaft gears for nicks or excessive wear.
- Following high mileage, replace also all transmission shaft gears if main shaft is replaced.
 - Replace also the differential crown gear in case of replacement of transmission shaft.



Rods and forks


1. Check rods for distortion, wear and freedom of movement without excessive play.
2. Check forks for distortion or wear of surfaces mating the sliding sleeves.






MAIN SHAFT REASSEMBLY

- Using a press and suitable tool, install front bearing.




- Install 3rd speed drive gear needle bearing.



- Install 3rd speed drive gear and 3rd-4th speed engagement sliding sleeve assembly, complete of hub and 3rd-4th speed synchronizer rings.
- Using a press and suitable tool, install rear bearing and 4th speed drive gear with relevant needle bearing and bushing.




("S" version only) When assembling the hub, make sure that an oil groove matches the hole on the main shaft.






TRANSMISSION SHAFT REASSEMBLY



1. Using a press and suitable tool, install front bearing.
2. Install retaining ring securing bearing.



3. Install needle bearing, 1st speed driven gear and 1st speed synchronizer ring.
4. Using a press and suitable tool, install 1st and 2nd speed sliding sleeve hub.
5. Install retaining ring securing hub.



6. Install 1st and 2 speed engagement sliding sleeve - reverse speed gear.
7. Insert springs and pins into hub.
8. Install 2nd speed driven gear needle bearing.
9. Install 2nd speed synchronizer ring.
10. Install 2nd speed driven gear.
11. Using a press and suitable tool, install 3rd speed driven gear.




**NEEDLE
BEARING**


13 - 22



- 12. Install spacer.
- 13. Using a press and suitable tool, install 4th speed driven gear.




- 14. ("S" version only) Instal washer.
- 15. Using a press and suitable tool, install rear bearing.




BENCH REASSEMBLY


1. Install throw-out bearing sleeve.
2. Install throw-out bearing engagement rod and fork.




3. Install speed control rod and idler arm.



4. Insert main and transmission shafts.



5. Insert safety pawls (use tool No. 1.821.047.000).








6. Install reverse speed shaft and idle gear.




Ensure gear engagement toothing is faced downwards.



7. Install 3rd and 4th speed rod, fork and prong.




Before installing rod, install safety pawl into rod.




8. Install 5th and reverse speed rod and control prong.



Before installing prong, install safety pawl into prong.



9. Install 1st and 2nd speed rod and fork. Remove 3rd and 4th speed control rod to make installation easy.







317 11 1/2

13 - 25


10. Install reverse speed idle gear fork lever.




11. Insert speed control shaft into cover without tightening attaching screws.



12. Install gearbox casing backing speed control shaft to make engagement easy.



13. Tighten screws securing speed control shaft bushing.



SPEED CONTROL
SHAFT




13 - 26




14. Install speed control rods positioning balls and springs.



Install spring made with wire of greater diameter on 5th and reverse speed control rod.




15. Install speed engagement idler arm.
16. Install retaining rings securing bearings.



17. Install rear bearings retaining plate.




17.7 to 22.9 ft.lbs
(24 to 31 N·m)




- 18. Install 5th speed driven gear onto transmission shaft.
- 19. Install 5th speed drive gear bushing and needle bearing onto main shaft.
- 20. Install 5th speed drive gear with synchronizer ring and hub-sliding sleeve assembly with fork and rollers and springs retaining flange.
- 21. Install ring nuts securing main and transmission shaft gears. Perform caulking after tightening.




("S" version only) When assembling the hub, make sure that an oil groove matches the hole on the main shaft.







22. Install 5th speed engagement fork attachment screw.



23. Install rear cover.

24. Install flange.

 Wipe contact surfaces with sealant.






DIFFERENTIAL

DESCRIPTION

The differential consists of a reduction pair and a differential casing including crown wheels and side pinions. The differential casing is supported by two taper bearings, and is divided in two sections matched by the same screws securing the cylindrical crown gear.


The odometer gear, made of teflon, is installed on outer surface of casing. The backlash between crown wheels and side pinions is determined using variable thickness rings placed below crown wheels.

The pre-load adjustment system of differential taper bearings is analogous to that of other known groups, in other words it is obtained by means of variable thickness rings located below relevant seal cover.




REMOVAL

1. Remove gearbox and place it on relevant stand (refer to: "GEARBOX REMOVAL/INSTALLATION").
2. Withdraw flange from differential (using a lever); using tool No. 1.821.059.000 and tool No. 1.821.161.000.




3. Remove differential casing seal cover-gearbox side, with O'Ring and seal.
4. Remove differential casing seal cover-engine side, and shim ring.

6. Remove differential assembly.



BENCH DISASSEMBLY

1. Withdraw roller bearings using tool 1.821.034.000.




5. Remove differential cover.







2. Remove odometer gear.



3. Remove differential casing crown gear.
4. Remove differential casing halves.




5. Remove spring pin securing side pinion shaft.
6. Remove side pinion shaft from casing half.
7. Remove side pinions and relevant shoulder washers.
8. Remove crown wheels from casing halves together with roller cages and shim rings.



CHECKS AND INSPECTIONS


Gearing

1. Check bearing for scoring, traces of overheating or excessive wear.
2. Check crown gear for nicks or excessive wear.
- Replace also gearbox transmission shaft in case of replacement of crown gear (after high mileage).
3. Check side pinions shaft for seizing, wear or excessive play into casing half.
4. Check side pinions and crown wheels for nicks or wear of working surfaces.




Crown wheels and side pinions backlash check.

1. Install shim ring, crown wheel and relevant roller cage, complete side pinion shaft and relevant retaining pin into casing half.



| mm | In |
|-----|-------|
| 1.0 | 0.039 |
| 1.1 | 0.043 |
| 1.2 | 0.047 |
| 1.3 | 0.051 |
| 1.4 | 0.055 |




2. Insert tool No. 1.820.125.000 and install a magnetic base dial gauge with its probe contacting upper end of tool.
Rotate and move tool axially; verify that average axial play is between 0.07 to 0.20 mm (0.00276 and 0.0079 in).


NOTE: Check that variation of axial play in a complete revolution of tool is ≤ 0.10 mm (≤ 0.0039 in).
Replace crown wheel and/or side pinions if above condition is not met.

! If necessary, insert new shim rings of proper thickness.

13 - 32



3. Install second crown wheel and relevant roller cage and shim ring with thickness equal to that of previously installed ring.
4. Join the two casing halves aligning reference notches.
5. Install crown gear and lock it momentarily.




6. Insert tool No. 1.820.125.000 and install a magnetic base dial gauge with its probe contacting upper end of tool.
Rotate and move tool axially; verify that average axial play is between 0.07 to 0.20 mm (0.00276 and 0.0079 in).

NOTE: Check that variation of axial play in a complete revolution of tool is ≤ 0.10 mm (≤ 0.0039 in). Replace crown wheel and/or side pinions if above condition is not met.

If necessary, insert new shim rings of proper thickness.




Shim rings installed on crown wheels must be of the same thickness.




REASSEMBLY


1. Carry-out crown wheels and side pinions backlash checks before reassembly (refer to: "CHECKS AND INSPECTIONS").




2. Join the two casing halves aligning the reference notches.
3. Install crown gear.




4. Using a press and suitable tool, install roller bearing.



5. Install odometer gear.



6. Using a press and suitable tool, install roller bearing.










INSTALLATION

1. Insert magnet into its seating.
2. Insert differential assembly into gearbox.
3. Install cover (wipe contact surfaces with sealant).
4. Install odometer idle gear into differential cover.

5. Install oil seal into seal cover using specified tool.
6. Install O'ring on cover.
7. Install seal cover - gearbox side.
8. Settle outer race of roller bearing into seating (engine side).



9. Install shim ring of suitable thickness (refer to "DIFFERENTIAL ADJUSTMENT").
10. Install oil seal into seal cover using specified tool.
11. Install O'ring on cover.
12. Install seal cover - engine side.
13. Install left axle shaft securing flange.




ADJUSTMENT

Differential casing bearings shim ring thickness determining

NOTE: After the exact thickness of shim ring has been determined, select thickness closest to determined value among spare shim rings.



If determined thickness does not correspond to any of available rings, or to the sum of thickness of two rings, install immediately higher thickness rings.



$$S = P - H + 0.12$$

Fixed number corresponding to prescribed interference for bearing setting. VALID FOR MEASURES IN mm ONLY.

| mm | In |
|------|-------|
| 1.25 | 0.049 |
| 1.30 | 0.051 |
| 1.35 | 0.053 |
| 1.40 | 0.055 |
| 1.45 | 0.057 |
| 1.50 | 0.059 |
| 1.55 | 0.061 |



| | |
|------|-------|
| 1.60 | 0.063 |
|------|-------|


13 - 36




ON VEHICLE OPERATIONS

Differential casing oil seal replacement - gearbox side


1. Remove front wheels.
2. Remove left front fender.



3. Disconnect left axle shaft from differential flange.





4. Remove oil seal.
5. Install replacement oil seal using proper tool.
6. Remove plug and drain oil.
7. Extract flange from differential (using a lever).



Differential casing oil seal replacement - engine side

1. Remove right front fender.
2. Disconnect right axle shaft from intermediate shaft.

3. Remove oil seal.
4. Install replacement oil seal using proper tool.
5. Remove bolts securing intermediate shaft flange to engine mount and withdraw shaft from differential.







GEARBOX OUTER LINKAGE


DESCRIPTION

The gearbox outer linkage, that is a mechanical connection between speed selector lever and the gearbox, consists of a speed selection and engagement rod, an reaction rod provided at forward end with a rubber block fixed to gearbox bracket, and with rear end free to slide inside a second rubber block fixed to a bracket on the tunnel.

The rubber block allows sliding of rear end of anchor rod into its seating during engine oscillations.

The peculiar attachment system of the two rods prevents the speed selector lever from noticeable angular oscillations when engine is subject to working stress (abrupt break-away, irregular idling, etc).


This is obtained since the speed engagement control assembly is not fixed to vehicle body, but it is sustained by the rubber block. In this way only minor movements are present on the control assembly. Furthermore, this solution prevents possible disengagement of speeds.



REMOVAL/ INSTALLATION

1. Remove speed selector lever knob.
2. Remove speed selector lever console (refer to Group 66).


3. Disconnect reaction rod from bracket on gearbox.
4. Disconnect speed selection and engagement rod from flexible coupling.
5. Remove nuts securing bellow - cover assembly.
6. Remove rubber block and remove gearbox control.



DISASSEMBLY/REASSEMBLY

1. Speed selection and engagement rod.
2. Speed selection rod.
3. Speed selector lever.

4. Cover.
5. Cup.
6. Safety ring.
7. Rubber block.





**6.4 to 8.3 ft.lbs
(8.7 to 11.2 N·m)**


13 - 40



CHECKS AND INSPECTIONS

1. Check flexible coupling bushes for wear.
2. Check speed selection and engagement rod joint bushings for wear.

3. Check speed control lever ball and cup for wear.
4. Check below for integrity.
5. Check rubber block for integrity.





TECHNICAL CHARACTERISTICS AND SPECIFICATIONS

TECHNICAL DATA

GEARBOX RATIOS

| Model | Axle ratio | Engaged gear | Gearbox ratio | Overall ratio | Vehicle speed at 1000 rpm |
|-------------|------------------|--------------|---------------|---------------|---------------------------|
| 164 - 164 L | 18/56 (3.111) | 1 | 1:3.500 | 1:10.888 | 6.70 mph |
| | | 2 | 1:2.176 | 1:6.769 | 10.75 mph |
| | | 3 | 1:1.518 | 1:4.722 | 15.46 mph |
| | | 4 | 1:1.132 | 1:3.521 | 20.74 mph |
| | | 5 | 1:0.916 | 1:2.849 | 25.62 mph |
| | | R | 1:3.545 | 1:11.028 | 6.62 mph |
| 164 S | 17/58 (3.412) | 1 | 1:3.500 | 1:11.942 | 6.03 mph |
| | | 2 | 1:2.176 | 1:7.425 | 9.69 mph |
| | | 3 | 1:1.523 | 1:5.916 | 13.85 mph |
| | | 4 | 1:1.156 | 1:3.944 | 18.25 mph |
| | | 5 | 1:0.916 | 1:3.125 | 23.03 mph |
| | | R | 1:3.545 | 1:12.096 | 5.95 mph |

FLUIDS AND LUBRICANTS

| Application | Type | Name |
|---|--------|--|
| Gearbox-differential unit oil servicing | OIL | AGIP DEXRON II SHELL ATF DEXRON II |
| Throw-out bearing seating and clutch disengagement fork joint | GREASE | AGIP GREASE 33 FD |
| Gear lever ball and speed select/engagement rod bushings | GREASE | ISECO MOLIKOTE LONGTERM No.2 FIAT GRAS/IX |
| Power steering oil reservoir servicing | OIL | AGIP DEXRON II SHELL ATF DEXRON II |



SEALANTS AND ADHESIVES

| Application | Type | Name |
|-------------------------------|---------|-------------|
| Rear cover and gearbox casing | SEALANT | LOCTITE 573 |

CHECKS AND ADJUSTMENTS

DIFFERENTIAL

| Model | Crown wheel/side pinion backlash |
|----------------------|---|
| 164 164 L 164S | 0.07 to 0.20 mm (0.00276 to 0.0079 in) |

NOTE: Backlash between crown wheels and side pinions is adjusted by using spare rings with a thickness ranging from 1.80 to 2.20 mm (0.071 to 0.087 in).

TIGHTENING TORQUES

GEARBOX AND DIFFERENTIAL

| | | |
|--|-----------------------|---------------|
| Screw securing clutch disengagement sleeve support cover | 5.2 to 6.6 ft.lbs | 7 to 9 Nm |
| Screw securing left and right side covers to casing | 17.7 to 22.9 ft.lbs | 24 to 31 Nm |
| Screws securing gearbox casing to support | 17.7 to 22.9 ft.lbs | 24 to 31 Nm |
| Screws securing rear cover to gearbox casing | 17.7 to 22.9 ft.lbs | 24 to 31 Nm |
| Threaded plug, draining gearbox oil | 14.0 to 22.1 ft.lbs | 19 to 30 Nm |
| Screw securing differential cover to engine-gearbox support (55 mm - 2.16 in long) | 17.7 to 22.9 ft.lbs | 24 to 31 Nm |
| Screw securing differential cover to engine-gearbox support (20 mm - 0.79 in long) | 35.4 to 45.7 ft.lbs | 48 to 62 Nm |
| Screw retaining gearbox control rod spring | 14.0 to 22.1 ft.lbs | 19 to 30 Nm |
| Ring nut, locking main shaft gears | 105.5 to 136.4 ft.lbs | 143 to 185 Nm |
| Ring nut, locking transmission shaft gears | 105.5 to 136.4 ft.lbs | 143 to 185 Nm |
| Screw securing main shaft rear bearing retaining plate | 17.7 to 22.9 ft.lbs | 24 to 31 Nm |
| Screw securing transmission shaft rear bearing retaining plate | 17.7 to 22.9 ft.lbs | 24 to 31 Nm |
| Self-locking screw securing 1st and 2nd speed fork | 17.7 to 22.9 ft.lbs | 24 to 31 Nm |
| Self-locking screw securing 3rd and 4th speed prong | 17.7 to 22.9 ft.lbs | 24 to 31 Nm |
| Self-locking screw securing 3rd and 4th speed fork | 17.7 to 22.9 ft.lbs | 24 to 31 Nm |

(Cont.d)


GEARBOX AND DIFFERENTIAL

| | | |
|---|---------------------|-------------|
| Self-locking screw securing reverse and 5th speed prong | 17.7 to 22.9 ft.lbs | 24 to 31 Nm |
| Screw securing complete reverse lever | 17.7 to 22.9 ft.lbs | 24 to 31 Nm |
| Self-locking screw securing 5th speed fork | 17.7 to 22.9 ft.lbs | 24 to 31 Nm |
| Screw securing gearbox control shaft bushing to casing | 5.2 to 6.6 ft.lbs | 7 to 9 Nm |
| Self-locking nut securing gear lever to internal shaft | 17.7 to 22.9 ft.lbs | 24 to 31 Nm |
| Screw securing external lever to outer shaft | 17.7 to 22.9 ft.lbs | 24 to 31 Nm |
| Screw securing odometer support | 5.9 to 8.8 ft.lbs | 8 to 12 Nm |
| Self-locking screw securing crown gear | 59.7 to 66.4 ft.lbs | 81 to 90 Nm |

GEARBOX OUTER LINKAGE

| | | |
|---|---------------------|----------------|
| Screw securing speed engagement reaction rod rear flexible block | 4.1 to 5.4 ft.lbs | 5.6 to 7.3 Nm |
| Screw securing speed engagement lever-ball joint to complete support | 4.1 to 5.4 ft.lbs | 5.6 to 7.3 Nm |
| Self-locking nut securing end of rod support to bracket on gearbox | 4.1 to 5.4 ft.lbs | 5.6 to 7.3 Nm |
| Screw securing speed engagement reaction rod bracket to gearbox | 7.4 to 8.8 ft.lbs | 10 to 12 Nm |
| Self-locking nut securing speed engagement tie-rod fork to gear lever | 6.4 to 8.3 ft.lbs | 8.7 to 11.2 Nm |
| Screw securing speed engagement tie-rod to coupling | 11.8 to 15.5 ft.lbs | 16 to 21 Nm |
| Screw securing coupling to gearbox output rod | 14.0 to 18.4 ft.lbs | 19 to 25 Nm |
| Self-locking nut securing rod cover to body | 3.4 to 5.3 ft.lbs | 4.6 to 7.2 Nm |
| Self-locking nut securing anti-vibration weight on gearbox reaction rod | 8.8 to 11.8 ft.lbs | 12 to 16 Nm |

ENGINE-GEARBOX SECURING DEVICES

| | | |
|--|---------------------|---------------|
| Screw securing gearbox assembly to engine | 26.8 to 33.2 ft.lbs | 36.4 to 45 Nm |
| Screw securing gearbox assembly to support | 29.5 to 36.9 ft.lbs | 40 to 50 Nm |



SPECIAL TOOLS

| Tool number | Description |
|---------------|--|
| 1.820.018.000 | Half rings for: - extracting main shaft rear bearing - extracting main shaft 4th speed drive gear |
| 1.820.023.000 | Half plate extracting transmission shaft front bearing |
| 1.820.024.000 | Half plate supporting half rings (use with 1.820.018.000) |
| 1.820.043.000 | Half rings for: - extracting transmission shaft 4th speed driven gear - extracting transmission shaft rear bearing |
| 1.820.046.000 | Half rings for: - extracting transmission shaft 2nd and 3rd speed driven gears - extracting transmission shaft 2nd speed synchronizer - extracting transmission shaft 1st speed driven gear sliding sleeve-hub |
| 1.820.047.001 | Plate supporting half rings (use with 1.820.043.000) |
| 1.820.047.003 | Plate supporting half rings (use with 1.820.046.000) |
| 1.820.085.000 | Tool for measuring shim thickness for differential casing bearings |
| 1.821.034.000 | Differential bearings puller |
| 1.821.047.000 | Guide for fitting 1st, 3rd and 5th speed safety pawls |
| 1.821.059.000 | Differential flange puller (use with 1.821.161.000) |
| 1.821.092.000 | Guide for: - main shaft front and rear bearings - transmission shaft rear bearing - transmission shaft 4th speed driven gear |
| 1.821.049.000 | Half plate for extracting/inserting main shaft front and rear bearings |
| 1.821.161.000 | Ram (use with 1.821.059.000) |
| 1.821.169.000 | Puller for steering tie-rod pin |
| 1.821.170.000 | Key for fitting differential cover oil seal (use with 1.821.171.000) |
| 1.821.171.000 | Grip (use with 1.821.170.000) |
| 1.820.125.000 | Tool, differential axial play check |
| 1.820.146.000 | Plate for supporting gearbox on rotary stand |
| 1.820.581.000 | Beam for supporting engine |
| | Guide for: - transmission shaft front bearing - transmission shaft 1st and 2nd speed engagement sliding sleeve-hub - transmission shaft 3rd speed driven gear |
| | Guide for differential bearings |



TROUBLESHOOTING PROCEDURE






| TROUBLES AND SYMPTOMS | FAULT ISOLATION | TEST REFERENCE |
|---|--|----------------|
| | <p>When origin of the noise has been identified, and consequently it is not produced by the engine, identify the malfunctioning group as indicated below:</p> <ul style="list-style-type: none"> - Start engine. - Maintain the gearbox to idle; in this condition it is possible to note noises. - Bring the vehicle to the speed at which the noise is particularly evident. - To locate the malfunction properly, engage different gear speeds alternatively in the logic sequence, while adjusting the vehicle speed. - While performing the above mentioned procedure, some difficulties in engaging the gear speeds, excessive slack in the gear control, or malfunction of the reverse gear electrical circuit could be encountered. | |
| NOISY GEARBOX DIFFERENTIAL GROUP | | A |
| NOISY GEARBOX WHEN IN NEUTRAL (VEHICLE NOT IN MOTION) | | B |
| CONSTANT NOISE DURING RUN AND WITH GEARBOX IN NEUTRAL | | C |
| NOISE OF A SPECIFIC GEAR SPEED DURING BOTH ACCELERATION AND DECELERATION | | D |



TROUBLESHOOTING PROCEDURE

| TROUBLES AND SYMPTOMS | FAULT ISOLATION | TEST REFERENCE |
|--|-----------------|----------------|
| NOISE DURING ACCELERATION AND DECELERATION, MOSTLY PRESENT IN 4TH OR 5TH GEAR | | E |
| KNOCKS DURING PICKUP OR GEAR SPEED CHANGE | | F |
| NOISE DURING CURVES, BOTH IN NORMAL RUN AND IN NEUTRAL | | G |
| NOISY REVERSE GEAR | | H |
| BINDING OF GEARBOX CONTROLS, AND POSSIBLE NON-RETURN OF SELECTOR LEVER TO NEUTRAL | | I |
| EXCESSIVE SLACK DURING GEAR SPEED SELECTIONS, AND NOISE/VIBRATIONS OF SELECTOR LEVER | | J |
| DIFFICULT OR NOISY (CLASHING) ENGAGEMENT OR DISENGAGEMENT OF GEAR SPEEDS | | K |
| INSUFFICIENT SENSIBILITY OF GEAR ENGAGEMENT | | L |

| | |
|---|---------------|
| NOISY GEARBOX/DIFFERENTIAL GROUP | TEST A |
|---|---------------|




| TEST STEPS | | RESULTS | REMEDY |
|------------|--|---|---|
| A1 | OIL LEVEL CHECK | | |
| | - Check oil level | <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div> | Carry-out step A2 |
| | | <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div> | Top-up oil to proper level |
| A2 | OIL CHECK | | |
| | - Check that the gearbox is serviced with oil of the approved type | <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div> | Carry-out step A3 |
| | | <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div> | Service with oil of the approved type |
| A3 | OIL LEAKS CHECK | | |
| | - Check for absence of oil leaks through the differential mount oil seals, through the filler plug or through the drain plug | <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div> | Replace oil seals or plugs , as necessary |

End of test A

13 - 48




| | |
|--|---------------|
| NOISY GEARBOX WHEN IN NEUTRAL (VEHICLE NOT IN MOTION) | TEST B |
|--|---------------|

| TEST STEPS | | RESULTS | REMEDY |
|------------|---------------------------------|---|---|
| B1 | ENGINE IDLE CHECK | | |
| | - Check engine idle RPM setting | <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div> | Carry-out step B2 |
| | | <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div> | Adjust engine idle RPM to correct value |
| B2 | OIL LEVEL CHECK | | |
| | - Check oil level | <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div> | Top-up oil to proper level |

MECHANICAL TRANSMISSION

| | |
|--|---------------|
| CONSTANT NOISE DURING RUN AND WITH GEARBOX IN NEUTRAL | TEST C |
|--|---------------|

| TEST STEPS | | RESULTS | REMEDY |
|--|-----------------------|--|--|
| C1 | BEARINGS CHECK | | |
| - Check that main and secondary shaft bearings are not worn or damaged | |  | Replace bearings and check their housings |

End of test C


13 - 50

MECHANICAL TRANSMISSION

184



| | |
|---|---------------|
| NOISE OF A SPECIFIC GEAR DURING BOTH ACCELERATION AND DECELERATION | TEST D |
|---|---------------|


| TEST STEPS | | RESULTS | REMEDY |
|---|--------------------|--|----------------------|
| D1 | GEARS CHECK | | |
| <ul style="list-style-type: none">- Check that gear teeth mating surfaces are not worn and free of meshing traces | |  | Replace gears |

End of test D

13 - 51



| | |
|--|---------------|
| NOISE DURING ACCELERATION AND ACCELERATION, MOSTLY PRESENT IN 4TH OR 5TH GEAR | TEST E |
|--|---------------|

| TEST STEPS | | RESULTS | REMEDY |
|------------|---|--|--|
| E1 | SPUR GEAR PAIR CHECK |  | Restore correct play or replace the spur gear pair |
| - | Check the spur gear pair for wear, damages and excessive play | | |

End of test E

13 - 52




| | |
|--|---------------|
| KNOCKS DURING PICKUP OR GEAR SPEED CHANGE | TEST F |
|--|---------------|

| TEST STEPS | | RESULTS | REMEDY |
|--|-------------------------------------|---|--|
| F1 | SPUR GEAR PAIR CHECK | | |
| - Check the spur gear pair for wear, damages and excessive play | | <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">○ OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px; margin-top: 5px;"> <div style="text-align: center;">○ OK</div> <div style="font-size: 2em;">▶</div> </div> | <p>Carry-out step F2</p> <p>Restore correct play or replace the spur gear pair</p> |
| F2 | CROWN GEAR ATTACHMENTS CHECK | | |
| - Check for looseness of crown gear attachments | | <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">○ OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px; margin-top: 5px;"> <div style="text-align: center;">○ OK</div> <div style="font-size: 2em;">▶</div> </div> | <p>Carry-out step F3</p> <p>Tighten screws</p> |
| F3 | SPIDER PIN CHECK | | |
| - Check for wear of spider pin and relevant seating on differential case | | <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">○ OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px; margin-top: 5px;"> <div style="text-align: center;">○ OK</div> <div style="font-size: 2em;">▶</div> </div> | <p>Carry-out step F4</p> <p>Replace differential unit</p> |
| F4 | PINION SHAFT CHECK | | |
| - Check pinion shaft retaining nut for looseness | | <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">○ OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px; margin-top: 5px;"> <div style="text-align: center;">○ OK</div> <div style="font-size: 2em;">▶</div> </div> | <p>Carry-out step F5</p> <p>Tighten or replace nut</p> |



NOISE DURING CURVES, BOTH IN NORMAL RUN AND IN NEUTRAL

TEST G


| TEST STEPS | | RESULTS | REMEDY |
|------------|---|--|---------------------------|
| G1 | GEAR TEETH CHECK |  | Replace differential unit |
| | - Check planetary and crown gear teeth for wear, damages and traces of gear meshing | | |

End of test G







13 - 54



| | |
|---------------------------|---------------|
| NOISY REVERSE GEAR | TEST H |
|---------------------------|---------------|


| TEST STEPS | | RESULTS | REMEDY |
|--|--------------------|--|-------------------------|
| H1 | GEARS CHECK |  | Replace defective items |
| - Check reverse gears for wear and damages | | | |

| | |
|--|---------------|
| BINDING OF GEARBOX CONTROLS, AND POSSIBLE NON-RETURN OF SELECTOR LEVER TO NEUTRAL | TEST I |
|--|---------------|

| TEST STEPS | | RESULTS | REMEDY |
|---|----------------------------------|---|--|
| I1 | GEARBOX LINKAGE CHECK | | |
| - Check gearbox linkage for binding or looseness | |   | Carry-out step I2 |
| | |   | Tighten or replace defective items |
| I2 | LINKAGE LUBRICATION CHECK | | |
| - Check for proper lubrication of gearbox linkage | |   | Lubricate gearbox linkage as required |




End of test I



13 - 56










| | |
|--|---------------|
| EXCESSIVE SLACK DURING GEAR SPEED SELECTIONS, AND NOISE/ VIBRATIONS OF SELECTOR LEVER | TEST J |
|--|---------------|

| TEST STEPS | | RESULTS | REMEDY |
|------------|--|--|---|
| J1 | LINKAGE ITEMS CHECK |  | Check for proper torque of attaching items, and replace defective items |
| - | Check for wear of selector lever spherical unit, flexible joint bushings and gear selection rod knuckle bushings | | |

DIFFICULT OR NOISY (CLASHING) ENGAGEMENT OR DISENGAGEMENT OF GEAR SPEEDS

TEST K

| TEST STEPS | | RESULTS | REMEDY |
|------------|--|--|---|
| K1 | GEARS CHECK | | |
| | - Check gear teeth for nicks or excessive wear, inner surfaces for traces of gears meshing |  ▶  ▶ | Carry-out step K2 Replace defective gears |
| K2 | HUBS AND SLIDING SLEEVES CHECK | | |
| | - Check hubs and sliding sleeves for nicks, excessive wear and play, and freedom of movement |  ▶  ▶ | Carry-out step K3 Replace sliding sleeves |
| K3 | SYNCHRONIZER RINGS CHECK | | |
| | - Check synchronizer rings for elongation and wear of the inner surface |  ▶  ▶ | Carry-out step K4 Replace synchronizer rings |
| K4 | PAWL SPRINGS CHECK | | |
| | - Check sleeve hub pawl springs for integrity |  ▶ | Replace sliding sleeves |

End of test K

13 - 58



| | |
|--|---------------|
| INSUFFICIENT SENSIBILITY OF GEAR ENGAGEMENT | TEST L |
|--|---------------|

| TEST STEPS | | RESULTS | REMEDY |
|------------|---|--|--|
| L1 | FORK CONTROL RODS CHECK | | |
| | - Check bushings of fork control rods for wear or seizure | <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">○ OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">○ OK</div> <div style="font-size: 2em;">▶</div> </div> | <p>Carry-out step L2</p> <p>Replace worn or defective items</p> |
| L2 | PAWLS CHECK | | |
| | - Check pawls and relevant springs for integrity | <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">○ OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">○ OK</div> <div style="font-size: 2em;">▶</div> </div> | <p>Carry-out step L3</p> <p>Replace defective items</p> |
| L3 | RODS CHECK | | |
| | - Check rods for wear, distortion and freedom of movement | <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">○ OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">○ OK</div> <div style="font-size: 2em;">▶</div> </div> | <p>Carry-out step L4</p> <p>Replace rods</p> |
| L4 | SELECTOR FORK CHECK | | |
| | - Check selector fork for wear or damage | <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">○ OK</div> <div style="font-size: 2em;">▶</div> </div> | <p>Replace selector</p> |

